



SEPTEMBER 2003  
LS1016A  
LS1032A

# BLACK BOX® Advanced Console Server

## Version 2.1.4 Revision 1a - User Guide



CUSTOMER  
SUPPORT  
INFORMATION

Black Box Corporation - 1000 Park Drive - Lawrence, PA 15055-1018  
Tech Support and Ordering: 724-746-5500 (1-877-877-BBOX) - Fax: 724-746-0746  
To contact us about Black Box products or services: [info@blackbox.com](mailto:info@blackbox.com)

---

---

# **BLACK BOX® Advanced Console Server User Guide**

## **Version 2.1.4 Revision 1a**

September, 2003

Copyright © Black Box Corporation, 2003

We believe the information in this manual is accurate and reliable. However, we assume no responsibility, financial or otherwise, for any consequences of the use of this product or manual. This manual is published by Black Box Corporation, which reserves the right to make improvements or changes in the products described in this manual as well as to revise this publication at any time and without notice to any person of such revision or change. The operating system covered in this manual is v2.1.4. All brand and product names mentioned in this publication are trademarks or registered trademarks of their respective holders.

Black Box, BLACK BOX ® Advanced Console Server, LS1032A, LS1016A are registered trademark of Black Box Corporation.

Microsoft, Windows 95, 98, XP, ME, NT, and 2K are trademarks of Microsoft Corporation.

UNIX is a trademark of UNIX System Laboratories, Inc.

Linux is a registered trademark of Linus Torvalds.

This document contains proprietary information of Black Box and is not to be disclosed or used except in accordance with applicable contracts or agreements. ©Black Box, 2003

All rights reserved. This document may not, in whole or part, be copied, photocopied, reproduced, translated, or converted to any electronic or machine-readable form without the prior written consent of Black Box.

Product Version 2.1.4 Revision 1a

Document Number 2.1.4-Draft 27a

---

---

# Table of Contents

---

## Preface

Purpose . . . . .	13
Audience and User Levels . . . . .	13
New Users . . . . .	13
Power Users . . . . .	13
How to use this Guide . . . . .	14
Conventions and Symbols . . . . .	15
Fonts . . . . .	15
Hypertext Links . . . . .	15
Glossary Entries . . . . .	16
Quick Steps . . . . .	16
Parameter Syntax . . . . .	16
Note Box Icons . . . . .	18

## Chapter 1 - Introduction and Overview

The BLACK BOX Advanced Console Server . . . . .	19
What's in the box . . . . .	20
Safety Instructions . . . . .	23
Battery . . . . .	25
FCC Warning Statement . . . . .	26
Aviso de Precaución S-Mark Argentina . . . . .	26
Trabajar dentro del BLACK BOX® Advanced Console Server . . . . .	28
Batería . . . . .	29

## Chapter 2 - Installation, Configuration, and Usage

Introduction . . . . .	31
System Requirements . . . . .	31
Default Configuration Parameters . . . . .	32
Pre-Install Checklist . . . . .	33
Task List . . . . .	34
The Wizard . . . . .	34
Quick Start . . . . .	36
Configuration using a Console . . . . .	36
Configuration using a Web browser . . . . .	39
Configuration using Telnet . . . . .	46
The Installation and Configuration Process . . . . .	49

# Table of Contents

---

---

Task 1: Connect the BLACK BOX ® Advanced Console Server to the Network and other Devices . . . . .	49
Task 2: Configure the COM Port Connection and Log In . . . . .	52
Task 3: Modify the System Files . . . . .	54
Task 4: Edit the pslave.conf file . . . . .	57
Task 5: Activate the changes . . . . .	60
Task 6: Test the configuration . . . . .	60
Task 7: Save the changes . . . . .	61
Task 8: Reboot the BLACK BOX ® Advanced Console Server . . . . .	61
Accessing the Serial Ports . . . . .	62
Opening and closing a telnet session to a serial port . . . . .	62
Opening and closing an SSH session to a serial port . . . . .	62
Accessing Serial Ports using “ts_menu” . . . . .	63
Accessing Serial Ports using the Web Interface . . . . .	64

## Chapter 3 - Additional Features

Introduction . . . . .	65
Configuration Wizard - Basic Wizard . . . . .	66
Using the Wizard through your Browser . . . . .	72
Access Method . . . . .	73
Configuration for CAS . . . . .	73
Configuration for TS . . . . .	88
Configuration for Dial-in Access . . . . .	96
Authentication . . . . .	100
Parameters Involved and Passed Values . . . . .	100
Configuration for CAS, TS, and Dial-in Access . . . . .	102
NIS Client . . . . .	112
NIS Client Configuration . . . . .	112
How to Test the Configuration . . . . .	113
nsswitch.conf file format . . . . .	114
Examples . . . . .	114
CAS Port Pool . . . . .	115
How to Configure it . . . . .	116
Clustering . . . . .	118
Parameters Involved and Passed Values . . . . .	119
Centralized Management - the Include File . . . . .	122
Enhanced Clustering . . . . .	125
CronD . . . . .	134
Parameters Involved and Passed Values . . . . .	134

# Table of Contents

---

Configuration for CAS, TS, and Dial-in Access . . . . .	135
Data Buffering . . . . .	137
Introduction . . . . .	137
Linear vs. Circular Buffering . . . . .	138
Parameters Involved and Passed Values . . . . .	138
Configuration for CAS . . . . .	140
DHCP . . . . .	150
Parameter Involved and Passed Values . . . . .	150
Configuration for CAS, TS, and Dial-in Access . . . . .	152
Dual Power Management . . . . .	154
Parameters Involved and Passed Values . . . . .	154
Configuration for CAS . . . . .	154
Configuration for TS . . . . .	155
Configuration for Dial-in Access . . . . .	155
Filters and Network Address Translation . . . . .	156
Description . . . . .	156
Structure of the iptables . . . . .	156
Syntax . . . . .	157
Parameters Involved and Passed Values . . . . .	166
Configuration for CAS, TS, and Dial-in Access . . . . .	166
Generating Alarms . . . . .	172
Port Slave Parameters Involved with Generating Alarms . . . . .	172
Configuration for CAS, TS, and Dial-in Access . . . . .	172
Syslog-ng Configuration to use with Alarm Feature . . . . .	179
Alarm, Sendmail, Sendsms and Snmptrap . . . . .	181
Help . . . . .	188
Help Wizard Information . . . . .	188
Help Command Line Interface Information . . . . .	189
NTP . . . . .	195
Parameters Involved and Passed Values . . . . .	195
Configuration for CAS, TS, and Dial-in Access . . . . .	196
PCMCIA . . . . .	197
Supported Cards . . . . .	197
Tools for Configuring and Monitoring PCMCIA Devices . . . . .	197
Ejecting Cards . . . . .	197
PCMCIA Network Configuration . . . . .	198
Wireless LAN PC Cards . . . . .	199
Modem PC Cards . . . . .	200
Establishing a Callback with your Modem PC Card . . . . .	202
ISDN PC Cards . . . . .	206

# Table of Contents

---

---

Establishing a Callback with your ISDN PC Card . . . . .	208
Establishing a Callback with your ISDN PC Card (2nd way) . . . . .	210
Ports Configured as Terminal Servers. . . . .	213
TS Setup Wizard. . . . .	213
Serial Settings . . . . .	219
Parameters Involved and Passed Values. . . . .	219
Configuration for CAS . . . . .	220
CLI Method . . . . .	228
Configuration for TS . . . . .	229
Configuration for Dial-in Access . . . . .	233
Session Sniffing . . . . .	235
Versions 2.1.0 and later . . . . .	235
Parameters Involved and Passed Values. . . . .	237
Configuration for CAS . . . . .	238
SNMP . . . . .	246
Configuration for CAS, TS, and Dial-in Access. . . . .	248
Syslog . . . . .	249
Port Slave Parameters Involved with syslog-ng . . . . .	250
Configuration for CAS, TS, and Dial-in Access. . . . .	250
The Syslog Functions . . . . .	256
Terminal Appearance . . . . .	271
Parameters Involved and Passed Values. . . . .	271
Configuration for CAS, TS, and Dial-in Access. . . . .	272
Time Zone. . . . .	280
How to set Date and Time . . . . .	281

## Appendix A - New User Background Information

Users and Passwords. . . . .	283
How to show who is logged in and what they are doing . . . . .	283
Linux File Structure . . . . .	284
Basic File Manipulation Commands . . . . .	285
The vi Editor . . . . .	286
The Routing Table . . . . .	288
Secure Shell Session . . . . .	289
The Process Table. . . . .	293
TS Menu Script . . . . .	294

# Table of Contents

---

## Appendix B - Cabling, Hardware, and Electrical Specifications

General Hardware Specifications . . . . .	297
Rear Panel LEDs . . . . .	299
Ethernet Connector . . . . .	299
Console Connector . . . . .	299
Serial Connector . . . . .	299
The RS-232 Standard . . . . .	300
Cable Length . . . . .	301
Connectors . . . . .	302
Straight-Through vs. Crossover Cables . . . . .	303
Which cable should be used? . . . . .	303
Cable Diagrams . . . . .	304

## Appendix C - The pslave Configuration File

Introduction . . . . .	311
Configuration Parameters . . . . .	311
CAS, TS, and Dial-in Common Parameters . . . . .	311
CAS Parameters . . . . .	321
TS Parameters . . . . .	331
Dial-in Access Parameters . . . . .	333

## Appendix D - Linux-PAM

Introduction . . . . .	337
The Linux-PAM Configuration File . . . . .	339
Configuration File Syntax . . . . .	339
Newest Syntax . . . . .	342
Module Path . . . . .	343
Arguments . . . . .	346
Directory-based Configuration . . . . .	347
Default Policy . . . . .	348
Reference . . . . .	356

# Table of Contents

---

---

## Appendix E - Software Upgrades and Troubleshooting

Upgrades . . . . .	357
The Upgrade Process . . . . .	357
Troubleshooting . . . . .	359
Flash Memory Loss . . . . .	359
Hardware Test . . . . .	362
Port Test . . . . .	362
Port Conversation . . . . .	363
Test Signals Manually . . . . .	363
Single User Mode . . . . .	364
Troubleshooting the Web Configuration Manager . . . . .	366
What to do when the initial Web page does not appear . . . . .	366
How to restore the Default Configuration of the Web Configuration Manager . . . . .	366
Using a different speed for the Serial Console . . . . .	366
CPU LED . . . . .	368

## Appendix F - Certificate for HTTP Security

Introduction . . . . .	369
Procedure . . . . .	369

## Appendix G - IPSEC

Introduction . . . . .	373
Basic IPsec Knowledge . . . . .	373
Using IPsec to create a VPN . . . . .	374
The Authentication . . . . .	374
The Encryption . . . . .	374
The software parts . . . . .	375
IPSec Configuration . . . . .	375
The configuration file . . . . .	375
General comments on ipsec.conf . . . . .	375
The setup section of ipsec.conf . . . . .	376
Connection defaults . . . . .	378
Editing a connection description . . . . .	379
Example file for BLACK BOX ® Advanced Console Server-to-network connection . . . . .	382



# Table of Contents

---

IPsec Usage .....	384
The IPsec Daemon .....	384
Adding and Removing a Connection .....	384
Starting and Stopping a Connection .....	385
Generating the RSA key pair .....	385
Generating an RSA key pair .....	386
Debugging Commands .....	386
IPsec look .....	386
IPsec whack .....	387
IPsec and Road Warriors .....	388
IPsec, Security for the Internet Protocol .....	388
Applications of IPsec. ....	389
Configuration .....	390
Before you Start .....	390
Set up and test networking .....	390
Enabling IPsec .....	390
Quick Start .....	390
“Road Warrior” remote access .....	390
BLACK BOX® Advanced Console Server-to-network VPN .....	393
Setting up RSA authentication keys .....	394
Generating an RSA key pair .....	395
Exchanging authentication keys .....	395
The Configuration File .....	396
Description .....	396
Conn Sections .....	398
Config Sections .....	402
Recommended Configuration .....	403
IPsec Usage .....	403
The IPsec Daemon .....	404
Adding and Removing a Connection .....	404
Starting and Stopping a Connection .....	404

# Table of Contents

---

---

## Appendix H- Web User Management

Introduction . . . . .	405
Default Configuration for Web User Management . . . . .	405
How Web User Management works . . . . .	407
Task 1: Check the URL in the Access Limit List. . . . .	407
Task 2: Read the Username and the Password . . . . .	408
Task 3: Look for the group retrieved in the user groups list . . . . .	408
Web User Management Configuration - Getting Started. . . . .	408
Changing the Root Password. . . . .	409
Adding and Deleting Users . . . . .	409
Adding a User. . . . .	409
Deleting a User. . . . .	410
Adding and Deleting User Groups . . . . .	411
Adding a group . . . . .	411
Deleting a group . . . . .	411
Adding and Deleting Access Limits. . . . .	412
Adding an Access Limit . . . . .	412
Deleting an access limit . . . . .	413

## Appendix I - Connect to Serial Ports from Web

Introduction . . . . .	415
Tested Environment . . . . .	415
On Windows. . . . .	416
From Internet Explorer . . . . .	416
From Netscape or Mozilla . . . . .	416
Step-by-Step Process . . . . .	417

## Appendix J - Examples for Configuration Testing

Introduction . . . . .	419
Console Access Server . . . . .	419
Terminal Server. . . . .	422
Dial-in Access . . . . .	424

# Table of Contents

---

## Appendix K - Wiz Application Parameters

Basic Parameters (wiz) . . . . .	427
Access Method Parameters (wiz --ac <type>) . . . . .	427
Alarm Parameter (wiz --al) . . . . .	428
Authentication Parameters (wiz --auth) . . . . .	428
Data Buffering Parameters (wiz --db) . . . . .	429
Power Management Parameters (wiz --pm) . . . . .	429
Serial Settings Parameters (wiz --sset <type>) . . . . .	430
Sniffing Parameters (wiz --snf) . . . . .	431
Syslog Parameters (wiz --sl) . . . . .	431
Terminal Appearance Parameters (wiz --tl) . . . . .	431
Terminal Server Profile Other Parameters (wiz --tso) . . . . .	432

## Appendix L - Copyrights

References . . . . .	433
----------------------	-----

List of Figures . . . . .	437
---------------------------	-----

List of Tables. . . . .	441
-------------------------	-----

Glossary. . . . .	443
-------------------	-----

Index . . . . .	447
-----------------	-----

# Table of Contents

---

---

This page has been left intentionally blank.

# Preface

---

---

## Purpose

The purpose of this guide is to provide instruction for users to independently install, configure, and maintain the BLACK BOX ® Advanced Console Server. This manual should be read in the order written, with exceptions given in the text. *Whether or not you are a UNIX user, we strongly recommend that you follow the steps given in this manual.*

## Audience and User Levels

This guide is intended for the user who is responsible for the deployment and day-to-day operation and maintenance of the BLACK BOX ® Advanced Console Server. It assumes that the reader understands networking basics and is familiar with the terms and concepts used in Local and Wide Area Networking. UNIX and Linux users will find the configuration process very familiar. It is not necessary to be a UNIX expert, however, to get the BLACK BOX ® Advanced Console Server up and running. There are two audiences or user levels for this manual:

### New Users

These are users new to Linux and/or UNIX with a primarily PC/Microsoft background. You might want to brush up on such things as common Linux/UNIX commands and how to use the vi editor prior to attempting installation and configuration. This essential background information appears in [Appendix A - New User Background Information](#). It is recommended that New Users configure the BLACK BOX ® Advanced Console Server using a Web browser, however, New Users can also configure the BLACK BOX ® Advanced Console Server with vi, the Wizard or the Command Line Interface (CLI).

### Power Users

These are UNIX/Linux experts who will use this manual mostly for reference. Power Users can choose between configuring the BLACK BOX ® Advanced Console Server via Web browser, vi, Wizard, or CLI.

# Preface

---

---

Each configuration task will be separated into a section (a clickable link on the PDF file) for each user type. Users then can skip to the appropriate level that matches their expertise and comfort level.

## How to use this Guide

This guide is organized into the following sections:

- [Chapter 1 - Introduction and Overview](#) contains an explanation of the product and its default CAS setup. It also includes safety guidelines to be followed.
- [Chapter 2 - Installation, Configuration, and Usage](#) explains how the BLACK BOX ® Advanced Console Server should be connected and what each cable is used for. It describes the basic configuration process to get the BLACK BOX ® Advanced Console Server up and running for its most common uses.
- [Chapter 3 - Additional Features](#) is dedicated to users wanting to explore all available features of the BLACK BOX ® Advanced Console Server. It provides configuration instructions for syslog, data buffers, authentication, filters, DHCP, NTP, SNMP, clustering, and sniffing.
- [Appendix A - New User Background Information](#) contains information for those who are new to Linux/UNIX.
- [Appendix B - Cabling, Hardware, and Electrical Specifications](#) has detailed information and pinout diagrams for cables used with the BLACK BOX ® Advanced Console Server.
- [Appendix C - The pslave Configuration File](#) contains example files for the various configurations as well as the master file.
- [Appendix D - Linux-PAM](#) enables the local system administrator to choose how to authenticate users.
- [Appendix E - Software Upgrades and Troubleshooting](#) includes solutions and test procedures for typical problems.
- [Appendix F - Certificate for HTTP Security](#) provides configuration information that will enable you to obtain a Signed Digital Certificate.
- [Appendix G - IPSEC](#) provides encryption and authentication services at the IP (Internet Protocol) level of the network protocol stack.

# Preface

---

- [Appendix H- Web User Management](#) covers default and optional configuration, and the addition/deletion of users, groups, and access limits.
- [Appendix I- Connect to Serial Ports from Web](#) enables this process, based on how the serial port is configured.
- [Appendix J - Examples for Configuration Testing](#) provides examples for testing the Advanced Secure Console Port Server after configuration.
- [Appendix K - Wiz Application Parameters](#) contains all basic and custom wizard parameters.
- [Appendix L - Copyrights](#) lists details about applications that were incorporated into the product.
- The [Glossary](#) provides definitions for commonly-used terms in this manual.

## Conventions and Symbols

This section explains the significance of each of the various fonts, formatting, and icons that appear throughout this guide.

### Fonts

This guide uses a regular text font for most of the body text and `Courier` for data that you would input, such as a command line instruction, or data that you would receive back, such as an error message. An example of this would be:

```
telnet 200.200.200.1 7001
```

### Hypertext Links

References to another section of this manual are hypertext links that are [underlined](#) (and are also blue in the PDF version of the manual). When you click on them in the PDF version of the manual, you will be taken to that section.

# Preface

---

---

## Glossary Entries

Terms that can be found in the glossary are underlined and slightly larger than the rest of the text. These terms have a hypertext link to the glossary.

## Quick Steps

Step-by-step instructions for installing and configuring the BLACK BOX® Advanced Console Server are numbered with a summarized description of the step for quick reference. Underneath the quick step is a more detailed description. Steps are numbered 1, 2, 3, etc. Additionally, if there are sub-steps to a step, they are indicated as Step A, B, C, and are nested within the Step 1, 2, 3, etc. For example:

### Step 1: Modify files.

You will modify four Linux files to let the BLACK BOX® Advanced Console Server know about its local environment.

#### Step A: Modify `pslave.conf`.

Open the file `pslave.conf` and add the following lines . . .

## Parameter Syntax

This manual uses standard Linux command syntaxes and conventions for the parameters described within it.

### Brackets and Hyphens (dashes)

The brackets ([ ]) indicate that the parameter inside them is optional, meaning that the command will be accepted if the parameter is not defined. When the text inside the brackets starts with a dash (-) and/or indicates a list of characters, the parameter can be one of the letters listed within the brackets.

### Example:

```
iptables [-ADC] chain rule-specification [options]
```

### Ellipses

Ellipses (...) indicate that the latest parameter can be repeated as many times as needed. Usually this is used to describe a list of subjects.



# Preface

---

## Example:

```
ls [OPTION]... [FILE]...
```

## Pipes

The pipe (|) indicates that one of the words separated by this character should be used in the command.

## Example:

```
netstat {--statistics|-s} [--tcp|-t] [--udp|-u] [--raw|-w]
```

When a configuration parameter is defined, the Linux command syntax conventions will be also used, with a difference.

## Greater-than and Less-than signs

When the text is encapsulated with the “<>” characters, the meaning of the text will be considered, not the literal text. When the text is not encapsulated, the literal text will be considered.

## Spacing and Separators

The list of users in the following example must be separated by semicolons (;); the outlets should be separated by commas (,) to indicate a list or with dashes (-) to indicate range; there should not be any spaces between the values.

**sXX.pmusers:** The user access list. For example: jane:1,2;john:3,4. The format of this field is:

```
[<username>:<outlet list>][;<username>:<outlet list>...]
```

where <outlet list>'s format is:

```
[<outlet number>|<outlet start>-<outlet end>][,<outlet number>|<outlet start>-<outlet end>]...
```

# Preface

---

---

## Note Box Icons

Note boxes contain instructional or cautionary information that the reader especially needs to bear in mind. There are five levels of note box icons:



**Tip.** An informational tip or tool that explains and/or expedites the use of the BLACK BOX® Advanced Console Server.



**Important!** An important tip that should be read. Review all of these notes for critical information.



**Warning!** A very important type of tip or warning. Do not ignore this information.



**DANGER!** Indicates a direct danger which, if not avoided, may result in personal injury or damage to the system.



**Security Issue.** Indicates security-related information where it is relevant.

# Introduction and Overview

---

---

## The BLACK BOX<sup>®</sup> Advanced Console Server

The BLACK BOX<sup>®</sup> Advanced Console Server is line of Console Access Servers that allow both local and dial-in access for in-band and out-of-band network management. run an embedded version of the Linux operating system. Configuration of the is done by editing a few plain-text files, and then updating the versions of the files on the BLACK BOX<sup>®</sup> Advanced Console Server. The files can be edited using the vi editor provided or on another computer with the environment and text editor of your choice. The default “profile” of the BLACK BOX<sup>®</sup> Advanced Console Server is that of a Console Access Server.

You can access the BLACK BOX<sup>®</sup> Advanced Console Server via three methods:

- A console directly connected to the BLACK BOX<sup>®</sup> Advanced Console Server
- Telnet/ssh over a network
- A browser

And configure it with any of the following four options:


- vi
- Wizard
- Browser
- Command Line Interface (CLI) - only for certain configuration parameters

With the BLACK BOX<sup>®</sup> Advanced Console Server set up as a Console Access Server, you can access a server connected to the BLACK BOX<sup>®</sup> Advanced Console Server through the server’s serial console port from a workstation on the LAN or WAN. There is no authentication by default, but the system can be configured for authentication to be performed by a Radius server, a TacacsPlus server, or even by a local database. Either telnet or ssh (a secure shell session) can be used. See [Appendix A - New User Background Information](#) for more information about ssh. The instructions in [Chapter 2 - Installation, Configuration, and Usage](#) will set up a fully-functional, default CAS environment. More options can be added after the initial setup, as illustrated in [Chapter 3 - Additional Features](#).


# Introduction and Overview

## What's in the box

There are several models of the BLACK BOX® Advanced Console Server. Black Box will ship either Cable Package #1 or #2 with the product according to current availability.



*Figure 1: Cable Package #1*




*Figure 2: Cable Package #2*

The following figures show the main units and accessories included in package.


# Introduction and Overview



**Note:** Although some BLACK BOX® Advanced Console Server units in the figures are shown with a dual power supply (A/C or -48VDC), some models may have single power supply. The single power units will have just one power cable.




Back View of the 32-Port



**Figure 3: The BLACK BOX® Advanced Console Server 32-Port, its cables, connectors and other box contents**

# Introduction and Overview



**Figure 4: The BLACK BOX® Advanced Console Server 16-port, its cables, connectors and other box contents**

# Introduction and Overview

---

---

## Safety Instructions

Read all the following safety guidelines to protect yourself and your BLACK BOX ® Advanced Console Server.



**DANGER!** In order to avoid shorting out your BLACK BOX ® Advanced Console Server when disconnecting the network cable, first unplug the cable from the and then from the network jack. When reconnecting a network cable to the, first plug the cable into the network jack, and then into the.



**Important!** To help protect the BLACK BOX ® Advanced Console Server from electrical power fluctuations, use a surge suppressor, line conditioner, or uninterruptible power supply.



**Important!** Be sure that nothing rests on the cables of the BLACK BOX ® Advanced Console Server and that they are not located where they can be stepped on or tripped over.



**Important!** Do not spill food or liquids on the BLACK BOX ® Advanced Console Server. If it gets wet, contact Black Box.



**DANGER!** Do not push any objects through the openings of the BLACK BOX ® Advanced Console Server. Doing so can cause fire or electric shock by shorting out interior components.

# Introduction and Overview

---

---



**Important!** Keep your BLACK BOX® Advanced Console Server away from heat sources and do not block cooling vents.



**Important!** The BLACK BOX® Advanced Console Server product (DC version) is only intended to be installed in restricted access areas (Dedicated Equipment Rooms, Equipment Closets or the like) in accordance with Articles 110-18, 110-26 and 110-27 of the National Electrical Code, ANSI/NFPA 701, 1999 Edition.

Use 18 AWG or 0.75 mm<sup>2</sup> or above cable to connect the DC configured unit to the Centralized D.C. Power Systems.

Install the required double-pole, single-throw, DC rated UL Listed circuit breaker between the power source and the BLACK BOX® Advanced Console Server DC version. Minimum Breaker Rating: 2A. Required conductor size: 18 AWG.

## Working inside the BLACK BOX® Advanced Console Server

Do not attempt to service the BLACK BOX® Advanced Console Server yourself, except when following instructions from Black Box Technical Support personnel. In the latter case, first take the following precautions:

- Turn the BLACK BOX® Advanced Console Server off.
- Ground yourself by touching an unpainted metal surface on the back of the equipment before touching anything inside it.
- Ground yourself by touching an unpainted metal surface on the back of the equipment before touching anything inside it.



# Introduction and Overview

---

## Battery



**WARNING:** There is the danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.



**WARNUNG:** Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.



**Предупреждение.** Есть опасность взрыва, если батарея заменена неправильно. Замените батарею только тем же самым или эквивалентным типом, рекомендованным изготовителем. Избавьтесь от используемых батарей согласно инструкциям изготовителя.

# Introduction and Overview

---

---

## FCC Warning Statement

The BLACK BOX ® Advanced Console Server has been tested and found to comply with the limits for Class A digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Installation & Service Manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user is required to correct the problem at his or her own expense.

## Canadian DOC Notice

The BLACK BOX ® Advanced Console Server does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le BLACK BOX ® Advanced Console Server n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

## Aviso de Precaución S-Mark Argentina

Por favor de leer todos los avisos de precaución como medida preventiva para el operador y el BLACK BOX ® Advanced Console Server.



**¡Peligro!** No hacer funcionar el BLACK BOX ® Advanced Console Server con la tapa abierta.



**¡Peligro!** Para prevenir un corto circuito en el BLACK BOX ® Advanced Console Server al desconectarlo de la red, primero desconectar el cable del equipo y luego el cable que conecta a la red. Para conectar el equipo a la red, primero conectar el cable a la red y luego al equipo.

# Introduction and Overview

---



**¡Peligro!** Asegurarse que el equipo este conectado a tierra, para prevenir un shock eléctrico. El cable eléctrico del equipo viene con tres clavijas para conectar asegurar conexión a tierra. No use adaptadores o quite la clavija de tierra. Si se tiene que utilizar una extensión, utilice una que tenga tres cables con clavija para conexión a tierra.



**¡Importante!** Para proteger al BLACK BOX® Advanced Console Server de fluctuaciones en corriente eléctrica, utilice una fuente eléctrica de respaldo.



**¡Importante!** Asegurarse de que nada descansa sobre los cables del BLACK BOX® Advanced Console Server, y que los cables no obstruyan el paso.



**¡Importante!** Asegurarse de no dejar caer alimentos o bebidas en el BLACK BOX® Advanced Console Server. Si esto ocurre, avise a Black Box.



**¡Peligro!** No empuje ningún tipo de objeto en los compartimientos del BLACK BOX® Advanced Console Server. Hacer esto podría ocasionar un incendio o causar un corto circuito dentro del equipo.

# Introduction and Overview

---

---



**¡Importante!** Mantenga el BLACK BOX® Advanced Console Server fuera del alcance de calentadores, y asegúrese de no tapar la ventilación del equipo.



**¡Importante!** El BLACK BOX® Advanced Console Server con alimentación de corriente directa (CD) solo debe ser instalado en áreas con restricción y de acuerdo a los artículos 110-18, 110-26, y 110-27 del National Electrical Code, ANSI/NFPA 701, Edición 1999.

Para conectar la corriente directa (CD) al sistema, utilice cable de 0.75 mm (18 AWG).

Instalar el interruptor corriente directa (CD) aprobado por UL entre la fuente de alimentación y el BLACK BOX® Advanced Console Server. El límite mínimo del interruptor deberá ser 2 amperes, con conductor de 0.75 mm (18 AWG).

## Trabajar dentro del BLACK BOX® Advanced Console Server

No intente dar servicio al BLACK BOX® Advanced Console Server, solo que este bajo la dirección de Soporte Técnico de Black Box. Si este es el caso, tome las siguientes precauciones:

Apague el BLACK BOX® Advanced Console Server. Asegúrese que este tocando tierra antes de tocar cualquier otra cosa, que puede ser al tocar la parte trasera del equipo.

# Introduction and Overview

---

## Batería



**¡Peligro!** Una batería nueva puede explotar, si no esta instalada correctamente. Reemplace la batería cuando sea necesario solo con el mismo tipo recomendado por el fabricante de la batería. Deshacerse de la batería de acuerdo a las instrucciones del fabricante de la batería.

# Introduction and Overview

---

---

This page has been left intentionally blank.

# Chapter 2 - Installation, Configuration, Usage

---

---

## Introduction

This chapter will allow you to install and configure the BLACK BOX ® Advanced Console Server as the default CAS configuration. *Please read the entire chapter before beginning.* A basic installation and configuration should take a half hour at the most, either done manually or with the Wizard.

The BLACK BOX ® Advanced Console Server operating system is embedded Linux. If you are fairly new to Linux, you will want to brush up prior to proceeding with this chapter with the essential background information presented in [Appendix A - New User Background Information](#). *Even if you are a UNIX user and find the tools and files familiar, do not configure this product as you would a regular Linux server.*

The chapter is divided into the following sections:

- [System Requirements](#)
- [Default Configuration Parameters](#)
- [Pre-Install Checklist](#)
- [Task List](#)
- [The Wizard](#)
- [Quick Start](#)
- [The Installation and Configuration Process](#)

## System Requirements

Black Box recommends either of the following specifications for configuration of the BLACK BOX ® Advanced Console Server:

- A workstation with a console serial port, or
- A workstation with Ethernet and TCP/IP topology

# Chapter 2 - Installation, Configuration, Usage

---

---

The following table shows the different hardware required for various configuration methods:

Table 1: Hardware vs. Configuration Methods

Hardware	Configuration Method
Console, Console Cable (constructed from RJ-45 straight-through cable + adapter)	vi, Wizard, or CLI
Workstation, Hub, Ethernet Cables	vi, Wizard, CLI, or browser

If you will be using vi, the files that need to be changed are discussed in [Configuration using Telnet](#) in this chapter. If you will be using the Wizard, basic Wizard access can be found under [Configuration Wizard - Basic Wizard](#) in [Chapter 3 - Additional Features](#) and specifics of this method are discussed under the appropriate option title in the same chapter. If you choose the browser method, the [Quick Start](#) in this chapter shows the screen flow and input values needed for this configuration mode. If you choose the CLI (Command Line Interface) method, this allows you to configure certain parameters for a specified serial port or some network-related parameters. Specifics of this method are discussed under the appropriate option title in [Chapter 3 - Additional Features](#).

## Default Configuration Parameters

- DHCP enabled (if there is no DHCP Server, IP for Ethernet is 192.168.160.10 with a Net-mask of 255.255.255.0)
- CAS configuration
- socket\_server in all ports (access method is telnet)
- 9600 bps, 8N1
- No Authentication



# Chapter 2 - Installation, Configuration, Usage

---

---

## Pre-Install Checklist

There are several things you will need to confirm prior to installing and configuring the BLACK BOX ® Advanced Console Server:

*Root Access*

You will need Root Access on your local UNIX machine in order to use the serial port.

*HyperTerminal,  
Kermit, or Minicom*

If you are using a PC, you will need to ensure that HyperTerminal is set up on your Windows operating system. If you have a UNIX operating system, you will be using Kermit or Minicom.

*IP Address of:  
PC or terminal,  
BLACK BOX ®  
Advanced Console  
Server, NameServer,  
and Gateway*

You will need to locate the IP address of your PC or workstation, the BLACK BOX ® Advanced Console Server, and the machine that resolves names on your network. Your Network Administrator can supply you with these. If there is outside access to the LAN that the BLACK BOX ® Advanced Console Server will be connected with, you will need the gateway IP address as well.

*Network Access*

You will need to have a NIC card installed in your PC to provide an Ethernet port, and have network access.

# Chapter 2 - Installation, Configuration, Usage

---

---

## Task List

There are eight key tasks that you will need to perform to install and configure the BLACK BOX ® Advanced Console Server:

[Task 1: Connect the BLACK BOX ® Advanced Console Server to the Network and other Devices.](#)

[Task 2: Configure the COM Port Connection and Log In.](#)

[Task 3: Modify the System Files.](#)

[Task 4: Edit the pslave.conf file.](#)

[Task 5: Activate the changes.](#)

[Task 6: Test the configuration.](#)

[Task 7: Save the changes.](#)

[Task 8: Reboot the BLACK BOX ® Advanced Console Server](#)

## The Wizard

The eight key tasks can also be done through a wizard in the 2.1 plus versions of the BLACK BOX ® Advanced Console Server.

### Basic Wizard

The Basic Wizard will configure the following parameters:

- Hostname
- DHCP enabled/disabled
- System IP (if DHCP is disabled)
- Netmask (if DHCP is disabled)
- Default Gateway
- DNS Server

# Chapter 2 - Installation, Configuration, Usage

---

- [Domain](#)

Basic Wizard access is covered in the Quick Start in this chapter and also in [Configuration Wizard - Basic Wizard](#) in [Chapter 3 - Additional Features](#).

## Custom Wizard

Further configuration of the BLACK BOX ® Advanced Console Server can be done through one of several customized wizards. These procedures are explained under their respective topic heading in [Chapter 3 - Additional Features](#). There are custom wizards for the following optional configurations:

- [Access Method](#)
- [Generating Alarms](#)
- [Authentication](#)
- [Data Buffering](#)
- [Help](#)
- [Serial Settings](#)
- [Session Sniffing](#)
- [Syslog](#)
- [Terminal Appearance](#)

# Chapter 2 - Installation, Configuration, Usage

---

---

## Quick Start

This Quick Start gives you all the necessary information to quickly configure and start using the BLACK BOX® Advanced Console Server as a Console Access Server (CAS). The complete version of this process is listed later in this chapter under [The Installation and Configuration Process](#). New Users may wish to follow the latter instruction set, as this Quick Start does not contain a lot of assumed knowledge. You can configure the BLACK BOX® Advanced Console Server by any one of four methods:

- Console
- Browser
- Telnet
- CLI (Command Line Interface)

If you have a serial port that you can use as a console port, use the Console method. If you have access to telnet, you can use this method, while [New Users](#) may prefer the Browser method for its user-friendliness.



**Important!** Take care when changing the IP address of the BLACK BOX® Advanced Console Server. Confirm the address you are changing it to. (You may want to write it down.)

### Configuration using a Console

**Step 1: Connect the console cable.**

Connect the console cable (created from the RJ-45 straight-through cable and the appropriate console adapter) to the port labeled “Console” on the BLACK BOX® Advanced Console Server with the RJ-45 connector end, and to your PC’s available COM port with the serial port end.

# Chapter 2 - Installation, Configuration, Usage

---

**Step 2:** Power on the BLACK BOX ® Advanced Console Server.

After the BLACK BOX ® Advanced Console Server finishes booting, you will see a login prompt on the console screen.

**Step 3:** Enter *root* as login name and *tslinux* as password.

**Step 4:** Type *wiz* and press Enter.

A configuration wizard screen will appear in your Hyperterminal session, asking you a series of questions.

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

You will want to configure the following settings:

- Hostname
- DHCP enabled/disabled
- System IP (if DHCP is disabled)
- Domain Name
- Primary DNS Server

# Chapter 2 - Installation, Configuration, Usage

---

- Gateway IP
- Network Mask (if DHCP is disabled)

After you input the requested parameters you will receive a confirmation screen:

Current configuration:

Hostname : CAS

DHCP : enabled

Domain name : mycompany.com

Primary DNS Server : 197.168.160.200

Gateway IP : 192.168.160.1

If the parameters are correct, “y” should be typed; otherwise, type “n” and then “c” when asked to change the parameters or quit the program. After the parameters are confirmed, the next question will be whether to save the configuration to flash. Select “y” to make the new configuration permanent in non-volatile memory.

After you confirm and save the basic parameters, you will be presented with the shell prompt. From there, either select to continue configuration using the vi editor or use the browser or CLI method (if appropriate).

The BLACK BOX® Advanced Console Server is now configured as a CAS with its new IP address, with no authentication, and accepting telnet to the serial ports. You can telnet the CAS IP + serial port 1 with the following command:

```
telnet <IP assigned by DHCP Server or by you> 7001
```



Note. Serial port 1 is configured as 9600, 8N1 by default. The server connected to this serial port has to have the same configuration for its serial port.

To explore the BLACK BOX® Advanced Console Server features, either continue configuration using the vi editor from the console or use a browser from a workstation and point to the BLACK BOX® Advanced Console Server.

# Chapter 2 - Installation, Configuration, Usage

---

## Configuration using a Web browser

The BLACK BOX ® Advanced Console Server comes with DHCP client enabled. If you have a DHCP Server installed on your LAN, you can skip Step 2 below. If not, the DHCP request will fail and an IP address pre-configured on the Console server's Ethernet interface (192.168.160.10) will be used instead. To access the using your browser:

**Step 1: Connect Hub to workstation and BLACK BOX ® Advanced Console Server.**

Your workstation and your BLACK BOX ® Advanced Console Server must be on the same physical LAN. Connect one RJ-45 cable from the Ethernet port of the BLACK BOX ® Advanced Console Server to a spare port from a hub, and another cable from another spare port of that same hub to the workstation used to manage the servers.

**Step 2: If you do not have a DHCP Server in your LAN, add a route pointing to the BLACK BOX ® Advanced Console Server IP.**

From the workstation, issue a command to add a route pointing to the network IP address of the BLACK BOX ® Advanced Console Server (192.168.160.0) accessed through the workstation's Ethernet interface.

For Linux, the command would be:

```
route add -net 192.168.160.0/24 gw <IP address assigned to the workstation's Ethernet interface>
```

**Example: if the workstation has IP address 200.246.93.150 the command would be:**

```
route add -net 192.168.160.0/24 gw 200.246.93.150
```

For Windows, the command would be:

```
route add 192.168.160.0 mask 255.255.255.0 <IP address assigned to the workstation's Ethernet interface>
```

**Example: if the workstation has IP address 200.246.93.150 the command would be:**

```
route add 192.168.160.0 mask 255.255.255.0 200.246.93.150
```

**Step 3: Point your browser to the IP address assigned by the DHCP Server (or to 192.168.160.10 if there is no DHCP Server in your LAN).**

The login page shown in the following figure will appear.

# Chapter 2 - Installation, Configuration, Usage



Figure 5: Login page of the Web Configuration Manager

Step 4: Enter *root* as login name and *tslinux* as password.

Step 5: Click the Submit button.

This will take you to the Configuration & Administration Menu page, shown in the following figure:




Figure 6: Configuration & Administration Menu page



# Chapter 2 - Installation, Configuration, Usage

This page gives a brief description of all menu options. A menu of links is provided along the left side of the page. A summary of what each link leads to is shown on [Table 3: Configuration Section](#) through [Table 6: Information Section](#).



**Security Issue.** Change the password of the Web root user as soon as possible. The user database for the Web Configuration Manager is different than the system user database, so the root password can be different. See [Changing the Root Password](#) in [Appendix H- Web User Management](#).

Step 6: Click on the General link.

**BLACK BOX**  
NETWORK SERVICES

Description	
Hostname:	Black Box LES2800A
Console Banner:	Black Box LES2800A
Ethernet port	
Primary IP Address:	200.246.93.88
Network Mask:	255.255.255.0
Secondary IP Address:	
Network Mask:	
Common Configuration File Name:	
DHCP Client:	<input checked="" type="radio"/> inactive <input type="radio"/> active <input type="radio"/> act & restores last assigned
MTU:	1500
DNS Service	
Primary DNS Server:	200.246.93.1
Secondary DNS Server:	

Figure 7: General page

Step 7: Configure parameters presented in the fields.

Step 8: Click on the Submit button.

Step 9: Make the changes effective.

# Chapter 2 - Installation, Configuration, Usage

---

---

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button. If you disabled DHCP and changed your Ethernet IP, you will lose your connection. You will need to use your browser to connect to the new IP.

Step 10: Click on the Save Configuration to Flash button.

The configuration was saved in flash. The new configuration will be valid and running. The BLACK BOX ® Advanced Console Server is now configured as a CAS with its assigned (by DHCP Server or you) IP address, with no authentication, and accepting telnet to the serial ports. You can telnet the CAS IP + serial port 1 with the following command:

```
telnet <IP assigned> 7001
```



Note. Serial port 1 is configured as 9600, 8N1 by default. The server connected to this serial port has to have the same configuration for its serial port.

To explore the BLACK BOX ® Advanced Console Server features, either continue configuration using browser, use the vi editor from the console, or use CLI, if appropriate.

A description of each of the links on the five sections of the Configuration and Administration menu page is provided on the following five tables:

Table 2: Applications Section

Link Name	Description of Page Contents
<i>Logout</i>	Exits the Web Management Service
<i>Connect to Serial Ports</i>	Telnet/SSH connection to Portslave

# Chapter 2 - Installation, Configuration, Usage

---

---

Table 3: Configuration Section

Link Name	Description of Page Contents
<i>Configuration</i>	This section contains the configuration tools
<i>General</i>	Unit Description, Ethernet, DNS, Name Service Access, Data Buffering
<i>Syslog</i>	Configuration for the syslog-ng
<i>SNMP</i>	Configuration for the SNMP server
<i>Serial Ports</i>	Configuration of Portslave package
<i>Serial Port Groups</i>	Configuration of User Groups for Serial Ports
<i>Host Table</i>	Table of hosts in /etc/hosts
<i>Static Routes</i>	Static routes defined in /etc/network/st_routes
<i>IPsec</i>	IPsec connections configuration
<i>IP Tables</i>	Static IPTables Filter in /etc/network/firewall
<i>Boot Configuration</i>	Configuration of parameters used in the boot process
<i>Edit Text File</i>	Tool to edit a configuration file
<i>System Users</i>	Management of system users defined in /etc/password
<i>System Groups</i>	Management of system groups defined in /etc/groups

# Chapter 2 - Installation, Configuration, Usage

---

---

Table 4: Administration Section

Link Name	Description of Page Contents
<i>Reboot</i>	Resets the equipment
<i>Download/ Upload Image</i>	Uses an FTP server to load/save a kernel image
<i>Load/Save Configuration</i>	Uses flash memory or an FTP server to load or save the BLACK BOX ® Advanced Console Server's configuration
<i>Run Configuration</i>	Makes the configuration changes effective
<i>Set Date/Time</i>	Set the BLACK BOX ® Advanced Console Server 's date and time
<i>Active Sessions</i>	Shows the active sessions
<i>CAS Sessions</i>	Shows the CAS sessions
<i>Process Status</i>	Shows the running processes and allows the administrator to kill them
<i>Restart Processes</i>	Allows the administrator to start or stop some specific processes
<i>PCMCIA</i>	Allows the administrator to insert and eject PCMCIA cards

Table 5: Web User Management Section

Link Name	Description of Page Contents
<i>Users</i>	List of users allowed to access the Web server
<i>Groups</i>	List of possible access groups
<i>Access Limits</i>	List of access limits for specific URLs
<i>Load/Save Configuration</i>	Load/Save Configuration in /etc/websum.conf

# Chapter 2 - Installation, Configuration, Usage

---

Table 6: Information Section

Link Name	Description of Page Contents
<i>Interface Statistics</i>	Shows statistics for all active interfaces
<i>DHCP client</i>	Shows host information from DHCP
<i>Serial Ports</i>	Shows the status of all serial ports
<i>Routing Table</i>	Shows the routing table and allows the administrator to add or delete routes
<i>ARP Cache</i>	Shows the ARP cache
<i>IP Statistics</i>	Shows IP protocol statistics
<i>ICMP Statistics</i>	Shows ICMP protocol statistics
<i>TCP Statistics</i>	Shows TCP protocol statistics
<i>UDP Statistics</i>	Shows UDP protocol statistics
<i>RAM Disk Usage</i>	Shows the BLACK BOX ® Advanced Console Server File System status
<i>System Information</i>	Shows information about the kernel, time, CPU, and memory



Note: The link [Connect to Serial Ports](#) is only available for all BLACK BOX ® Advanced Console Server models. See [“Appendix I - Connect to Serial Ports from Web”](#) on page 415.

# Chapter 2 - Installation, Configuration, Usage

---

---

## Configuration using Telnet

The BLACK BOX ® Advanced Console Server comes with DHCP client enabled. If you have a DHCP Server installed on your LAN, you can skip Step 2 below. If not, the DHCP request will fail and an IP address pre-configured on the Console server's Ethernet interface (192.168.160.10) will be used instead. To access the using telnet:

**Step 1: Connect Hub to workstation and BLACK BOX ® Advanced Console Server.**

Your workstation and your BLACK BOX ® Advanced Console Server must be on the same physical LAN. Connect one RJ-45 cable from the Ethernet port of the BLACK BOX ® Advanced Console Server to a spare port from a hub, and another cable from another spare port of that same hub to the workstation used to manage the servers.

**Step 2: If you do not have a DHCP Server in your LAN, add a route pointing to the BLACK BOX ® Advanced Console Server IP.**

From the workstation issue a command to add a route pointing to the network IP address of the BLACK BOX ® Advanced Console Server (192.168.160.0) accessed through the workstation's Ethernet interface.

For Linux, the command would be:

```
route add -net 192.168.160.0/24 gw <IP address assigned to  
the workstation's Ethernet interface>
```

**Example: if the workstation has IP address 200.246.93.150 the command would be:**

```
route add -net 192.168.160.0/24 gw 200.246.93.150
```

For Windows, the command would be:

```
route add 192.168.160.0 mask 255.255.255.0 <IP address  
assigned to the workstation's Ethernet interface>
```

**Example: if the workstation has IP address 200.246.93.150 the command would be:**

```
route add 192.168.160.0 mask 255.255.255.0 200.246.93.150
```

**Step 3: Telnet to <IP assigned by DHCP Server or 192.168.160.10 if there is no DHCP Server>.**

# Chapter 2 - Installation, Configuration, Usage

---

Step 4: Enter *root* as login name and *tslinux* as password.

Step 5: Type *wiz* and press Enter.

A Configuration Wizard screen will appear on your telnet screen, asking you a series of questions.

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

**After you input the requested parameters you will receive a confirmation screen:**

Current configuration:

Hostname : CAS

DHCP: disabled

System IP : 192.168.160.10

Domain name : mycompany.com

Primary DNS Server : 197.168.160.200

# Chapter 2 - Installation, Configuration, Usage

---


Gateway : eth0

Network Mask : 255.255.255.0

If the parameters are correct, “y” should be typed; otherwise, type “n” and then “c” when asked to change the parameters or quit the program. After the parameters are confirmed, the next question will be whether to save the configuration to flash. Select “y” to make the new configuration permanent in non-volatile memory.

At this point you may lose your connection when saving the changes, if you disabled DHCP and assigned an IP address. *Don't worry!* The new configuration will be valid. The BLACK BOX® Advanced Console Server is now configured as a CAS with its assigned (by DHCP or you) IP address, with no authentication, and accepting telnet to the serial ports. You can telnet the CAS IP + serial port 1 with the following command:

```
telnet <IP assigned> 7001
```



Note. Serial port 1 is configured as 9600, 8N1 by default. The server connected to this serial port has to have the same configuration for its serial port.

After you confirm the basic parameters, you will be presented with the shell prompt. From there, either select to continue configuration using the vi editor or continue using a browser. For additional configuration, see [Chapter 3 - Additional Features](#) in this guide.



# Chapter 2 - Installation, Configuration, Usage

## The Installation and Configuration Process

### Task 1: Connect the BLACK BOX ® Advanced Console Server to the Network and other Devices

#### Power Users

Connect a PC or terminal to the BLACK BOX ® Advanced Console Server using the console cable. If you are using a PC, HyperTerminal can be used in the Windows operating system and Kermit or Minicom in the UNIX operating system. When the BLACK BOX ® Advanced Console Server boots properly, a login banner will appear. Log in as *root* (default password is *linux*). A new password should be created as soon as possible. The terminal parameters should be set as follows:

- Serial Speed: 9600 bps
- Data Length: 8 bits
- Parity: None
- Stop Bits: 1 stop bit
- Flow Control: none
- ANSI emulation

You may now skip to [Task 4: Edit the pslave.conf file](#).



**Important!** Any configuration change must be saved in flash once validated. To save in **Flash** run `saveconf` (see [Task 7: Save the changes](#)). To validate/activate a configuration, run `signal_ras hup` (see [Task 5: Activate the changes](#)).



**Note:** If your terminal does not have ANSI emulation, select `vt100`; then, on the BLACK BOX ® Advanced Console Server, log in as `root` and switch to `vt100` by typing:

```
TERM=vt100;export TERM
```

# Chapter 2 - Installation, Configuration, Usage

---

---



Tip. We strongly recommend to use 9600 bps console speed. In case you need to use another speed please check [Appendix E - Software Upgrades and Troubleshooting](#).



Important! Always complete ALL the steps for your chosen configuration before testing or switching to another configuration.

## New Users

If you are using a PC, you will be using HyperTerminal to perform the initial configuration of the BLACK BOX ® Advanced Console Server directly through your PC's COM port connected with the BLACK BOX ® Advanced Console Server console port. HyperTerminal, which comes with Windows 95, 98, Me, NT, 2K, and XP is often located under Start > Program > Accessories. HyperTerminal emulates a dumb terminal when your PC connects to the serial port (console port) of the BLACK BOX ® Advanced Console Server.

After the initial configuration through the HyperTerminal connection, you will be connecting your PC (or another terminal) to the BLACK BOX ® Advanced Console Server via an Ethernet connection in order to manage the BLACK BOX ® Advanced Console Server. The workstation used to access the BLACK BOX ® Advanced Console Server through telnet or ssh uses a LAN connection.

These events can be summarized as follows:

- PC (Hyper terminal): COM port connects via serial cable to the BLACK BOX ® Advanced Console Server's console port.
- PC (Ethernet): Ethernet port connects via hub to the BLACK BOX ® Advanced Console Server's Ethernet port.
- Use the HyperTerminal to configure the box.
- Use the PC Ethernet to access the box as client (telnet/ssh).

# Chapter 2 - Installation, Configuration, Usage

---

**Step 1: Plug the power cable into the BLACK BOX ® Advanced Console Server.**

Insert the female end of the black power cable into the power socket on the BLACK BOX ® Advanced Console Server and the three-prong end into a wall outlet.



**DANGER!** To help prevent electric shock, plug the BLACK BOX ® Advanced Console Server into a properly grounded power source. The cable is equipped with a 3-prong plug to help ensure proper grounding. Do not use adapter plugs or remove the grounding prong from the cable. If you use an extension cable, use a 3-wire cable with properly grounded plugs.

**Step 2: Connect the console cable.**

You will be constructing a Console Cable out of the RJ-45 straight-through cable and the appropriate adapter provided in the product box. (There are four options: all adapters have an RJ-45 connector on one end, and either a DB25 or DB9 connector on the other end, male or female). Connect this cable to the port labeled “Console” on the BLACK BOX ® Advanced Console Server with the RJ-45 connector end, and connect the adapter end to your PC’s available COM port. For more detailed information on cables, see [Appendix B - Cabling, Hardware, and Electrical Specifications](#).



**Note:** The modem cable is not necessary for a standard installation and configuration. Use it when the configuration is complete and you want to access the box remotely through a serial port.

**Step 3: Connect Hub to PC and the BLACK BOX ® Advanced Console Server.**

Your workstation and BLACK BOX ® Advanced Console Server must be on the same physical LAN. Connect one RJ-45 cable from the Ethernet port of the BLACK BOX ® Advanced Console Server to the hub, and another from the hub to the workstation used to manage the servers.

**Step 4: Install and launch HyperTerminal, Kermit or Minicom if not already installed.**

You can obtain the latest update to HyperTerminal from:

<http://www.hilgraeve.com/hpe/download.html>


# Chapter 2 - Installation, Configuration, Usage

---

## Task 2: Configure the COM Port Connection and Log In

### Step 1: Select available COM port.

In HyperTerminal (Start > Program > Accessories), select File > Properties, and click the Connect To tab. Select the available COM port number from the Connection dropdown.




*Figure 8: Choose a free COM port*

### Step 2: Configure COM port.

Click the Configure button (hidden by the dropdown menu in the above figure). Your PC, considered here to be a “dumb terminal,” should be configured to use 9600 bps, 8 data bits, no parity, 1 stop bit, and no flow control (as shown in the following figure).

# Chapter 2 - Installation, Configuration, Usage

---



*Figure 9: Port Settings*

**Step 3:** Power on the BLACK BOX ® Advanced Console Server.

**Step 4:** Click OK on the Properties window.

You will see the BLACK BOX ® Advanced Console Server booting on your screen. After it finishes booting, you will see a login prompt.

# Chapter 2 - Installation, Configuration, Usage

---

## Task 3: Modify the System Files

When the BLACK BOX ® Advanced Console Server finishes booting, a prompt will appear (a flashing underline cursor) in your HyperTerminal window. You will modify the following Linux files to let the BLACK BOX ® Advanced Console Server know about its local environment:

`/etc/hostname`

`/etc/hosts`

`/etc/resolv.conf`

`/etc/network/st_routes`

The Linux files must be modified to identify the BLACK BOX ® Advanced Console Server and other devices it will be communicating with. The operating system provides the vi editor, which is described in [Appendix A - New User Background Information](#) for the uninitiated. The BLACK BOX ® Advanced Console Server runs Linux, a UNIX-like operating system, and those not familiar with it will want to refer to Appendix A.

**Step 1:** Type *root* and press Enter.

**Step 2:** At the password prompt, type *tslinux*.


Press Enter.

**Step 3:** Modify `/etc/hostname`.

In HyperTerminal, type `vi /etc/hostname` (without the quotes) and press Enter. Arrow over the existing text in the file, type `r` (for replace) and type the first number of the model of your BLACK BOX ® Advanced Console Server. (Or, you can replace the default naming convention with anything you'd like for your hostname.) When finished, press the Esc key, (to return to command mode), then type `:` (colon), and then `wq` and press Enter. This will save the file. (The only entry in this file should be the hostname of the BLACK BOX ® Advanced Console Server.) An example is shown in the following figure. (The HyperTerminal screen is shown in this first example for clarity, however, for the other Linux files we will modify, only the command line text will be shown.)

# Chapter 2 - Installation, Configuration, Usage

---



*Figure 10: The /etc/hostname file with hostname typed in*

## Step 4: Modify /etc/hosts.

This file should contain the IP address for the Ethernet interface and the same hostname that you entered in the /etc/hostname file. It may also contain IP addresses and host names for other hosts in the network. Modify the file using the vi as you did in Step 1.

<i>Obtain IP address from your System Administrator</i> →	127.0.0.1	localhost	↖ <i>Replace to match hostname from previous step</i>
	192.168.160.10	LS1016A	
	129.6.15.28	ntphost	

*Figure 11: Contents of the /etc/hosts file*

## Step 5: Modify /etc/resolv.conf.

This file must contain the domain name and nameserver information for the network. Obtain the nameserver IP address from your Network Administrator. The default contents of this file are:

```
domain      mycompany.com
nameserver  200.200.200.2
```

# Chapter 2 - Installation, Configuration, Usage

---

---

## Step 6: Modify `/etc/network/st_routes`.

The fourth file defines static routes. In the console server example in the router is a gateway router and thus its IP address is configured in this file to be the default gateway. Other static routes are also configured in this file. If you will be managing servers through a LAN, you don't need to alter this file. If you will be managing via Internet, you will be connecting through a router, and thus need to modify this file. You would get the IP address from your Network Administrator. The default contents of this file are:

```
route add default dev eth0
```

## Step 7: Change password for root and new users.

The default `/etc/passwd` file has the user "root" with password "tlinux". You should change the password for user *root* as soon as possible. Before changing any password or adding new users you should also activate *shadow password*, if it is needed. The BLACK BOX® Advanced Console Server has support for shadow password, but it is not active by default. To activate shadow password follow the steps listed below:

### Step A: Create an empty file called `/etc/shadow`.

```
# cd /etc
# touch shadow
```

### Step B: Add a temporary user to the system. It will be removed later.

```
# adduser boo
```

### Step C: Edit the file *shadow*.

For each user in `passwd` file, create a copy of the line that begins with "boo:" in the `shadow` file, then replace "boo" with the user name. The line beginning with "root" must be the first line in the file `/etc/shadow`.

### Step D: Edit the *passwd* file.

Replace the password in all password fields with an "x". The root's line will look like this:

```
"root:x:0:0:root:/root:/bin/sh"
  ^
  ^ password field
```



# Chapter 2 - Installation, Configuration, Usage

---



Tip. Using the vi editor, put the cursor in the first byte after “root:”, then type “ct:x” plus <ESC>.

Step E: Remove the temporary user boo.

```
# deluser boo
```

Step F: Change the password for all users and add the new ones needed.

```
# passwd <username>  
or  
# adduser <username>
```

Step G: Edit /etc/config\_files and add a line with “/etc/shadow.”

## Task 4: Edit the pslave.conf file

This is the main configuration file (/etc/portslave/pslave.conf) that contains most product parameters and defines the functionality of the BLACK BOX ® Advanced Console Server. Only three parameters need to be modified or confirmed for a basic configuration:

- conf.eth\_ip (if you disabled DHCP)
- all.authtype
- all.protocol



Tip. You can do a find for each of these parameters in vi, once you open this file by typing / <your string> to search the file downward for the string specified after the /.

A listing of the pslave.conf file with all possible parameters, as well as the files used to create other configurations from parameters in this file, is provided in [Appendix C - The pslave Configuration File](#). Additional, optional modifications made to this file will depend on the configuration desired.

# Chapter 2 - Installation, Configuration, Usage

---

---

There are three basic types of parameters in this file:

- *conf.\** parameters are global or apply to the Ethernet interface.
- *all.\** parameters are used to set default parameters for all ports.
- *s#.\** parameters change the default port parameters for individual ports.

An *all.\** parameter can be overridden by a *s#.\** parameter appearing later in the *pslave.conf* file (or vice-versa).



**Power Users:** To find out what to input for these three parameters so that you can configure what you need, go the appropriate appendix, where you will find a complete table with an explanation for each parameter. You can use the templates from that same Appendix (*pslave.conf.cas*, etc.) as reference.

*conf.eth\_ip*      This is the IP address of the Ethernet interface. Use it if you don't have DHCP Server in your LAN. An example value would be:

200.200.200.1

# Chapter 2 - Installation, Configuration, Usage

---

*all.authtype* This parameter controls the authentication required by the BLACK BOX<sup>®</sup> Advanced Console Server. The authentication required by the device to which the user is connecting is controlled separately. There are several authentication type options:

- *none* (no authentication)
- *local* (authentication is performed using the `/etc/passwd` file)
- *remote* (This is for a terminal profile only. The unit takes in a username but does not use it for authentication. Instead it passes it to the remote server where it is then used for authentication.)
- *radius* (authentication is performed using a Radius authentication server)
- *TacacsPlus* (authentication is performed using a TacacsPlus authentication server)
- *ldap* (authentication is performed against an ldap database using an ldap server. The IP address and other details of the ldap server are defined in the file `/etc/ldap.conf`)
- *local/radius* (authentication is performed locally first, switching to Radius if unsuccessful)
- *radius/local* (the opposite of the previous option)
- *local/TacacsPlus* (authentication is performed locally first, switching to TacacsPlus if unsuccessful)
- *TacacsPlus/local* (the opposite of the previous option)
- *RadiusDownLocal* (local authentication is tried only when the Radius server is down)
- *TacacsPlusDownLocal* (local authentication is tried only when the TacacsPlus server is down)

An example value would be:

```
radius
```

# Chapter 2 - Installation, Configuration, Usage

---

- all.protocol* For the console server configuration, the possible protocols are:
- *socket\_server* (when telnet is used)
  - *socket\_ssh* (when ssh version one or two is used)
  - *raw\_data* (to exchange data in transparent mode – similar to *socket\_server* mode, but without telnet negotiation, breaks to serial ports, etc.)

An example value would be:

```
socket_server
```

The Authentication feature

See [Authentication](#) in [Chapter 3 - Additional Features](#).

## Task 5: Activate the changes

Execute the following command in HyperTerminal to activate the changes:

```
signal_ras hup
```

## Task 6: Test the configuration

Now you will want to make sure that the ports have been set up properly.

**Step 1: Ping the BLACK BOX ® Advanced Console Server from a DOS prompt.**

Open a DOS window, type in the following, and then press Enter:

```
ping <IP assigned to the BLACK BOX ® Advanced Console Server  
by DHCP or you>
```

An example would be:

```
ping 192.168.160.10
```

If you receive a reply, your BLACK BOX ® Advanced Console Server connection is OK. If there is no reply see [Appendix E - Software Upgrades and Troubleshooting](#).

**Step 2: Telnet to the server connected to the first port of the BLACK BOX ® Advanced Console Server.**

*(This will only work if you selected *socket\_server* as your *all.protocol* parameter.)*

# Chapter 2 - Installation, Configuration, Usage

---

While still in the DOS window, type the following and then press Enter:

```
telnet <IP assigned to the BLACK BOX ® Advanced Console  
Server by DHCP or you> 7001
```

An example would be:

```
telnet 192.168.160.10 7001
```

If everything is configured correctly, a telnet session should open on the server connected to port 1. If not, check the configuration, follow the above steps again, and check [Appendix E - Software Upgrades and Troubleshooting](#).

## Task 7: Save the changes

Execute the following command in HyperTerminal to save the configuration:

```
saveconf
```

## Task 8: Reboot the BLACK BOX ® Advanced Console Server

After rebooting, the initial configuration is complete.



**Note:** restoreconf does the opposite of saveconf, copying the contents of the /proc/flash/script file to the corresponding files in the ramdisk. The files on the ramdisk are overwritten. Restoreconf is run automatically each time the BLACK BOX ® Advanced Console Server is booted.

# Chapter 2 - Installation, Configuration, Usage

---

---

## Accessing the Serial Ports

There are four ways to access the serial ports, depending on the protocol you configured for that serial port (all.protocol being `socket_server` for telnet access, `socket_ssh` for ssh access, etc). One can access the serial port by statically addressing it (using TCP port number, alias name or IP address) or just access the next free serial port available from an existent pool (by using the pool's TCP port number, alias or IP address). For details on configuration to access using telnet or ssh please see [Access Method](#), Configuration for CAS in Chapter 3.

### Opening and closing a telnet session to a serial port

To open a telnet session to a serial port or the first free serial port belonging to a pool of serial ports, issue the command:

```
telnet <CAS hostname> <TCP port number>
```

<CAS hostname> is the hostname configured in the workstation where the telnet client will run (through `/etc/hosts` or DNS table). It can also be just the IP address of the BLACK BOX® Advanced Console Server (Ethernet's interface) configured by the user or learned from DHCP.

<TCP port number> is the number associated to the serial port or pool of serial ports. From factory, 7001 corresponds to serial port 1, 7002 to serial port 2 and so forth, and 3000 is a pool with all serial ports.

To close the telnet session, just press the telnet hot key configured in telnet client application (usually it's "Ctrl J") and "q" to quit.

### Opening and closing an SSH session to a serial port

To open a ssh session to a serial port or the next free serial port from a pool, issue the command:

```
ssh -l <Username>:<Server> <CAS hostname>
```

<Username> is the user configured to access that serial port. It is present either in the local

# Chapter 2 - Installation, Configuration, Usage

---

CAS database or in a Radius/Tacacs/LDAP/Kerberos, etc database.

<Server> can be just the TCP port number assigned for that serial port (7001, 7002, etc), pool of ports (3000, etc), the alias for the server connected to that serial port or the alias of a pool of ports.

<CAS hostname> is the hostname configured in the workstation where the ssh client will run (through /etc/hosts or DNS table). It can also be just the IP address of the BLACK BOX® Advanced Console Server (Ethernet's interface) configured by the user or learned from DHCP.

To exit the ssh session, press the hot key configured for that ssh client (usually "~.").  
Secure Console Port Server

## Accessing Serial Ports using "ts\_menu"

To access the serial port (telnet or ssh) using *ts\_menu*, login to the CAS unit and, after receiving the shell prompt, run *ts\_menu*. The servers (aliases) or serial ports will be shown as option to start a connection (telnet/ssh). After typing *ts\_menu*, you will see something similar to the following:

```
Serial Console Server Connection Menu for your Master Terminal
Server
```

```
1 ttyS1 2 ttyS2 3 ttyS3 4 ttyS4
5 ttyS5 6 ttyS6 7 ttyS7 8 ttyS8
```

```
Type 'q' to quit, a valid option[1-8], or anything else to refresh:
```

How to close the session from *ts\_menu* (from the console of your unit)

**Step 1: Enter the escape character.**

The escape character is shown when you first connect to the port.  
In character/text Mode, the Escape character is ^]

After entering the escape character, the following is shown:

```
Console escape. Commands are:
```

```
l go to line mode
c go to character mode
```

# Chapter 2 - Installation, Configuration, Usage

---

---

```
z suspend telnet
b send break
t toggle binary
e exit telnet
```

**Step 2: Press “e” to exit from the session and return to the original menu.**

**Select the exit option and you will return to the shell prompt.**

How to close the session from `ts_menu` (from a telnet session to your unit)

You have to be sure that a different escape character is used for exiting your telnet session; otherwise, if you were to exit from the session created through the `ts_menu`, you will close your entire telnet session to your unit. To do this, when you first telnet to your unit, use the “-e” option. So for example, to set `Ctrl-?` as the escape character, type:

```
telnet -e ^? 192.168.160.10
```

To exit from the session created through the `ts_menu`, just follow Step 1 from above. To exit from the entire telnet session to your unit, type the escape character you had set.

## Accessing Serial Ports using the Web Interface

From the Web, there's a “Connect to Serial Port” option that has to be selected. A serial port is chosen and a Java window will open on the user's screen. For a telnet session, just log in and provide the password (whenever necessary). For ssh, enter

```
<username>:<TCP port number or alias for the server>
```

as login name and provide the password (whenever necessary). To exit the session, select “Disconnect” from the Java window. See the [Step-by-Step Process](#) section of [Appendix I - Connect to Serial Ports from Web](#) for more details.



# Chapter 3 - Additional Features

---

## Introduction

After the Configuration Wizard section in this chapter, each of the following sections is listed alphabetically and shows how to configure the option using vi, the custom Wizard (when available), browser, where appropriate, and the Command Line Interface (CLI), when available. This chapter contains the following sections:

- [Configuration Wizard - Basic Wizard](#)
- [Access Method](#)
- [Authentication](#)
- [CAS Port Pool](#)
- [Clustering](#)
- [CronD](#)
- [Data Buffering](#)
- [DHCP](#)
- [Dual Power Management](#)
- [Filters and Network Address Translation](#)
- [Generating Alarms](#)
- [Help](#)
- [NTP](#)
- [PCMCIA Ports Configured as Terminal Servers Serial Settings](#)
- [Session Sniffing](#)
- [SNMP](#)
- [Syslog](#)
- [Terminal Appearance](#)
- [Time Zone](#)

## Configuration Wizard - Basic Wizard

The configuration wizard application is a quicker and easier way to configure the BLACK BOX® Advanced Console Server. It is recommended that you use this application if you are not familiar with the vi editor or if you just want to do a quick installation of the BLACK BOX® Advanced Console Server.

The command *wiz* gets you started with some basic configuration. After executing this command, you can continue the configuration of the BLACK BOX® Advanced Console Server using any browser or by editing system files with the vi editor. What follows are the basic parameters to get you quickly started. The files that will be eventually modified if you decide to save to flash at the end of this application are:

1. /etc/hostname
2. /etc/hosts
3. /etc/resolv.conf
4. /etc/network/st\_routes
5. /etc/network/ifcfg\_eth0
6. /etc/portslave/pslave.conf

Step 1: Enter the command *wiz*.

At the command prompt type “wiz” in your terminal to bring up the wizard. You will receive an initial instruction screen.

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or

# Chapter 3 - Additional Features

---

3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

**Step 2: Press Enter to continue with the wizard.**

**You will see the current configurations and have the choice of setting them to default values, or not.**

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

```
Hostname: CAS  
DHCP: enabled  
Domain name: #  
Primary DNS Server: #  
Gateway IP: eth0
```

Set to defaults? (y/n) [n] :

**Step 3: Press Enter or type *n* or *y*.**


**The default answer or value to any question is in the brackets. You can take one of three actions:**

- Either just press the ENTER key to execute whatever is in between the brackets, or
- Type *n* to NOT reset the current configurations to the Black Box defaults, or
- Type *y* to reset to Black Box default configurations.

## Configuration Wizard - Basic Wizard

---

---



Tip. On most of the following configuration screens, the default or current value of the parameter is displayed inside brackets. Just press the ENTER key if you are satisfied with the value in the brackets. If not, enter the appropriate parameter and press ENTER.

If at any time after choosing whether to set your configurations to default or not, you want to exit the wizard or skip the rest of the configurations, press ESC. This will immediately display a summary of the current configurations for your verification before exiting the application. This will not work if you did not enter a valid choice for the parameter you are currently on.

For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

**Step 4: Enter Hostname and then press the Enter key.**

This is an alias for your BLACK BOX ® Advanced Console Server that allows you to refer to the BLACK BOX ® Advanced Console Server by this name rather than its IP address. Enter hostname after the prompt:

Hostname[ CAS ] :

**Step 5: Type *y*, *n*, or press Enter to enable or disable DHCP client.**

Type *y* or press Enter if there is a DHCP Server in your LAN, to have the Dynamic Host Configuration Protocol (DHCP) automatically assign an IP address for your BLACK BOX ® Advanced Console Server. Type *n* to manually assign an IP address.

Do you want to use dhcp to automatically assign an IP for your system (y/n) [y]:



Note: Typing *y* omits Steps 6 and Step 10.

# Chapter 3 - Additional Features

---

**Step 6:** If DHCP client is disabled, enter IP Address of your BLACK BOX ® Advanced Console Server and then press the Enter key.

If the DHCP client is enabled, skip this step. This question will only appear if DHCP client is disabled. This is the IP address of the BLACK BOX ® Advanced Console Server within your network. See your network administrator to obtain a valid IP address for the BLACK BOX ® Advanced Console Server .

```
IP of your system[]: 192.168.160.10
```

**Step 7:** Enter Domain name and then press Enter.

Domain name locates or identifies your organization within the Internet.

```
Domain name[#]: mycompany.com
```

**Step 8:** Enter IP address of Domain Name Server and press Enter.

At the prompt, enter the IP address of the server that resolves domain names. Your domain name is alphabetical so that it is easier to remember. Every time you see the domain name, it is actually being translated into an IP address by the domain name server. See your network administrator to obtain this IP address for the domain name server.

```
Domain Name Server[#]: 192.168.160.200
```

**Step 9:** Enter Gateway IP address and press Enter.

The Gateway is a node on a network that serves as an entrance point into another network. See your network administrator to find out your organization's gateway address.

```
Gateway IP[eth0]: 192.168.160.1
```

**Step 10:** If DHCP client is disabled, enter Netmask and press Enter.

If the DHCP client is enabled, skip this step. This question will appear only if DHCP client is disabled. The Netmask is a string of 0s and 1s that mask or screen out the host part of an IP address so that only the network part of the address remains.

```
Netmask[#]: 255.255.255.0
```

**Step 11:** Review configuration parameters.

You will now have the parameters you just configured displayed back to you. If you entered *y* in Step 5:

# Configuration Wizard - Basic Wizard

---

---

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

```
Hostname: CAS  
DHCP: enabled  
Domain name: mycompany.com  
Primary DNS Server: 197.168.160.200  
Gateway IP: 192.168.160.1
```

Are all these parameters correct (Y)es or (N)o [N]:

**If you entered *n* in Step 5:**

Current configuration:

```
Hostname: CAS  
DHCP: disabled  
System IP: 192.168.160.10  
Domain name: mycompany.com  
Primary DNS Server: 192.168.160.200  
Gateway IP: 192.168.160.1  
Network Mask: 255.255.255.0
```

Are all these parameters correct (y/n) [y]:

**Step 12:** Type *y*, or *n*, or press Enter.

Type *y* if all parameters are correct. Type *n* or just press ENTER if not all the parameters are correct and you want to go back and redo them.

**Step 13:** If you typed *n* in Step 11, type *c* or *q*.

As directed by the prompt, type *c* to go back to very beginning of this application to change the parameters. Type *q* to exit.

**Step 14:** If you typed *y* in Step 11, choose whether to activate your configurations.

# Chapter 3 - Additional Features

---

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You can now use the browser to finish your system configurations, but before that, please read below.

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## Step 15: Choose whether to save to flash.

**Flash is a type of memory that will maintain the information saved on it even after the BLACK BOX ® Advanced Console Server is turned off. Once it is turned on again, the saved information can be recovered. If y is entered, the screen will display an explanation of what saving to flash means:**

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time, thus making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the BLACK BOX ® Advanced Console Server even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the BLACK BOX ® Advanced Console Server.

Do you want to save your configurations to flash? (y/n) [n]:

## Step 16: Type 'y' if you want to save to flash. Type 'n' if you don't want to save to flash.

**You can now continue BLACK BOX ® Advanced Console Server configurations using the Web browser by typing in the IP address of the BLACK BOX ® Advanced Console Server.**

## Configuration Wizard - Basic Wizard

---

---

### Using the Wizard through your Browser

The Web interface supports wizards for serial ports configuration. The wizard is a useful tool that simplifies configuration of serial ports. The Web interface will access the following wizard files:

- /etc/portslave/pslave.wiz.cas (CAS)
- /etc/portslave/pslave.wiz.ts (TS)
- /etc/portslave/pslave.wiz.ras (Dial-in Access)

The step-by-step process to configuring ports for a specific profile appear in the following sections, and the exact screen flow begins with.

To summarize the process, the wizard configuration is started by first selecting the desired port(s) on the Port Selection page ([Figure 13: Port Selection page](#)), clicking Submit, and then selecting either the CAS, TS, or RAS profile buttons on the subsequent Serial Port Configuration Page. Change the appropriate parameters, and then click the Submit button on the Serial Port Configuration Page. For most applications, the parameters to be changed are:

For CAS:

- Port Speed
- First RADIUS/TacacsPlus Authentication Server
- First Accounting Server
- RADIUS/TacacsPlus secret
- Protocol (if the protocol is Socket SSH, Socket Telnet, or Socket Raw)
- Socket Port (keep the “Incremented” option on)



# Chapter 3 - Additional Features

---

For TS:

- Port Speed
- First RADIUS/TacacsPlus Authentication Server
- First Accounting Server
- RADIUS/TacacsPlus secret
- Protocol (if the protocol is Login, Rlogin, SSH, or Socket Client)
- Socket Port (write the TCP port for the protocol selected; keep the “incremented” option off)

For Dial-in access:

- First RADIUS/TacacsPlus Authentication Server
- First Accounting Server
- RADIUS/TacacsPlus secret
- Remote IP Address (keep the “Incremented” option on)

## Access Method

*Access method* is how a user accesses a server connected to one of the serial ports on the BLACK BOX® Advanced Console Server (CAS profile) or how a user connected to one of the serial ports accesses a server in the network (TS profile or Dial-In profile).

### Configuration for CAS

Parameters Involved and Passed Values

The parameters involved in configuring Access Method for CAS are as follows:

- all.ipno* This is the default IP address of the BLACK BOX ® Advanced Console Server's serial ports. Any host can access a port using its IP address as long as a path to the address exists in the host's routing table. An example value would be 192.168.1.101+. The "+" indicates that the first port should be addressed as 192.168.1.101 and the following ports should have consecutive values.
- all.socket\_port* In the CAS profile, this defines an alternative labeling system for the BLACK BOX ® Advanced Console Server ports. An example value would be 7001+. The "+" after the numerical value causes the serial interfaces to be numbered consecutively. In this example, serial interface 1 is assigned the port value 7001, serial interface 2 is assigned the port value 7002, etc. One example on how this could be used is in the case of all.protocol or s<n>.protocol socket\_ssh and the port value (7001, 7002, etc), if supplied by the ssh client like username:port value, the ssh client will be directly connected with the serial interface.
- all.protocol* The possible protocols are telnet, ssh1/ssh2 or raw data:  
*socket\_server* = telnet protocol,  
*socket\_ssh* = ssh1/ssh2 protocol,  
*raw\_data* = used to exchange data in transparent mode. Raw\_data is similar to socket\_server mode but without telnet negotiation breaks to serial ports.  
An example value would be socket\_server.
- all.users* Restricts access to ports by user name (only the users listed can access the port or, using the character "!", all but the users listed can access the port.) A single comma and spaces/tabs may be used between names. A comma may not appear between the "!" and the first user name. The users may be local, Radius or TacacsPlus. User groups (defined with the parameter conf.group) can be used in combination with user names in the parameter list. Notice that these are common users, not administrators. Example: all.users ! joe, mark, user\_group. In this example, the users joe, mark, and members of user\_group cannot access the port.

# Chapter 3 - Additional Features

---

- all.poll\_interval* Valid only for protocols `socket_server` and `raw_data`. When not set to zero, this parameter sets the wait for a TCP connection keep-alive timer. If no traffic passes through the BLACK BOX® Advanced Console Server for this period of time, the BLACK BOX® Advanced Console Server will send a line status message to the remote device to see if the connection is still up. If not configured, 1000 ms is assumed (the unit for this parameter is ms). If set to zero, line status messages will not be sent to the socket client.
- all.tx\_interval* Valid for protocols `socket_server` and `raw_data`. Defines the delay (in milliseconds) before transmission to the Ethernet of data received through a serial port. If not configured, 100ms is assumed. If set to zero or a value above 1000, no buffering will take place.
- all.idletimeout* *Valid only for the CAS configuration* (protocols `socket_server`, `socket_ssh`, and `raw_data`). Specifies how long (in minutes) a connection can remain inactive before it is cut off. If set to zero (the default), the connection will not time out.
- conf.group* Used to group users to simplify configuration of the parameter `all.users` later on. This parameter can be used to define more than one group. The format is:  
<group name>:<user1>{,<user2>[,<user3>]}  
Example: `conf.group group_name: user1, user2`.
- s<n>.serverfarm* Alias name given to the server connected to the serial port. `Server_connected`.  
Example: `s1.serverfarm Server_connected_serial1`.

## vi Method

The parameters described above must be changed by directly editing the `/etc/portslave/plsave.conf` file.

## Browser Method


To configure Access Method with your browser:

Step 1: Point your browser to the Console Server.

In the address or location field of your browser type the Console Access Server's IP address. For example:

`http://10.0.0.0`


**Step 2: Log in as root and type the Web root password configured by the Web server.**  
 This will take you to the Configuration and Administration page.



*Figure 12: Configuration and Administration page*

**Step 3: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page or in the Configuration section of the page. This will take you to the Port Selection page.



*Figure 13: Port Selection page*

**Step 4: Select port(s).**

On the Port Selection page, choose all ports or an individual port from the dropdown menu. This will take you to the Serial Port Configuration page.

# Chapter 3 - Additional Features


---

**Step 5:** Click the CAS profile button.

Click the CAS profile button in the wizards section. The default CAS profile parameters are now loaded.

**Step 6:** Scroll down to the Profile section.

You can change the settings for *all.ipno*, *all.socket\_port*, and *all.protocol* in this section.



Profile	
Protocol:	Socket Server
Remote IP Address:	192.168.1.101 <input checked="" type="checkbox"/> incremented
Socket Port:	7001 <input checked="" type="checkbox"/> incremented

*Figure 14: Profile Section of Serial Port Configuration page*

**Step 7:** Scroll to the Authentication Section.

You can configure the parameter *all.users* here under Access Restriction on Users.

**Step 8:** Scroll to Console Access Server Section.

You can configure the following parameters here:

- *all.sttyCmd*
- *all.poll\_interval*
- *all.tx\_interval*
- *all.idletimeout*

**Step 9:** Configure *s<n>.serverfarm*.


This parameter will not appear on the configuration page when “All ports” is selected. Scroll to the SSH section. Each port can be named after the server or device connected to it. This makes the process of associating what is connecting to which port easier.

**Step 10:** Click the Submit button.

This will take you back to the Port Selection page. At this point, the configuration file is written in the RAMdisk.

**Step 11:** Click on the Serial Port Groups link on the Link Panel.

Click the Add Group button that appears. A Serial Ports - Users Group Table Entry page appears.



The image shows a web form titled "Add Serial Ports - Users Group Table Entry #1". The form has a teal header bar with the title in white text. Below the header, there are two input fields. The first is labeled "Group Name:" and the second is labeled "Users:". Below these fields are two buttons: "Submit" and "Cancel". The form is overlaid on a faint background of a network diagram.

*Figure 15: Serial Ports - Users Group Table Entry page*

**Step 12:** Configure conf.group.

Fill in the Group Name and Users fields to configure the group.

**Step 13:** Click the Submit button.

At this point, the configuration file is written in the RAMdisk.

**Step 14:** Make the changes effective.

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 15:** Save it in the flash.

Go to the link Administration > Load/Save Configuration and click the Save to Flash button.

## Wizard Method

**Step 1:** Bring up the wizard.

At the command prompt, type the following to bring up the Access Method custom wizard:

```
wiz --ac cas
```

# Chapter 3 - Additional Features

---

This will bring up Screen 1:

## *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.ipno : #  
all.socket_port : 7001+  
all.protocol : socket_server  
all.users : #
```

```
all.poll_interval : #
all.tx_interval   : #
all.idletimeout   : #
conf.group        : #
```

Set to defaults? (y/n) [n] :

### *Screen 3:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

ALL.IPNO - This is the default IP address of the system's serial ports. If configured as 192.168.1.101+, the '+' indicates that the first port should be addressed as 192.168.1.101 and the following ports should have consecutive values. Any host can access a port using its IP address as long as a path to the address exists in the host's routing table.

```
all.ipno[#] :
```

ALL.SOCKET\_PORT - This defines an alternative labeling system for the system ports. The '+' after the numerical value causes the interfaces (or ports) to be numbered consecutively.

(e.g. interface 1 of your system is assigned port 7001, interface 2 has the value 7002, etc.)

```
all.socket_port[7001+] :
```



# Chapter 3 - Additional Features

---

## *Screen 4:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.PROTOCOL - The possible protocols are telnet, ssh1/ssh2, or raw data.  
(e.g. socket\_server -telnet protocol, socket\_ssh -ssh1/ssh2 protocol, raw\_data -used to exchange data in transparent mode; similar to socket\_server mode but without telnet negotiation breaks to serial ports.)

```
all.protocol[socket_server] :
```

ALL.USERS - Restricts access to ports by user name. Only the users listed can access the port, or using a '!', all but the users listed can access the port.  
A single comma and spaces/tabs may be used between names. A comma may NOT appear between the '!' and the first user name. The users may be local, Radius or TacacsPlus. User groups (defined with the parameter conf.group) can be used in combination with user names in the parameter list. Notice that these are common users, not administrators.  
(e.g. !joe, mark, grpl -the users, Joe, Mark, and members of grpl, cannot access the port.)

```
all.users[#] :
```

## *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.POLL\_INTERVAL - Valid for protocols socket\_server and raw\_data. When not set to 0, this parameter sets the wait for a TCP connection keep-alive timer. If no traffic passes through the system for this period of time, the system will send a line status message to the remote device to see if

the connection is still up. If not configured, default is 1000ms. If set to 0, line status messages will not be sent to the socket client.

all.poll\_interval[#] :

ALL.TX\_INTERVAL - Valid for protocols socket\_server and raw\_data. This parameter defines the delay (in milliseconds) before transmission to the Ethernet of data received through a serial port. If not configured, 100ms is assumed. If set to 0 or a value above 1000, no buffering will take place.

all.tx\_interval[#] :

### *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.IDLETIMEOUT - This parameter specifies how long (in minutes) a connection can remain inactive before it is cut off. If set to 0 (the default), the connection will not time out.

all.idletimeout[#] :

CONF.GROUP - Used to combine users into a group. This simplifies the parameter, all.users. You can define more than one group. (e.g. groupName: user1, user2)

conf.group[#] :sales: john, jane

Would you like to create another group? (y/n) [n] :

# Chapter 3 - Additional Features

---

## *Screen 7:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

Current configuration:  
(The ones with the '#' means it's not activated.)

```
all.ipno : #
all.socket_port : 7001+
all.protocol : socket_server
all.users : #
all.poll_interval : #
all.tx_interval : #
all.idletimeout : #
conf.group : #
```

Are these configuration(s) all correct? (y/n) [n]:

### *If you type 'n':*

Type 'c' to go back and CORRECT these parameters or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application.*

### *If you type 'y':*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 8, typing 'q' leads to Screen 9.*

---


---

*Screen 8:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You have 8 available ports on this system.

Type 'q' to quit, a valid port number[1-8], or anything  
else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. For "wiz -ac cas," an additional parameter is asked: serverfarm. Typing 'q' leads to Screen 9.

*Screen 9:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

# Chapter 3 - Additional Features

---

## *Screen 10:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

### CLI Method

To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be ttyS<serial port number> :

```
config configure line <serial port number> tty <string>
```

To configure the ipno:

```
config configure line <serial port number> ipno <string>
```

To configure the socket\_port:

```
config configure line <serial port number> socket <number>
```

To configure the protocol. <string> is the type of protocol desired:

```
config configure line <serial port number> protocol <string>
```

To configure modbus\_smode:

```
config configure line <serial port number> modbus <string>
```

To configure users:

```
config configure line <serial port number> users <string>
```

To configure the poll\_interval:

```
config configure line <serial port number> pollinterval  
<number>
```

To configure tx\_interval:

```
config configure line <serial port number> txinterval <num-  
ber>
```

# Chapter 3 - Additional Features

---

To configure `idletimeout`:

```
config configure line <serial port number> idletimeout <number>
```

To configure `conf.group`:

```
config configure conf group <string>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
ipno <string> socket <number> protocol <string>  
modbus <string> users <string> pollinterval <number>  
txinterval <number> idletimeout <number>
```

**Step 2: Activate and Save.**

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## Configuration for TS

### Parameters and Passed Values

For TS configuration, you will need to configure the following parameters:

<i>all.host</i>	The IP address of the host to which the terminals will connect.
<i>all.protocol</i>	For the terminal server configuration, the possible protocols are login (which requests username and password), rlogin (receives username from the BLACK BOX ® Advanced Console Server and requests a password), telnet, ssh, ssh2, or socket_client. If the protocol is configured as telnet or socket_client, the parameter socket_port needs to be configured.
<i>all.socket_port</i>	This parameter is valid only if all.protocol is configured as socket_client or telnet. The socket_port is the TCP port number of the application that will accept connections requested by this serial port.
<i>all.telnet_client_mode</i>	When the protocol is TELNET, this parameter configured as BINARY (1) causes an attempt to negotiate the TELNET BINARY option on both input and output with the Telnet server. So it puts the telnet client in binary mode. The acceptable values are "0" or "1", where "0" is text mode (default) and "1" is a binary mode.
<i>all.userauto</i> (unique to TS)	Username used when connected to a UNIX server from the user's serial terminal.

### vi Method

The parameters described above must be changed by directly editing the /etc/portslave/pslave.conf file.



# Chapter 3 - Additional Features

---

## Browser Method

**Step 1:** Follow the steps 1 to 4 in the section titled Configuration for CAS, [“Browser Method” on page 75](#).

**Step 2:** Click the TS Profile button in the Wizard section.  
Configure the following parameters:

<i>Profile section:</i>	Protocol (telnet, ssh, rlogin or socket client) Socket port (23 for telnet, 22 for ssh, 513 for rlogin)
<i>Terminal Server section:</i>	Host (the name or the IP address of the host) Automatic User

**Step 3:** Click the Submit button.

At this point, the configuration file is written in the RAMdisk.

**Step 4:** Make changes effective.

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 5:** Save it in the flash.

Go to the link Administration > Load/Save Configuration and click the Save to Flash button.

## Wizard Method

**Step 1:** Bring up the wizard.

At the command prompt, type the following to bring up the Access Method custom wizard:

```
wiz --ac ts
```

This will bring up Screen 1:

## *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.protocol : rlogin  
all.socket_port : 23  
all.telnet_client_mode : 0  
all.userauto : #
```

Set to defaults? (y/n) [n] :

# Chapter 3 - Additional Features

---

## *Screen 3:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
```

ALL.PROTOCOL - Users can access the servers through the serial port using ssh, ssh2, telnet, login, rlogin, or socket\_client.  
(e.g. login -requests username and password, rlogin - receives username from the system and requests a password, etc.)

```
all.protocol[rlogin] :
```

ALL.SOCKET\_PORT - This defines the port(s) to be used by the protocols telnet and socket\_client. For these two protocols a default value of 23 is used when no value is configured.

```
all.socket_port[23] :
```

## *Screen 4:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

ALL.TELNET\_CLIENT\_MODE - This parameter only applies if the current protocol configured is telnet. Configuring as binary (1) causes an attempt to negotiate the TELNET BINARY option on both input and output with the Telnet server. Thus, it puts the telnet client in binary mode. The default is 0 which represents text mode.


```
all.telnet_client_mode[0] :
```

---

---

ALL.USERAUTO - Username used when connected to a Unix server from the user's serial terminal.

all.userauto[#] :



**Note:** all.host is configured under the wiz - - tso.

### *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.protocol : rlogin  
all.socket_port : 23  
all.telnet_client_mode : 0  
all.userauto : #
```

Are these configuration(s) all correct? (y/n) [n]:

### *If you type 'n'*

Type 'c' to go back and CORRECT these parameters or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

### *If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :

# Chapter 3 - Additional Features

---



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, `all.x`, and there was a specific port, `s2.x`, configured; then, answering yes to this question will discard `s2.x`.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 6, typing 'q' leads to Screen 7.*

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You have 8 available ports on this system.

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 7.

## *Screen 7:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## *Screen 8:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

# Chapter 3 - Additional Features

---

## CLI Method

To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be `ttyS<serial port number>` :

```
config configure line <serial port number> tty <string>
```

To configure the protocol (<string> is the type of protocol desired):

```
config configure line <serial port number> protocol <string>
```

To configure the `socket_port`:

```
config configure line <serial port number> socket <number>
```

To configure the `telnet_client_mode`:

```
config configure line <serial port number> telnetclientmode  
<number>
```

To configure `userauto`:

```
config configure line <serial port number> userauto <string>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
protocol <string> socket <number> telnetclientmode  
<number> userauto <string>
```

**Step 2:** Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing `signal_ras hup` and `saveconf` from the normal terminal prompt.)

---



---

## Configuration for Dial-in Access

### Parameters and Passed Values

The parameters that need to be configured are shown in the following list. *Note: The character “\” at the end of a line means that the string continues on the next line.*

- conf.pppd* Location of the ppp daemon with Radius. Default value:  
/usr/local/sbin/pppd.
- all.ipno* This is the default IP address of the BLACK BOX ® Advanced Console Server's serial ports. Any host can access a port using its IP address as long as a path to the address exists in the host's routing table. An example value would be 192.168.1.101+. The “+” indicates that the first port should be addressed as 192.168.1.101 and the following ports should have consecutive values.
- all.initchat* Modem initialization string. Example value:  
TIMEOUT 10 "" \d\ \dATZ \OK\r\n-ATZ-OK\r\n "" "" ATMO OK\R\N ""\  
TIMEOUT 3600 RING "" \  
STATUS Incoming %p:I.HANDSHAKE "" ATA\  
TIMEOUT 60 CONNECT@ "" \  
STATUS Connected %p:I.HANDSHAKE
- all.autoppp* Options to auto-detect a ppp session. The cb-script parameter defines the file used for callback and enables negotiation with the callback server. Callback is available in combination with Radius Server authentication. When a registered user calls the BLACK BOX ® Advanced Console Server, it will disconnect the user, then call the user back. The following three parameters must be configured in the Radius Server.
- attribute Service\_type(6): Callback Framed;
  - attribute Framed\_Protocol(7): PPP;
  - attribute Callback\_Number(19): the dial number (example: 50903300).



# Chapter 3 - Additional Features

---

Example value:

```
%j novj \  
proxyarp modem asyncmap 000A0000 \  
noipx noccp login auth require-pap refusechap\  
mtu %t mru %t \  
cb-script /etc/portslave/cb_script \  
plugin /usr/lib/libpsr.so
```

*all.pppopt* PPP options when user has already been authenticated.

Example value:

```
%i:%j novj \  
proxyarp modem asyncmap 000A0000 \  
noipx noccp mtu %t mru %t netmask%m \  
idle %I maxconnect %T \  
plugin /usr/lib/libpsr.so
```

*all.protocol* For the Dial-in configuration, the available protocols are PPP, SLIP and CSLIP.



Tip. Documentation about PPP options can be found on the Linux `pppd` man page.

vi Method

The parameters described above must be changed by directly editing the `/etc/portslave/pslave.conf` file.

Browser Method

For the serial ports you would have all the parameters described above but `conf.*`. To configure Access Method with your browser:

Step 1: Follow the steps 1 to 4 in the section titled Configuration for CAS, [“Browser Method” on page 75](#).

Step 2: Click the Dial in Profile button in the Wizard section.

**Step 3: Scroll down to the Profile section.**

You can change the settings for *all.ipno* and *all.protocol* in this section.

**Step 4: Scroll to the modem Section.**

You can configure the parameter *all.initchat* here.

**Step 5: Scroll to the PPP Section.**

You can configure the parameter *all.autoppp* and *all.pppopt* here.

**Step 6: Click the Submit button.**

At this point, the configuration file is written in the RAMdisk.

**Step 7: Make the changes effective.**

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 8: Save it in the flash.**

Go to the link Administration > Load/Save Configuration and click the Save to Flash button.

# Chapter 3 - Additional Features

---

## CLI Method

To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be `ttyS<serial port number>` :


```
config configure line <serial port number> tty <string>
```

To configure the protocol. <string> is the type of protocol desired:

```
config configure line <serial port number> protocol <string>
```

To configure ipno:

```
config configure line <serial port number> ipno <string>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
protocol <string> ipno <string>
```

**Step 2:** Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## Authentication

Authentication is the process of identifying an individual, usually based on a username and password. In security systems, authentication is distinct from authorization, which is the process of giving individuals access to system objects based on their identity. Authentication merely ensures that the individual is who he or she claims to be, but says nothing about the access rights of the individual. With the BLACK BOX ® Advanced Console Server, authentication can be performed locally, or with a remote Radius, Tacacs, or ldap database, or kerberos.

### Parameters Involved and Passed Values

The authentication feature utilizes the following parameters:

- all.authtype*      Type of authentication used. There are several authentication type options:
- *none* (no authentication)
  - *local* (authentication is performed using the `/etc/passwd` file)
  - *remote* (This is for a terminal profile only. The unit takes in a username but does not use it for authentication. Instead it passes it to the remote server where it is then used for authentication.)
  - *radius* (authentication is performed using a Radius authentication server)
  - *TacacsPlus* (authentication is performed using a TacacsPlus authentication server)
  - *ldap* (authentication is performed against an ldap database using an ldap server. The IP address and other details of the ldap server are defined in the file `/etc/ldap.conf`)

# Chapter 3 - Additional Features

---

- all.authtype*  
(cont.)
- *kerberos* (authentication is performed using a kerberos server. The IP address and other details of the kerberos server are defined in the file `/etc/krb5.conf`)
  - *local/radius* (authentication is performed locally first, switching to Radius if unsuccessful)
  - *radius/local* (the opposite of the previous option)
  - *local/TacacsPlus* (authentication is performed locally first, switching to TacacsPlus if unsuccessful)
  - *TacacsPlus/local* (the opposite of the previous option)
  - *RadiusDownLocal* (local authentication is tried only when the Radius server is down)
  - *TacacsPlusDownLocal* (local authentication is tried only when the TacacsPlus server is down)

Note that this parameter controls the authentication required by the BLACK BOX ® Advanced Console Server. The authentication required by the device to which the user is connecting is controlled separately.

*all.authhost1*  
*all.authhost2*

This address indicates the location of the Radius/TacacsPlus authentication server and is only necessary if this option is chosen in the previous parameter. A second Radius/TacacsPlus authentication server can be configured with the parameter `all.authhost2`.

*all.accthost1*  
*all.accthost2*

This address indicates the location of the Radius/TacacsPlus accounting server, which can be used to track how long users are connected after being authorized by the authentication server. Its use is optional. If this parameter is not used, accounting will not be performed. If the same server is used for authentication and accounting, both parameters must be filled with the same address. A second Radius/TacacsPlus accounting server can be configured with the parameter `all.accthost2`.

*all.radtimeout*

This is the timeout (in seconds) for a Radius authentication query to be answered.

- all.radretries* Defines the number of times each Radius/ TacacsPlus server is tried before another is contacted. The first server (authhost1) is tried “radretries” times, and then the second (authhost2), if configured, is contacted “radretries” times. If the second also fails to respond, Radius/ TacacsPlus authentication fails.
- all.secret* This is the shared secret (password) necessary for communication between the BLACK BOX ® Advanced Console Server and the Radius/ TacacsPlus servers.



**Note:** If you want to dial in to the serial port on a BLACK BOX ® Advanced Console Server series with CHAP authentication, you need to do the following:

1. Configure Sxx.authtype as local.
2. Add users in BLACK BOX ® Advanced Console Server.
3. Insert the users in the file /etc/ppp/chap-secrets.
4. Insert the file /etc/ppp/chap-secrets in the file /etc/config\_files.
5. Execute the *saveconf* command.

## Configuration for CAS, TS, and Dial-in Access

### vi Method

The parameters described above must be changed by directly editing the /etc/portslave/pslave.conf file.

### Browser Method

To configure Authentication with your browser:

**Step 1:** Follow the steps 1 to 4 in the section titled Configuration for CAS, [“Browser Method” on page 75](#).

**Step 2:** Scroll to the Authentication section.

Scroll down to the Authentication section and configure the parameters in this section.

# Chapter 3 - Additional Features

---

**Step 3: Click the Submit button.**

At this point, the configuration file is written in the RAMdisk.

**Step 4: Make changes effective.**

Click on the **Administration > Run Configuration** link, check the **Serial Ports/Ethernet/Static Routes** box and click on the **Activate Configuration** button.

**Step 5: Save it in the flash.**

Go to the link **Administration > Load/Save Configuration** and click the **Save to Flash** button.

## Wizard Method

### Step 1: Bring up the wizard.

At the command prompt, type the following to bring up the Authentication custom wizard:

```
wiz --auth
```

Screen 1 will appear.

#### *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...



# Chapter 3 - Additional Features

---

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.authtype : none  
all.authhost1 : 192.168.160.3  
all.accthost1 : 192.168.160.3  
all.authhost2 : 192.168.160.4  
all.accthost2 : 192.168.160.4  
all.radtimeout : 3  
all.radretries : 5  
all.secret : secret
```

Set to defaults? (y/n) [n] :

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.AUTHTYPE - This parameter controls the authentication required by the system. Users' access to the server through the serial port is granted through the check of username and password locally or remotely.

(e.g. none, local, TacacsPlus (note the capital 'T' in TacacsPlus), radius, ldap, kerberos, etc.)

```
all.authtype[none] :
```



Note: If *authtype* is configured as *none*, *local*, *ldap*, or *kerberos* the application will skip immediately to the summary screen because the rest of the parameters pertain only if the system is configured to use a Radius or TacacsPlus server. Configurations for *ldap* and *kerberos* are done in */etc/ldap.conf* and */etc/krb5.conf*, respectively.

ALL.AUTHHOST1 - This IP address indicates where the Radius or TacacsPlus authentication server is located.

```
all.authhost1[200.200.200.2] :
```

#### *Screen 4:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.ACCTHOST1 - This IP address indicates where the Radius or TacacsPlus accounting server is located. The accounting server can be used to track how long users are connected after being authorized by the authentication server.

```
all.accthost1[200.200.200.3] :
```

ALL.AUTHHOST2 - This IP address indicates where the SECOND Radius or TacacsPlus authentication server is located.

```
all.authhost2[200.200.200.2] :
```

# Chapter 3 - Additional Features

---

## *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.ACCTHOST2 - This IP address indicates where the SECOND Radius or TacacsPlus accounting server is located.

```
all.accthost2[200.200.200.3] :
```

ALL.RADTIMEOUT- This is the timeout (in seconds) for a Radius or TacacsPlus authentication query to be answered.

```
all.radtimeout[3] :
```

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.RADRETRIES - This defines the number of times each Radius or TacacsPlus server is tried before another is contacted.

```
all.radretries[5] :
```

ALL.SECRET - This is the shared secret necessary for communication between the system and the Radius or TacacsPlus servers.

```
all.secret[secret] :
```

## *Screen 7:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.authtype : none  
all.authhost1 : 200.200.200.2  
all.accthost1 : 200.200.200.3  
all.authhost2 : 200.200.200.2  
all.accthost2 : 200.200.200.3  
all.radtimeout : 3  
all.radretries : 5  
all.secret : rad-secret
```

Are these configuration(s) all correct? (y/n) [n] :

## *If you type 'n'*

Type 'c' to go back and CORRECT these parameters or 'q' to QUIT :

*Typing 'c' repeats application, typing 'q' exits the entire wiz application*

## *If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

# Chapter 3 - Additional Features

---

*Typing 'c' leads to Screen 8, typing 'q' leads to Screen 9.*

*Screen 8:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****  
You have 8 available ports on this system.
```

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 9.

*Screen 9:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## *Screen 10:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

**To configure certain parameters for a specific serial port.**

**Step 1: At the command prompt, type in the appropriate command to configure desired parameters.**

**To activate the serial port. <string> should be ttyS<serial port number> :**

```
config configure line <serial port number> tty <string>
```

**To configure authtype:**

```
config configure line <serial port number> authtype <string>
```

**To configure authhost1:**

```
config configure line <serial port number> authhost1  
<string>
```

**To configure accthost1:**

```
config configure line <serial port number> accthost1  
<string>
```

# Chapter 3 - Additional Features

---

**To configure authhost2:**

```
config configure line <serial port number> authhost2  
<string>
```

**To configure accthost2:**

```
config configure line <serial port number> accthost2  
<string>
```

**To configure radtimeout:**

```
config configure line <serial port number> timeout <number>
```

**To configure radretries:**

```
config configure line <serial port number> retries <number>
```

**To configure secret:**

```
config configure line <serial port number> secret <string>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
authtype <string> authhost1 <string> accthost1 <string>  
authhost2 <string> accthost2 <string> timeout <number>  
retries <number> secret <string>
```

**Step 2: Activate and Save.**

To activate your new configurations and save them to flash, type:

```
config write
```

## NIS Client

NIS (Network Information System) provides simple and generic client-server database access facilities that can be used to distribute information. This makes the network appear as a single system, with the same accounts on all hosts. The objective of this feature is to allow the administrator to manage BLACK BOX ® Advanced Console Server accounts on a NIS server.

The NIS client feature needs these following files/commands:

<code>/etc/yp.conf</code>	This file contains the configuration used by ypbind.
<code>/etc/domainname.conf</code>	This file contains the NIS domain name (set by the command <code>domainname</code> ).
<code>/usr/sbin/ypbind</code>	Finds the server for NIS domains and maintains the NIS binding information.
<code>/usr/bin/ypwhich</code>	Returns the name of the NIS server that supplies the NIS services.
<code>/usr/bin/ypcat</code>	Prints the values of all keys from the NIS database specified by map name.
<code>/usr/bin/ypmatch</code>	Prints the values of one or more keys from the NIS database specified by map name.
<code>/usr/sbin/domainname</code>	Shell script to read/write the NIS domain name.

## NIS Client Configuration

**Step 1:** Run the command *domainname*.

You ll want to make sure that you have the NIS domain name set.

```
Command : domainname [NIS domain name]
show or set the system's NIS/YP domain name
Ex : #domainname cyclades-nis
```

**Step 2:** Edit the `/etc/yp.conf` file.



# Chapter 3 - Additional Features

---

You will need to configure the NIS server.

Command : `vi /etc/yp.conf`

Example : NIS server has IP address 192.168.160.110, to add the following line in the file

```
ypserver 192.168.160.110
```

**Step 3: Edit the /etc/nsswitch.conf file.**

Change the /etc/nsswitch.conf file ("System Databases and Name service Switch "configuration file) to include the NIS in the lookup order of the databases.

**Step 4: Configure the parameter "<all/sxx>.authype" as "local."**

## How to Test the Configuration

To test the configuration do the following:

**Step 1: Start up the following command:**

```
/usr/sbin/ypbind
```

**Step 2: Display the NIS server name.**

Display the name of NIS server by running the following command:

```
/usr/bin/ypwhich
```

**Step 3: Display the "all users" entry.**

Displays the all users' entry in the NIS database by running the following command:

```
/usr/bin/ypcat -t passwd.byname
```

**Step 4: Display the user's entry in the NIS passwd file.**

```
/usr/bin/ypmatch -t <userid/username> passwd.byname
```

If the preceding steps were performed successfully, you now need to change the /etc/inittab file by uncommenting the line that performs a ypbind upon startup.

## nsswitch.conf file format

The `/etc/nsswitch.conf` file has the following format:

```
<database> : <service> [ <actions> <service> ]
```

where:

`<database>` - available: aliases, ethers, group, hosts, netgroup, network, passwd, protocols, publickey, rpc, services and shadow

`<service>` - available: nis (use NIS version 2) , dns (use Domain Name Service) and files (use the local files)

`<actions>` - Has this format: [ `<status>` = `<action>` ]

where:

`<status>` = SUCCESS, NOTFOUND, UNAVAIL or TRYAGAIN

`<action>` = return or continue

**SUCCESS** - No error occurred and the desired entry is returned. The default action for this status is 'return'

**NOTFOUND** - The lookup process works fine, but the needed value was not found. The default action for this status is "continue."

**UNAVAIL** - The service is permanently unavailable.

**TRYAGAIN** - The service is temporarily unavailable.

To use NIS only to authenticate users, you need to change the lines in `/etc/nsswitch.conf` that reference passwd, shadow, and group.

## Examples

1. You wish to authenticate the user first in the local database. If the user is not found, then use NIS:

```
passwd: files nis
shadow: files nis
group: files nis
```

2. You wish to authenticate the user first using NIS. If the user is not found, then use the local database:

```
passwd: nis file
shadow: nis files
group: nis files
```

3. You wish to authenticate the user first using NIS. If the user was not found or the NIS server is down, then use the local database:

```
passwd: nis [UNAVAIL=continue TRYAGAIN=continue] files
```

# Chapter 3 - Additional Features

---

shadow: nis [UNAVAIL=continue TRYAGAIN=continue] files  
group: nis [UNAVAIL=continue TRYAGAIN=continue] files

## CAS Port Pool

This feature is available for the BLACK BOX® Advanced Console Server 2.1.3 onward. CAS Port Pooling allows you to access a free serial port from a pool in addition to the original feature where you could access a specific serial port. When you access a serial port through the pool the features sniff session and multiple sessions are not available. This feature is available for serial ports configured as CAS profile only.

You can define more than one pool of serial ports. Each serial port can only belong to ONE pool. The pool is uniquely identified by a four parameter scheme:

- protocol,
- pool\_ipno,
- pool\_serverfarm, and
- pool\_socket\_port

The three new parameters: pool\_ipno, pool\_serverfarm, and pool\_socket\_port have the same meaning as ipno, serverfarm, and socket\_port respectively. Ports belonging to the same pool MUST be configured with the same value in these fields.

It is strongly recommended that you configure the same values in all parameters related to authentication for all serial ports belonging to a pool. Some of the authentication parameters are users, admin\_users, and authtype.

You can access the serial ports from a pool with the same commands you use today to access a specific serial port. You just need to use pool\_ipno, pool\_serverfarm, or pool\_socket\_port instead ipno, serverfarm, or socket\_port respectively in the ssh/telnet command.

When a connection request arrives using one of pool\_ipno, pool\_serverfarm, or pool\_socket\_port the BLACK BOX® Advanced Console Server will look for the first free

serial port from the pool and that port will be assigned to connection. If there is no serial port free in the pool the connection is just dropped.

## How to Configure it

Following is an example of serial port pool configuration:

```
#
# Serial port pool: pool-1
#

s1.tty ttyS1
s1.protocol socket_server
s1.socket_port 7001 // TCP port # for specific allocation
s1.pool_socket_port 3000 // TCP port # for the pool
s1.ipno 10.0.0.1 // IP address for specific allocation
s1.pool_ipno 10.1.0.1 // IP address for the pool
s1.serverfarm serial-1 // alias for specific allocation
s1.pool_serverfarm pool-1 // alias for the pool

s2.tty ttyS2
s2.protocol socket_server
s2.socket_port 7002 // TCP port # for specific allocation
s2.pool_socket_port 3000 // TCP port # for the pool
s2.ipno 10.0.0.2 // IP address for specific allocation
s2.pool_ipno 10.1.0.1 // IP address for the pool
s2.serverfarm serial-2 // alias for specific allocation
s2.pool_serverfarm pool-1 // alias for the pool

#
# Serial port pool: pool-2
#

s3.tty ttyS3
s3.protocol socket_ssh
s3.socket_port 7003 // TCP port # for specific allocation
s3.pool_socket_port 4000 // TCP port # for the pool
s3.ipno 10.0.0.3 // IP address for specific allocation
s3.pool_ipno 10.2.0.1 // IP address for the pool
s3.serverfarm serial-3 // alias for specific allocation
s3.pool_serverfarm pool-2 // alias for the pool
```

# Chapter 3 - Additional Features

---

```
s4.tty ttyS4
s4.protocol socket_ssh
s4.socket_port 7004 // TCP port # for specific allocation
s4.pool_socket_port 4000 // TCP port # for the pool
s4.ipno 10.0.0.4 // IP address for specific allocation
s4.pool_ipno 10.2.0.1 // IP address for the pool
s4.serverfarm serial-4 // alias for specific allocation
s4.pool_serverfarm pool-2 // alias for the pool
```

In the example above, there are two pools:

- *pool-1* (identified by Protocol `socket_server`, TCP port #3000, IP 10.1.0.1, and alias `pool-1`)
- *pool-2* (identified by Protocol `socket_ssh`, TCP port #4000, IP 10.2.0.1, and alias `pool-2`)

The serial ports `ttyS1` and `ttyS2` belong to the `pool-1`. The serial ports `ttyS3` and `ttyS4` belong to the `pool-2`.

You can access specifically serial port `ttyS1` by using TCP port 7001, IP address 10.0.0.1 or alias `serial-1`. If the `ttyS1` is being used by somebody else the connection will be dropped if the user is not a `admin_user`. Alternately, you can access `ttyS1` through pool (if it's free) using TCP port 3000, IP 10.1.0.1 or alias `pool-1`. If it is not free `ttyS2` will be automatically allocated. Additionally, if `ttyS2` is not free, the connection will be dropped.

Clustering

Clustering is available for the BLACK BOX® Advanced Console Server 2.1.0 and up allows the stringing of Terminal Servers so that one Master BLACK BOX® Advanced Console Server can be used to access all BLACK BOX® Advanced Console Servers on a LAN. The Master BLACK BOX® Advanced Console Server can manage up to 1024 serial ports, so that the following can be clustered:

- 1 Master 16-Port + 31 Slave 16-Ports or
- 1 Master 32-Port+ 15 Slave 32-Ports,

An example with one Master BLACK BOX® Advanced Console Server and two Slave BLACK BOX® Advanced Console Servers is shown in the following figure.




Figure 16: An example of the clustering feature

# Chapter 3 - Additional Features

---

## Parameters Involved and Passed Values

The Master BLACK BOX ® Advanced Console Server must contain references to the Slave ports. The configuration described earlier for Console Access Servers should be followed with the following exceptions for the Master and Slaves:

Table 7: Master Black Box Configuration (where it differs from the CAS standard)

Parameter	Description	Value for this example
conf.eth_ip	Ethernet Interface IP address.	20.20.20.1
conf.eth_ip_alias	Secondary IP address for the Ethernet Interface (needed for clustering feature).	
conf.eth_mask_alias	Mask for secondary IP address above.	255.255.255.0
all.socket_port	This value applies to both the local ports and ports on Slave BLACK BOX ® Advanced Console Server.	7001+
all.protocol	Depends on the application.	Socket_ssh or socket_server
all.authtype	Depends on the application.	Radius or local or none
s33.tty	This parameter must be created in the Master BLACK BOX ® Advanced Console Server file for every Slave port. Its format is: IP_of_Slave:[slave_socket_port] for non-Master ports. In this case, the slave_socket_port value is not necessary because s33.socket_port is automatically set to 7033 by all.socket_port above.	20.20.20.2:7033
s33.serverfarm	An alias for this port.	Server_on_slave1_serial_s1

Table 7: Master Black Box Configuration (where it differs from the CAS standard)

Parameter	Description	Value for this example
s33.ipno	This parameter must be created in the Master BLACK BOX ® Advanced Console Server file for every Slave port, unless configured using all.ipno.	0.0.0.0
s34.tty	See s33.tty.	20.20.20.2:7034
s34.serverfarm	An alias for this port.	Server_on_slave1_serial_s2
s34.ipno	See s33.ipno.	0.0.0.0
s35.tty	See s33.tty.	20.20.20.2:7035
s35.serverfarm	An alias for this port.	Server_on_slave1_serial_s3
s35.ipno	See s33.ipno.	0.0.0.0
etc. for s36-s64		
S65.tty	The format of this parameter is IP_of_Slave:[slave_socket_port] for non-Master ports. The value 7301 was chosen arbitrarily for this example.	20.20.20.3:7301
S65.serverfarm	An alias for this port.	Server_on_slave2_serial_s1
S65.ipno	See s33.ipno.	0.0.0.0
S66.tty	See s65.tty	20.20.20.3:7302
S66.serverfarm	An alias for this port.	Server_on_slave2_serial_s2
S66.ipno	See s33.ipno.	0.0.0.0
S67.tty	See s65.tty.	20.20.20.3:7303



# Chapter 3 - Additional Features

---

---

Table 7: Master Black Box Configuration (where it differs from the CAS standard)

Parameter	Description	Value for this example
S67.serverfarm	An alias for this port.	Server_on_slave2_serial_s3
S67.ipno	See s33.ipno.	0.0.0.0
etc. for s68-s96		

The Slave BLACK BOX<sup>®</sup> Advanced Console Servers do not need to know they are being accessed through the Master BLACK BOX<sup>®</sup> Advanced Console Server. (You are creating virtual terminals: virtual serial ports.) Their port numbers, however, must agree with those assigned by the Master.

Table 8: BLACK BOX<sup>®</sup> Advanced Console Server configuration for Slave 1 (where it differs from the CAS standard)

Parameter	Value for this example
all.protocol	socket_server
all.authtype	none
conf.eth_ip	20.20.20.2
all.socket_port	7033+
all.authtype	none

Table 9: BLACK BOX<sup>®</sup> Advanced Console Server configuration for Slave 2 (where it differs from the CAS standard)

Parameter	Value for this example
all.protocol	socket_server

**Table 9: BLACK BOX® Advanced Console Server configuration for Slave 2  
(where it differs from the CAS standard)**

Parameter	Value for this example
all.authtype	none
conf.eth_ip	20.20.20.3
all.authtype	none
all.socket_port	7301+

To access ports from the remote management workstation, use telnet with the secondary IP address:

```
telnet 209.81.55.110 7001
```

to access the first port of the Master BLACK BOX® Advanced Console Server.

```
telnet 209.81.55.110 7033
```

to access the first port of Slave 1.

```
telnet 209.81.55.110 7065
```

to access the first port of Slave 2.

Ssh can also be used from the remote management workstation:

```
ssh -l <username>:Server_on_slave2_serial_s3 209.81.55.110
```

to access the third port of Slave 2, or

```
ssh -l <username>:7069 209.81.55.110
```

to access the fifth port of Slave 2.


### Centralized Management - the Include File

The BLACK BOX® Advanced Console Server allows centralized management through the use of a Master pslave.conf file. Administrators should consider this approach to configure multiple BLACK BOX® Advanced Console Server. Using this feature, each unit has a simplified pslave.conf file where a Master include file is cited. This common configuration file contains information for all units, properly divided in separate sections, and would be stored on

# Chapter 3 - Additional Features

---

one central server. This file, in our example shown in [Figure 17: Example of Centralized Management](#), is `/etc/portslave/TSccommon.conf`. It must be downloaded to each BLACK BOX<sup>®</sup> Advanced Console Server.



*Figure 17: Example of Centralized Management*

The abbreviated `pslave.conf` and `/etc/hostname` files in each unit, for the example are:

For the `/etc/hostname` file in *unit 1*:

```
unit1
```

For the `pslave.conf` file in *unit 1*:

```
conf.eth_ip 10.0.0.1
conf.eth_mask 255.0.0.0
conf.include /etc/portslave/Scommon.conf
```

For the `/etc/hostname` file in *unit 2*:

```
unit2
```

For the `pslave.conf` file in *unit 2*:

```
conf.eth_ip 10.0.0.2
conf.eth_mask 255.0.0.0
```

```
conf.include /etc/portslave/TScommon.conf
```

**For the `/etc/hostname` file in *unit 3*:**

```
unit3
```

**For the `plsave.conf` file in *unit 3*:**

```
conf.eth_ip 10.0.0.3
```

```
conf.eth_mask 255.0.0.0
```

```
conf.include /etc/portslave/TScommon.conf
```

**The common include file for the example is:**

```
conf.host_config unit1
```

```
<parameters for unit1 following the rules for pslave.conf>
```

```
conf.host_config unit2
```

```
<parameters for unit2 following the rules for pslave.conf>
```

```
conf.host_config unit3
```

```
<parameters for unit3 following the rules for pslave.conf>
```

```
conf.host_config.end
```

When this file is included, *unit1* would read only the information between *conf.host\_config unit1* and *conf.host\_config unit2*. *Unit2* would use only the information between *conf.host\_config unit2* and *conf.host\_config unit3* and *unit3* would use information after *conf.host\_config unit3* and before *conf.host\_config.end*.

Steps for using Centralized Configuration

**Step 1:** Create and save the `/etc/portslave/pslave.conf` and `/etc/hostname` files in each BLACK BOX ® Advanced Console Server.

**Step 2:** Execute the command `signal_ras hup` on each unit.

# Chapter 3 - Additional Features

---

**Step 3:** Create, save, and download the common configuration.

Create and save the common configuration file on the server, then download it (probably using scp) to each unit. Make sure to put it in the directory set in the pslave.conf file (/etc/portslave in the example).

**Step 4:** Execute the command `signal_ras hup` on each unit again.

**Step 5:** Test each unit.

If everything works, add the line `/etc/portslave/TScommon.conf` to the `/etc/config_files` file.

**Step 6:** Save the file and close it.

**Step 7:** Execute the `saveconf` command.



**Note:** The included file `/etc/portslave/TScommon.conf` cannot contain another include file (i.e., the parameter `conf.include` must not be defined).

Also, `<max ports of BLACK BOX® Advanced Console Server> + N(+)` is done same way as serial port.

## Enhanced Clustering

With Enhanced Clustering, the CAS ports in the slave box can be configured as ssh or telnet and can have any type of authentication available. Authentication is performed in the Slave and not in the Master anymore. Additionally, the Master no longer needs to be the default gateway for all Slave boxes.

Enhanced clustering is available on implementations running Linux 2.4.x versions or newer. This new implementation is based on “iptables/nat” which is only available in these higher versions of Linux.

Enhanced Clustering has improved performance and security. Performance is greatly increased because only the NAT translation is performed on the Master box. The Master doesn't open an intermediary TCP connection with the Slave box. Also if ssh encryption and decryption is desired, it is performed on the Slave.

## New Parameters and Commands

A new parameter, `conf.nat_clustering_ip` allows you to enable or disable the clustering via the NAT table. This parameter should be configured with the IP address used to access the serial ports. The NAT clustering will work regardless of the interface where this IP address is assigned to. Additionally, there are two chains (`post_nat_cluster` and `pre_nat_cluster`) that holds all rules to perform NAT for clustering.

## Abbreviation List

<i>clustering_ip</i>	IP address of any BLACK BOX® Advanced Console Server interface (Master box). It is a public IP address and is the one that must be used to connect with the Slave's serial ports.
<i>master_ip</i>	Primary or secondary ethernet IP address of the Master box (usually a public IP address).
<i>slave_ip</i>	Primary or secondary ethernet IP address of the Slave box (usually a non public IP address)
<i>master_port</i>	Remote serial port parameter "socket_port" (configured in the Master box).
<i>slave_port</i>	Local serial port parameter "socket_port" (configured in the Slave box).

The Master BLACK BOX® Advanced Console Server box will issue a series of iptables commands to populate the nat table with the necessary rules to perform NAT translation for remote ports. Two chains will be created:

- *post\_nat\_cluster* (to change the source IP address), and
- *pre\_nat\_cluster* (to change the destination IP address)

The BLACK BOX® Advanced Console Server administrator must enable clustering via NAT in `pslave.conf` (`conf.nat_clustering_ip <clustering_ip>`).

```
iptables -D PREROUTING -t nat -p tcp -j pre_nat_cluster
iptables -D POSTROUTING -t nat -p tcp -j post_nat_cluster
```

# Chapter 3 - Additional Features

---

```
iptables -t nat -F post_nat_cluster
iptables -t nat -F pre_nat_cluster
iptables -t nat -X pre_nat_cluster
iptables -t nat -X post_nat_cluster
iptables -t nat -N pre_nat_cluster
iptables -t nat -N post_nat_cluster
iptables -A PREROUTING -t nat -p tcp -j pre_nat_cluster
iptables -A POSTROUTING -t nat -p tcp -j post_nat_cluster
iptables -A pre_nat_cluster -t nat -p tcp -d <master_ip> --dport
<master_port> -j DNAT --to <slave_ip>:<slave_port>
.....
iptables -A post_nat_cluster -t nat -p tcp -d <slave_ip> --dport
<slave_port> -j SNAT --to <master_ip>
.....
```

At any time the BLACK BOX ® Advanced Console Server administrator can issue an iptables command to view, change (at his own risk), or delete the rules in the nat table. If the administrator issues a “fwset restore” command he must also execute the command “signal\_ras hup” to recover the nat table.

BLACK BOX ® Advanced Console Server clustering was primarily designed to allow a large number of serial ports (in more than one box) to be accessed using just one single public IP address. It only works for ports configured with the CAS profile. With iptables you can extend the access to the clustering.

## Examples:

### 1. Accessing a Slave box with the WebUI from anywhere:

```
iptables -A PREROUTING -t nat -p tcp -d 192.168.47.79 --dport 8081
-j DNAT --to 192.168.51.2:80
```

### 2. Accessing a public DNS from any Slave box:

```
iptables -A PREROUTING -t nat -p udp -d 64.186.161.2 --dport 53 -j
SNAT --to 64.186.161.79:53
```

## How it works

The Master box (BLACK BOX® Advanced Console Server) will perform two translation for each packet. The destination IP address is translated in the PREROUTING stage. The source IP address is translated in the POSTROUTING stage.

The command to start a telnet client session has not changed. As before, it looks like this:

```
telnet <clustering_ip> <master_port>
```

And it will have the same result as the command below issued from a local workstation:

```
telnet <slave_ip> <slave_port>
```

The command to start an ssh client session must have the following command line option:

```
-p <master_port>
```

The <master\_port> will define at least the Slave box with which a connection is desired.

For example, you may use the following commands:

```
ssh -l <username1>:<server1> -p 7101 <master_ip>  
ssh -l <username2>:<server2> -p 7101 <master_ip>
```

The above commands will respectively have the same result as the following commands issued from a local workstation:

```
ssh -l <username1>:<server1> <slave1_ip>  
ssh -l <username2>:<server2> <slave1_ip>
```

If the parameter <master\_port> defines the local IP address assigned to the serial port, the command can be simplified:

```
ssh -l <username1> -p 7101 <master_ip>  
ssh -l <username2> -p 7102 <master_ip>
```


And it will have respectively the same result as the commands below issued from a local workstation:



# Chapter 3 - Additional Features

---

```
ssh -l <username1> <slave1_port1_ip>
ssh -l <username2> <slave2_port1_ip>
```



**Note:** In the old clustering implementation `<username?>` and `<server?>` must be valid in the Master box. In the new clustering they must be valid in the Slave. In the Master box there is no meaning anymore for remote port's `serverfarm` and `authtype` parameters.

If you wish to access all clustering ports with the `ssh` command option `-p port`, you must assign an IP address to the serial port. Do not omit the parameter `socket_port` in the Master box,

## General Configuration

The configuration of clustering ports is pretty much the same as before. There is only one new parameter in the Master box (`conf.nat_clustering_ip`) that enables or disables the clustering via NAT. The parameters *usernames* (if authentication is local) and *serverfarm* for remote ports must be configured now in the related Slave box.

In the following configuration examples, looking like “`s[1-32].tty ttyS[1-32]`” must be seen as 32 lines. For example:

```
s1.tty ttyS1
s2.tty ttyS2
...
s32.tty ttyS32
```

## Master box Configuration

```
#
# Enable Clustering via NAT
#
conf.nat_clustering_ip 64.186.161.108

#
# Primary ethernet IP address (must be the public IP).
```

```
#
conf.eth_ip    64.186.161.108
conf.eth_mask  255.255.255.0
conf.eth_mtu   1500
#
# Secondary ethernet IP address
#
conf.eth_ip_alias      192.168.170.1
conf.eth_mask_alias   255.255.255.0
#
# Local CAS serial ports (32 socket_ssh ports)
#
all.protocol socket_ssh
all.authtype local
all.socket_port 7001+

s[1-32].tty ttyS[1-32]
#
# Remote CAS serial ports, slave-1 (32 socket_ssh ports). This kind
of configuration can be used for ssh only; just one entry is neces-
sary.
#
s33.tty 192.168.170.2
s33.socket_port 7000
#
```

# Chapter 3 - Additional Features

---

```
# Remote CAS serial ports, slave-2 (32 socket_server ports)
#
s65.tty 192.168.170.3:7101
s66.tty 192.168.170.3:7102
....
s96.tty 192.168.170.3:7132

s65.socket_port 8001
s66.socket_port 8002
...
s96.socket_port 8032

#
# Remote CAS serial ports, slave-3 (32 socket_ssh ports)
#
s[97-128].tty 192.168.170.[101-132]
```

## Slave-1 box Configuration

```
#
# Primary ethernet IP address
#
conf.eth_ip 192.168.170.2
conf.eth_mask 255.255.255.0
conf.eth_mtu 1500

#
# Local CAS serial ports (32 socket_ssh ports)
#
all.protocol socket_ssh
all.authtype local

s[1-32].tty ttyS[1-32]
s[1-32].serverfarm slave-1-port[1-32]
```

## Slave-2 box Configuration

```
#
# Primary ethernet IP address
#
conf.eth_ip 192.168.170.3
conf.eth_mask 255.255.255.0
conf.eth_mtu 1500

#
# Local CAS serial ports (32 socket_server ports)
#
all.protocol socket_server
all.authtype local
all.socket_port 7101+

s[1-32].tty ttyS[1-32]
```

## Slave-3 box Configuration

```
#
# Primary ethernet IP address
#
conf.eth_ip 192.168.170.4
conf.eth_mask 255.255.255.0
conf.eth_mtu 1500

#
# Local CAS serial ports (32 socket_ssh ports)
#
all.protocol socket_ssh
all.authtype local
all.ipno 192.168.170.101+

s[1-32].tty ttyS[1-32]
```

# Chapter 3 - Additional Features

---

Example of starting CAS session commands

The *serverfarm*, *socket\_port*, or *tty* must be provided to select which serial port is to be connected to in the Slave box 1.

```
ssh -l <username>:<slave-1-port[1-32] -p 7000 64.186.161.108
```

The *master\_port* (*socket\_port* in the Master) will select which serial port is to be connected to in the Slave boxes 1 and 2.

```
telnet 64.186.161.108 80[01-32]
```

```
ssh -l -p [7097-7128] 64.186.161.108
```

---

---

## CronD

CronD is a service provided by the BLACK BOX® Advanced Console Server system that allows automatic, periodically-run custom-made scripts. It replaces the need for the same commands to be run manually.

### Parameters Involved and Passed Values

The following parameters are created in the `/etc/crontab_files` file:

- status* Active or inactive. If this item is not active, the script will not be executed.
- user* The process will be run with the privileges of this user, who must be a valid local user.
- source* Pathname of the crontab file that specifies frequency of execution, the name of shell script, etc. It should be set using the traditional crontab file format.

### Example:

The name of the shell script with the commands to be executed is `/etc/teste_cron.sh`.


The name of the crontab file is `/etc/crontab_tst` and it contains one line:

```
0-59 * * * * /etc/test_cron.sh
```

Insert the follow line in the `/etc/crontab_files`:

```
active root /etc/crontab_tst
```

Result: CronD will execute the shell script `teste_cron.sh` with root privileges each minute.



**Note:** In `/etc/crontab`, you can only have one active entry per user. For instance, from the example above, you cannot add another active entry for root because it already has an entry. If you want to add more scripts, you can just add them to the source file (`/etc/crontab_tst`).

# Chapter 3 - Additional Features

---

## Configuration for CAS, TS, and Dial-in Access



**Important!** After creating the shell script and *crontab* file and modifying the *crontab\_files* file, make sure the file named */etc/config\_files* contains the names of all files that should be saved to flash. Run the command *saveconf* after this confirmation.

### vi Method

The files *Crontab* and shell script are created and the file */etc/crontab\_files* is modified as indicated.

To use *cronD*:

**Step 1:** Create the files for every process that it will execute:

**Step 2:** Create a line in the file */etc/crontab\_files* for each process to be run.

**Step 3:** Update the system.

The next step is to update the system with the modified data. Make sure the file named */etc/config\_files* contains the names of all files that should be saved to flash.

**Step 4:** Run *saveconf*.

The command *saveconf*, which reads the */etc/config\_files* file, should then be run. *saveconf* copies all the files listed in the file */etc/config\_files* from the ramdisk to */proc/flash/script*.

**Step 5:** Reboot the BLACK BOX ® Advanced Console Server.

### Browser Method

To configure *CronD* with your browser:

**Step 1:** Point your browser to the Console Server.

In the address or location field of your browser type the Console Access Server's IP address. For example:


`http://10.0.0.0`

---

Step 2: Log in as root and type the Web root password configured by the Web server.  
This will take you to the Configuration and Administration page.

Step 3: Click on the Edit Text File link.

Click on this link on the Link Panel. You can then pull up the appropriate file and edit it.



*Figure 18: Edit Text File page*



# Chapter 3 - Additional Features

---

## Data Buffering

### Introduction

Data buffering can be done in local files or in remote files through NFS. When using remote files, the limitation is imposed by the remote Server (disk/partition space) and the data is kept in linear (sequential) files in the remote Server. When using local files, the limitation is imposed by the size of the available ramdisk. You may wish to have data buffering done in file, syslog or both. For syslog, *all.syslog\_buffering* and *conf.DB\_facility* are the parameters to be dealt with, and *syslog-ng.conf* file should be set accordingly. (Please see [Syslog](#) for the syslog-ng configuration file.) For the file, *all.data\_buffering* is the parameter to be dealt with.

*Conf.nfs\_data\_buffering* is a remote network file system where databuffering will be written, instead of using the default directory */var/run/DB*. When commented, it indicates local data buffering. The directory tree to which the file will be written must be NFS-mounted and the local path name is */mnt/DB\_nfs*. The remote host must have NFS installed and the administrator must create, export, and allow reading/writing to this directory. The size of this file is not limited by the value of the parameter *s1.data\_buffering*, though the value cannot be zero since a zero value turns off data buffering.

The *conf.nfs\_data\_buffering* parameter format is:

```
<server name or IP address>:<remote pathname>
```

If data buffering is turned on for port 1, for example, the data will be stored in the file *ttyS1.data* (or *&lt;serverfarm1&gt;.data* if *s1.serverfarm* was configured) in local directory */var/run/DB* or in remote path name and server indicated by the *conf.nfs\_data\_buffering*.

### Ramdisks

Data buffering files are created in the directory */var/run/DB*. If the parameter *s<nn>.serverfarm* is configured for the port *<nn>*, this name will be used. For example, if the *serverfarm* is called *bunny*, the data buffering file will be named *bunny.data*.

The shell script */bin/build\_DB\_ramdisk* creates a 48 Mbyte ramdisk for the BLACK BOX® Advanced Console Server. Use this script as a model to create customized ramdisks for your environment. Any user-created scripts should be listed in the file */etc/user\_scripts* because *rc.sysinit* executes all shell scripts found there. This avoids changing *rc.sysinit* itself.

## Linear vs. Circular Buffering

For local data buffering, this parameter allow users to buffer data in either a circular or linear fashion. Circular format (cir) is a revolving buffer file that is overwritten whenever the limit of the buffer size (set by `all.data_buffering`) is reached. In linear format (lin), data transmission between the remote device and the serial port ceases once the 4k bytes Rx buffer in the kernel is reached. Then if a session is established to the serial port, the data in the buffer is shown (`dont_show_DBmenu` must be 2), cleared, and data transmission is resumed. Linear buffering is impossible if flow control is set to none. Default is cir.

## Parameters Involved and Passed Values

Data Buffering uses the following parameters:

### *all.data\_buffering*

A non zero value activates data buffering (local or remote, according to what was configured in the parameter `conf.nfs_data_buffering`). If local data buffering, a file is created on the BLACK BOX ® Advanced Console Server; if remote, a file is created through NFS in a remote server. All data received from the port is captured in this file. If local data buffering, this parameter means the maximum file size (in bytes). If remote, this parameter is just a flag to activate (greater than zero) or deactivate data buffering. When local data buffering is used, each time the maximum is reached the oldest 10% of stored data is discarded, releasing space for new data (FIFO system) - circular file. When remote data

### *all.data\_buffering (cont.)*

buffering is used, there's no maximum file size other than the one imposed by the remote server - linear file. This file can be viewed using the normal UNIX tools (cat, vi, more, etc.). *Size is in bytes not kilobytes.*

# Chapter 3 - Additional Features

---

## *conf.nfs\_data\_buffering*

This is the Remote Network File System where data captured from the serial port will be written instead of being written to the local directory `/var/run/DB`. The directory tree to which the file will be written must be NFS-mounted, so the remote host must have NFS installed and the administrator must create, export and allow reading/writing to this directory. The size of this file is not limited by the value of the parameter `all.data_buffering`, though the value cannot be zero since a zero value turns off data buffering. The size of the file is dependent on the NFS server only (hard drive, partition size, etc.).

## *all.DB\_mode*

When configured as `cir` for circular format, the buffer is like a revolving file that is overwritten whenever the limit of the buffer size (as configured in `all.data_buffering` or `s<n>.data_buffering`) is reached. When configured as `lin` for linear format, once 4k bytes of the Rx buffer in the kernel is reached, a flow control stop (RTS off or XOFF—depending on how `all.flow` or `s<n>.flow` is set) is issued to prevent the serial port from receiving further data from the remote. Then when a session is established to the serial port, a flow control start (RTS on or XON) will be issued and data reception will then resume. If `all.flow` or `s<n>.flow` is set to `none`, linear buffering isn't possible. Default is `cir`.

## *all.syslog\_buffering*

When nonzero, the contents of the data buffer are sent to the `syslog-ng` every time a quantity of data equal to this parameter is collected. The `syslog` level for data buffering is hard coded to level 5 (notice) and facility is local plus `conf.DB_facility`. The file `/etc/syslog-ng/syslog-ng.conf` should be set accordingly for the `syslog-ng` to take some action.

- all.syslog\_sess* This parameter determines whether syslog is generated when a user is connected to the port or not. Originally, syslog is always generated whether the user is connected to the port or not. Now, users have the option to NOT have syslog generate messages when they connect to a port. This feature does not affect the local data\_buffering file. When set to 0 (default), syslog is always generated. When set to 1, syslog is only generated when the user is NOT connected to the port sending the data. When the user does connect to the port that is sending data, syslog messages won't be generated.
- all.dont\_show\_DBmenu* When zero, a menu with data buffering options is shown when a nonempty data buffering file is found. When 1, the data buffering menu is not shown. When 2, the data buffering menu is not shown but the data buffering file is shown if not empty. When 3, the data buffering menu is shown, but without the erase and show and erase options.
- all.DB\_timestamp* Records the time stamp in the data buffering file (1) or not (0). If it is configured as 1, the software will accumulate input characters until it receives a CR and LF from the serial port or the accumulated data reaches 256 characters. Either way, the accumulated data will be recorded in the data buffering file along with the current time. The parameter all.data\_buffering has to be with a non-zero value for this parameter to be meaningful.

## Configuration for CAS

vi Method

Files to be modified:

- pslave.conf
- syslog-ng.conf

# Chapter 3 - Additional Features

---

## Browser Method

To configure Data Buffering with your browser:

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

**Step 3: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page or in the Configuration section of the page. This will take you to the Port Selection page.

**Step 4: Select port(s).**

On the Port Selection page, choose all ports or an individual port to configure, from the dropdown menu. Click the Submit button. This will take you to the Serial Port Configuration page.

**Step 5: Scroll down to the Data Buffering section.**

You can change the settings in this section.

Data Buffering	
Maximum Buffer Size (0-disabled):	<input type="text" value="0"/>
Data Buffering Mode:	<input checked="" type="radio"/> CIR <input type="radio"/> LIN
Records the time stamp in the data buffering file:	<input type="radio"/> yes <input checked="" type="radio"/> no
Buffer size to send syslog (40 to 255, 0-disabled):	<input type="text" value="0"/>
Syslog Buffering at all times:	<input checked="" type="radio"/> yes <input type="radio"/> no
Data Buffering Menu:	<input type="text" value="Show Menu"/>
Alarm for Data Buffering:	<input type="radio"/> yes <input checked="" type="radio"/> no

*Figure 19: Data Buffering section of the Serial Port Configuration page*

**Step 6:** Click the Submit button.

**Step 7:** Select the General link.

Click on the General link on the Link Panel to the left of the page.

**Step 8:** Scroll down to the Data Buffering section.

Choose whether NFS will be used or not, and choose the Data Buffering Facility level here.



The screenshot shows a configuration panel titled "Data Buffering" with a teal header. Below the header are two rows of configuration options. The first row is labeled "Remote NFS path:" and has an empty text input field. The second row is labeled "Data Buffering Facility:" and has a dropdown menu with "local7" selected.

*Figure 20: Data Buffering section of the General page*

**Step 9:** Click the Submit button.

**Step 10:** Make the changes effective.

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 11:** Click on the link Administration > Load/Save Configuration.

**Step 12:** Click the Save Configuration to Flash button.

## Wizard Method

**Step 1:** Bring up the wizard.

At the command prompt, type the following to bring up the Data Buffer custom wizard:

```
wiz --db
```

# Chapter 3 - Additional Features

---

## *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
conf.nfs_data_buffering : #  
all.data_buffering : 0  
all.DB_mode : cir  
all.dont_show_DBmenu : 0  
all.DB_timestamp : 0  
all.syslog_buffering : 0  
all.syslog_sess : 0
```

Set to defaults? (y/n) [n] :

## Screen 3:

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

CONF.NFS\_DATA\_BUFFERING - This parameter applies only if users choose to remotely buffer data. This is the remote directory name where data buffering will be written to instead of the default directory '/var/run'. If deactivated, data buffering will be done locally.

conf.nfs\_data\_buffering[#] :

ALL.DATA\_BUFFERING - For local data buffering, this parameter represents the maximum file size in bytes allowed to be captured before it is discarded for new space. If remote this parameter is just a flag to either activate (any value greater than 0) or deactivate data buffering.

all.data\_buffering[0] :

## Screen 4:

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.DB\_MODE - For local data buffering, this parameter allow users to buffer data in either a circular or linear fashion. Circular format (cir) is a revolving buffer file that is overwritten whenever the limit of the buffer size (set by all.data\_buffering) is reached. In linear format (lin), data transmission between the remote device and the serial port ceases once the 4k bytes Rx buffer in the kernel is reached. Then if a session is established to the serial port, the data in the buffer is shown (dont\_show\_DBmenu must be 2), cleared, and data transmission is resumed. Linear buffering is impossible if flow control is set to none. Default is cir.

all.DB\_mode[cir] :



# Chapter 3 - Additional Features

---

ALL.DONT\_SHOW\_DBMENU - When 0, a menu with data buffering options is shown when a non-empty data buffering file is found. When 1, the data buffering menu is not shown. When 2, the data buffering menu is not shown but the data buffering file is shown if not empty. When 3, the data buffering menu is shown, but without the 'erase and show' and 'erase' options.

all.dont\_show\_DBmenu[0] :

## *Screen 5:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
ALL.DB_TIMESTAMP - Records the time stamp in the data buffering file (1) or not (0). In case it is configured as 1, the software will accumulate input characters until it receives a CR and LF from the serial port, or the accumulated data reaches 256 characters. Either way, the accumulated data will be recorded in the data buffering file along with the current time. The parameter, all.data_buffering, has to be nonzero in order for this parameter to work.
```

all.DB\_timestamp[0] :

ALL.SYSLOG\_BUFFERING - This parameter is another option to data buffering. Users can also have syslog perform this function along with data buffering into files. When nonzero, the contents of the data buffer are sent to the syslog-ng every time a quantity of data equal to this parameter is collected. The syslog level for data buffering is hard coded to level 5 (notice) and facility conf.DB\_facility. The file /etc/syslog-ng/syslog-ng.conf should be set accordingly for the syslog-ng to take some action.

(Please see the 'Syslog-ng Configuration to use with

Syslog Buffering Feature' section under Generating Alarms in Chapter 3 of the system's manual for the syslog-ng configuration file.)

```
all.syslog_buffering[0] :
```

### *Screen 6:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
ALL.SYSLOG_SESS - In order for this parameter to function,
make sure syslog buffering is activate. When set as 0,
syslog messages are always generated whether or not there
is a connection to the port that is sending data to your
unit. When set to 1, syslog messages are NOT generated when
there IS a connection to the port that is sending data. It
is only generated when there isn't a session to the port
that is sending data to your unit.
```

```
all.syslog_sess[0] :
```

### *Screen 7:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
```

```
Current configuration:
(The ones with the '#' means it's not activated.)
```

```
conf.nfs_data_buffering : #
all.data_buffering : 0
all.DB_mode : cir
all.dont_show_DBmenu : 0
all.DB_timestamp : 0
all.syslog_buffering : 0
all.syslog_sess : 0
```

```
Are these configuration(s) all correct? (y/n) [n] :
```

# Chapter 3 - Additional Features

---

*If you type 'n'*

Type 'c' to go back and CORRECT these parameters or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

*If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 8, typing 'q' leads to Screen 9.*

*Screen 8:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****  
You have 8 available ports on this system.
```

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 9.

### *Screen 9:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

### *Screen 10:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

# Chapter 3 - Additional Features

---

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

To configure certain parameters for a specific serial port.

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be ttyS<serial port number> :

```
config configure line <serial port number> tty <string>
```

To configure nfs\_data\_buffering:

```
config configure conf nfsdb <string>
```

To configure data\_buffering:

```
config configure line <serial port number> databuffering  
<number>
```

To configure DB\_mode:

```
config configure line <serial port number> dbmode <string>
```

To configure dont\_show\_DBmenu:

```
config configure line <serial port number> dbmenu <number>
```

To configure DB\_timestamp:

```
config configure line <serial port number> dbtimestamp  
<number>
```

To configure syslog\_buffering:

```
config configure line <serial port number> syslogdb <number>
```



**Tip.** You can configure all the parameters for a serial port in one line:

```
config configure line <serial port number> tty <string>
conf nfsdb <string> db <number> dbmode <string> dbmenu
<number> dbtimestamp <number> syslogdb <number>
```

## Step 2: Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## DHCP

The DHCP (Dynamic Host Configuration Protocol) Client is available for firmware versions 1.2.x and above. DHCP is a protocol that allows network administrators to assign IP addresses automatically to network devices. Without DHCP (or a similar protocol like BOOTP), each device would have to be manually configured. DHCP automatically sends a new IP address to a connected device when it is moved to another location on the network. DHCP uses the concept of a fixed time period during which the assigned IP address is valid for the device it was assigned for. This “lease” time can vary for each device. A short lease time can be used when there are more devices than available IP numbers. For more information, see RFC 2131.

### Parameter Involved and Passed Values

The DHCP client on the Ethernet Interface can be configured in two different ways, depending on the action the BLACK BOX® Advanced Console Server should take in case the DHCP Server does not answer the IP address request:

1. No action is taken and no IP address is assigned to the Ethernet Interface (most common configuration):
  - Set the global parameter `conf.dhcp_client` to 1.

# Chapter 3 - Additional Features

---

- Comment all other parameters related to the Ethernet Interface (`conf.eth_ip`, etc.).
  - Add the necessary options to the file `/etc/network/dhcpd_cmd` (some options are described below).
2. The BLACK BOX<sup>®</sup> Advanced Console Server restores the last IP address previously provided in another boot and assigns this IP address to the Ethernet Interface. For the very first time the unit is powered ON, the IP address restored is 192.168.160.10 in case of failure in the DHCP. The unit goes out from the factory with DHCP enabled (`conf.dhcp_client 2`):
- Set the global parameter `conf.dhcp_client` to 2.
  - Comment all other parameters related to the Ethernet Interface (`conf.eth_ip`, etc.).
  - Add the following lines to the file `/etc/config_files`:  

```
/etc/network/dhcpd_cmd
```

(from factory file already present in `/etc/config_files`)

```
/etc/dhcpd-eth0.save
```

(From the factory, the file is already present in `/etc/config_files`.)
  - Add the option “-x” to the factory default content of the file `/etc/network/dhcpd_cmd`:  

```
/sbin/dhcpd -l 3600 -x -c /sbin/handle_dhcp
```

From the factory, `/etc/network/dhcpd_cmd` already has such content.
  - Add all other necessary options to the file `/etc/network/dhcpd_cmd` (some options are described below). In both cases if the IP address of the BLACK BOX<sup>®</sup> Advanced Console Server or the default gateway are changed, the BLACK BOX<sup>®</sup> Advanced Console Server will adjust the routing table accordingly.

Two files are related to DHCP:

`/bin/handle_dhcp`

The script which is run by the DHCP client each time an IP address negotiation takes place.

---

---

`/etc/network/dhccpd_cmd` Contains a command that activates the DHCP client (used by the `cy_ras` program). Its factory contents are:

```
/bin/dhccpd -c /bin/handle_dhcp
```

The options available that can be used on this command line are:

- D** This option forces `dhccpd` to set the domain name of the host to the domain name parameter sent by the DHCP Server. The default option is to NOT set the domain name of the host to the domain name parameter sent by the DHCP Server.
- H** This option forces `dhccpd` to set the host name of the host to the hostname parameter sent by the DHCP Server. The default option is to NOT set the host name of the host to the hostname parameter sent by the DHCP Server.
- R** This option prevents `dhccpd` from replacing the existing `/etc/resolv.conf` file.



Note. Do not modify the `-c /bin/handle_dhcp` option.

## Configuration for CAS, TS, and Dial-in Access

### vi Method

Steps 1 and 2 under Parameters and Passed Values should be followed. You'll need to edit `/etc/portslave/pslave.conf`, comment some lines, etc.

### Browser Method

To configure DHCP via your Web browser:

Step 1: Point your browser to the Console Server.

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```



# Chapter 3 - Additional Features

---

**Step 2:** Log in as root and type the Web root password configured by the Web server.

This will take you to the Configuration and Administration page.

**Step 3:** Click the General link on the Link Panel.

This takes you to the General page.

**Step 4:** Scroll down to the Ethernet port section.

You can choose the DHCP Client option in this section. Select the radio button and click the Submit button at the bottom of the page.

Ethernet port	
Primary IP Address:	<input type="text" value="200.246.93.97"/>
Network Mask:	<input type="text" value="255.255.255.0"/>
Secondary IP Address:	<input type="text"/>
Network Mask:	<input type="text"/>
Common Configuration File Name:	<input type="text"/>
DHCP Client:	<input checked="" type="radio"/> inactive <input type="radio"/> active <input type="radio"/> act & restores last assigned
MTU:	<input type="text" value="1500"/>

*Figure 21: DHCP client section*

**Step 5:** Make the changes effective.

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 6:** Click on the link Administration > Load/Save Configuration.

**Step 7:** Click the Save Configuration to Flash button.

The configuration will be saved in flash.

## Dual Power Management


The BLACK BOX® Advanced Console Server comes with two power supplies which it can self-monitor. If either of them fails, two actions are performed: sounding a buzzer and generating a syslog message. This automanagement can be disabled (no actions are taken) or enabled (default), any time by issuing the commands:

```
signal_ras buzzer off
```

```
signal_ras buzzer on
```

To disable the buzzer in boot time, edit the shell script `/bin/ex_wdt_led.sh` and remove the keyword “buzzer.” The buzzer won’t sound if there is a power failure in any power supply. This parameter does not affect the behavior of the command “`signal_ras buzzer on/off`.” To make this change effective even after future reboots, create a line with “`/bin/ex_wdt_led.sh`” in `/etc/config_files`, save and quit that file and run `saveconf`.

### Parameters Involved and Passed Values



Note: This section applies only to the dual power supply model of the BLACK BOX® Advanced Console Server.

There are no parameters to be configured. However, if you want to generate alarms in case of a power failure, the `syslog-ng.conf` file must be changed. See the section [Generating Alarms](#).

### Configuration for CAS

vi Method

Files to be changed:

```
/etc/syslog-ng/syslog-ng.conf
```

Browser Method

Follow the steps described in the section “Generating Alarms.”

# Chapter 3 - Additional Features

---

## Configuration for TS

vi Method

Same as for CAS.

## Configuration for Dial-in Access

vi Method

Same as for CAS.

## Filters and Network Address Translation

The Filter feature is available for firmware version 2.1.0 and above; the Network Address Translation (NAT) feature is available for firmware version 2.1.1 and above.

### Description

IP filtering consists of blocking or not the passage of IP packets, based on rules which describe the characteristics of the packet, such as the contents of the IP header, the input/output interface, or the protocol. This feature is used mainly in firewall applications, which filter the packets which could crack the network system or generate unnecessary traffic in the network.

Network Address Translation (NAT) allows the IP packets to be translated from local network to global network, and vice-versa. This feature is particularly useful when there is demand for more IP addresses in the local network than available as global IP addresses. In the BLACK BOX® Advanced Console Server, this feature will be used mainly for clustering (one “Master” Console server works as the interface between the global network and the “slave” Console servers).

The BLACK BOX® Advanced Console Server uses the Linux utility *iptables* to set up, maintain and inspect both the filter and the NAT tables of IP packet rules in the Linux kernel. Besides filtering or translating packets, the *iptables* utility is able to count the packets which match a rule, and to create logs for specific rules.

### Structure of the iptables

The *iptables* are structured in three levels: table, chain, and rule. A table can contain several chains, and each chain can contain several rules.

#### Table

The table indicates how the *iptables* will work. There are currently three independent tables supported by the *iptables*, but only two will be used:

#### Chain

Each table contains a number of built-in chains and may also contain user-defined chains. The built-in chains will be called according to the type of packet. User-defined chains will be

# Chapter 3 - Additional Features

---

called when a rule which is matched by the packet points to the chain. Each table has a particular set of built-in chains:

for the *filter* table:

for the *nat* table:

Rule

Each chain has a sequence of rules. These rules contain:

When a chain is analyzed, the rules of this chain are reviewed one-by-one until the packet matches one rule. If no rule is found, the default action for that chain will be taken.

## Syntax

An iptables tutorial is beyond the scope of this manual. For more information on iptables, see the iptables man page (not included with the BLACK BOX® Advanced Console Server) or the how-to: <http://www.netfilter.org> or <http://www.iptables.org>

The syntax of the iptables command is:

```
iptables -command chain rule-specification [-t table] [options]
```

```
iptables -E old-chain-name new-chain-name
```

where:

# Filters and Network Address Translation

---

---

## Command

- table* Can be filter or nat. If the option *-t* is not specified, the filter table will be assumed.
- chain* Is one of the following:
- for filter table: INPUT, OUTPUT, FORWARD or a user-created chain.
  - for nat table: PREROUTING, OUTPUT, POSTROUTING or a user-created chain.

Only one command can be specified on the command line unless otherwise specified below. For all the long versions of the command and option names, you need to use only enough letters to ensure that iptables can differentiate it from all other options.

- A*  
*--append* Append one or more rules to the end of the selected chain. When the source and/or destination names resolve to more than one address, a rule will be added for each possible address combination.
- D*  
*--delete* Delete one or more rules from the selected chain. There are two versions of this command. The rule can be specified as a number in the chain (starting at 1 for the first rule) or as a rule to match.
- R*  
*--replace* Replace a rule in the selected chain. If the source and/or destination names resolve to multiple addresses, the command will fail. Rules are numbered starting at 1.
- I*  
*--insert* Insert one or more rules in the selected chain as the given rule number. Thus if the rule number is 1, the rule or rules are inserted at the head of the chain. This is also the default if no rule number is specified.
- L*  
*--list* List all rules in the selected chain. If no chain is selected, all chains are listed. It is legal to specify the *-Z* (zero) option as well, in which case the chain(s) will be atomically listed and zeroed. The exact output is affected by the other arguments given.
- F*  
*--flush* Flush the selected chain. This is equivalent to deleting all the rules one-by-one.

# Chapter 3 - Additional Features

---

- Z*                      Zero the packet and byte counters in all chains. It is legal to specify the *-L*, *--list* (list) option as well, to see the counters immediately before they are cleared. (See above.)
- zero*
- N*                      New chain. Create a new user-defined chain by the given name. There must be no target of that name already.
- new-chain*
- X*                      Delete the specified user-defined chain. There must be no references to the chain. If there are, you must delete or replace the referring rules before the chain can be deleted. If no argument is given, it will attempt to delete every non-built-in chain in the table.
- delete-chain*
- P*                      Set the policy for the chain to the given target. Only non-user-defined chains can have policies, and neither built-in nor user-defined chains can be policy targets.
- policy*
- E*                      Rename the user-specified chain to the user-supplied name. This is cosmetic, and has no effect on the structure of the table.
- rename-chain*
- h*                      Help. Gives a (currently very brief) description of the command syntax.
- help*

# Filters and Network Address Translation

---

---

## Rule Specification Options

- p*    `--protocol[!]protocol`  
The protocol of the rule or of the packet to check. The specified protocol can be one of `tcp`, `udp`, `icmp`, or `all`, or it can be a numeric value, representing one of these protocols or a different one. A protocol name from `/etc/protocols` is also allowed. A `!"` argument before the protocol inverts the test. The number zero is equivalent to `all`. Protocol `all` will match with all protocols and is taken as default when this option is omitted.
- s*    `--source[!]address[/mask]`  
Source specification. Address can be either a hostname, a network name, or a plain IP address. The mask can be either a network mask or a plain number, specifying the number of 1's at the left side of the network mask. Thus, a mask of 24 is equivalent to `255.255.255.0`. A `!"` argument before the address specification inverts the sense of the address. The flag `--src` is a convenient alias for this option.
- d*    `--destination[!]address[/mask]`  
Destination specification. See the description of the `-s` (source) flag for a detailed description of the syntax. The flag `--dst` is an alias for this option.
- j*    `--jump target`  
This specifies the target of the rule; i.e., what to do if the packet matches it. The target can be a user-defined chain (other than the one this rule is in), one of the special built-in targets which decide the fate of the packet immediately, or an extension (see `EXTENSIONS` below). If this option is omitted in a rule, then matching the rule will have no effect on the packet's fate, but the counters on the rule will be incremented. The special built-in targets are :
- `ACCEPT` means to let the packet through.
  - `DROP` means to drop the packet on the floor.
  - `QUEUE` means to pass the packet to userspace (if supported by the kernel).
  - `RETURN` means stop traversing this chain and resume at the next rule in the previous (calling) chain. If the end of a built-in chain is reached or a rule in a built-in chain with target `RETURN` is matched, the target specified by the chain policy determines the fate of the packet.

The following additional options can be specified:



# Chapter 3 - Additional Features

---

## Match Extensions

- i** -in-interface[!][name]  
Optional name of an interface via which a packet is received (for packets entering the INPUT and FORWARD chains). When the "!" argument is used before the interface name, the sense is inverted. If the interface name ends in a "+" then any interface which begins with this name will match. If this option is omitted, the string "+" is assumed, which will match with any interface name.
- o** -out-interface[!][name]  
Optional name of an interface via which a packet is going to be sent (for packets entering the FORWARD and OUTPUT chains). When the "!" argument is used before the interface name, the sense is inverted. If the interface name ends in a "+" then any interface which begins with this name will match. If this option is omitted, the string "+" is assumed, which will match with any interface name.
- [!]** -f -fragment  
This means that the rule only refers to second and further fragments of fragmented packets. Since there is no way to tell the source or destination ports of such a packet (or ICMP type), such a packet will not match any rules which specify them. When the "!" argument precedes the "-f" flag, the rule will only match head fragments, or unfragmented packets.
- c** -set-counters PKTS BYTES  
This enables the administrator to initialize the packet and byte counters of a rule (during INSERT, APPEND, REPLACE operations).
- v** -verbose  
Verbose output. This option makes the list command show the interface address, the rule options (if any), and the TOS masks. The packet and byte counters are also listed, with the suffix 'K', 'M' or 'G' for 1000, 1,000,000 and 1,000,000,000 multipliers respectively (but see the -x flag to change this). For appending, insertion, deletion and replacement, this causes detailed information on the rule or rules to be printed.
- n** -numeric  
Numeric output. IP addresses and port numbers will be printed in numeric format. By default, the program will try to display them as host names, network names, or services (whenever applicable).

# Filters and Network Address Translation

---

---

- x**            **- -exact**  
Expand numbers. Display the exact value of the packet and byte counters, instead of only the rounded number in K's (multiples of 1000) M's (multiples of 1000K) or G's (multiples of 1000M). This option is only relevant for the **-L** command.
- -line-numbers**        When listing rules, add line numbers to the beginning of each rule, corresponding to that rule's position in the chain.

Iptables can use extended packet matching modules. These are loaded in two ways: implicitly, when **-p** or **- -protocol** is specified, or with the **-m** or **- -match** option, followed by the matching module name; after these, various extra command line options become available, depending on the specific module.

## TCP Extension

These extensions are loaded if the protocol specified is **tcp** or **"-m tcp"** is specified. It provides the following options:

- -source-port [!] [port[:port]]**        Source port or port range specification. This can either be a service name or a port number. Inclusive range can also be specified, using the format **port:port**. If the first port is omitted, "0" is assumed; if the last is omitted, "65535" is assumed. If the second port is greater than the first they will be swapped. The flag **- -sport** is an alias for this option.
- -destination-port [!] [port[:port]]**    Destination port or port range specification. The flag **- -dport** is an alias for this option.
- -tcp-flags [!] mask comp**            Match when the TCP flags are as specified. The first argument is the flags which we should examine, written as a comma-separated list, and the second argument is a comma-separated list of flags which must be set. Flags are: **SYN ACK FIN RST URG PSH ALL NONE**. Hence the command **iptables -A FORWARD -p tcp - -tcp-flags SYN,ACK,FIN,RST SYN** will only match packets with the **SYN** flag set, and the **ACK**, **FIN** and **RST** flags unset.

# Chapter 3 - Additional Features

---

[!] -syn                      Only match TCP packets with the SYN bit set and the ACK and FIN bits cleared. Such packets are used to request TCP connection initiation; for example, blocking such packets coming in an interface will prevent incoming TCP connections, but outgoing TCP connections will be unaffected. It is equivalent to -tcp-flags SYN,RST,ACK SYN.  
If the "!" flag precedes the "-syn," the sense of the option is inverted.

--tcp-option [!] number                      Match if TCP option set.

## UDP Extension

These extensions are loaded if the protocol udp is specified or “-m udp” is specified. It provides the following options:

## ICMP Extension

--source-port [!] [port[:port]]                      Source port or port range specification. See the description of the --source-port option of the TCP extension for details.

--destination-port [!] [port[:port]]                      Destination port or port range specification. See the description of the --destination-port option of the TCP extension for details.

This extension is loaded if the protocol icmp is specified or “-m icmp” is specified. It provides the following option:

--icmp-type [!] *typename*                      This allows specification of the ICMP type, which can be a numeric ICMP type, or one of the ICMP type names shown by the command *iptables -p icmp -h*

## Multiport Extension

This module matches a set of source or destination ports. Up to 15 ports can be specified. It can only be used in conjunction with -m tcp or -m udp.

# Filters and Network Address Translation

---

---

## Target Extensions

- `--source-port [port[,port]]` Match if the source port is one of the given ports.
- `--destination-port [port[,port]]` Match if the destination port is one of the given ports.
- `--port [port[,port]]` Match if the both the source and destination port are equal to each other and to one of the given ports.

Iptables can use extended target modules. The following are included in the standard distribution.

## LOG

Turn on kernel logging of matching packets. When this option is set for a rule, the Linux kernel will print some information on all matching packets (like most IP header fields) via the kernel log (where it can be read with `syslog-ng`).

## REJECT (filter table only)

- `--log-level level` Level of logging (numeric or see `syslog.conf(5)`).
- `--log-prefix prefix` Prefix log messages with the specified prefix; up to 29 letters long, and useful for distinguishing messages in the logs.
- `--log-tcp-sequence` Log TCP sequence numbers. This is a security risk if the log is readable by users.
- `--log-tcp-options` Log options from the TCP packet header.
- `--log-ip-options` Log options from the IP packet header.

This is used to send back an error packet in response to the matched packet: otherwise it is equivalent to `DROP`. This target is only valid in the `INPUT`, `FORWARD` and `OUTPUT` chains, and user-defined chains which are only called from those chains. Several options control the nature of the error packet returned:

## SNAT (nat table only)

This target is only valid in the `nat` table, in the `POSTROUTING` chain. It specifies that the source address of the packet should be modified (and all future packets in this connection will also be mangled), and rules should cease being examined. It takes one option:

# Chapter 3 - Additional Features

---

## DNAT (nat table only)

- `--to-source <ipaddr>[-<ipaddr>][:port-port]` This can specify a single new source IP address, an inclusive range of IP addresses, and optionally, a port range (which is only valid if the rule also specifies `-p tcp` or `-p udp`). If no port range is specified, then source ports below 1024 will be mapped to other ports below 1024: those between 1024 and 1023 inclusive will be mapped to ports below 1024, and other ports will be mapped to 1024 or above. Where possible, no port alteration will occur.

This target is only valid in the nat table, in the PREROUTING and OUTPUT chains, and user-defined chains which are only called from those chains. It specifies that the destination address of the packet should be modified (and all future packets in this connection will also be mangled), and rules should cease being examined. It takes one option:

## MASQUERADE (nat table only)

This target is only valid in the nat table, in the POSTROUTING chain. It should only be used with dynamically assigned IP (dialup) connections: if you have a static IP address, you should use the SNAT target. Masquerading is equivalent to specifying a mapping to the IP address of the interface the packet is going out on, but also has the effect that connections are forgotten when the interface goes down. This is the correct behavior when the next dialup is unlikely to have the same interface address (and hence any established connections are lost anyway). It takes one option:

## REDIRECT (nat table only)

- `--to-ports <port>[-<port>]` This specifies a range of source ports to use, overriding the default SNAT source port-selection heuristics (see above). This is only valid with if the rule also specifies `-p tcp` or `-p udp`.

This target is only valid in the nat table, in the PREROUTING and OUTPUT chains, and user-defined chains which are only called from those chains. It alters the destination IP address to

# Filters and Network Address Translation

---

---

send the packet to the machine itself (locally-generated packets are mapped to the 127.0.0.1 address). It takes one option:

## Parameters Involved and Passed Values

The file with the iptables rules is `/etc/network/firewall`. The `fwset` script saves the iptables rules in the file `/etc/network/firewall` (command `iptables-save > /etc/network/firewall`) and then save the file in the flash memory. The `fwset restore` restores the iptables rules previously saved in `/etc/network/firewall` file (command `iptables-restore </etc/network/firewall`). This command is executed at boot to invoke the last configuration saved.

## Configuration for CAS, TS, and Dial-in Access

vi method

**Step 1: Execute `fwset restore`.**

This script will restore the IP Tables chains and rules configured in the `/etc/network/firewall` file. This script can be called in the process, whenever the user wants to restore the original configuration.

**Step 2: Add the chains and rules using the command line.**

See details of the iptables syntax earlier in this chapter.

**Step 3: Execute `iptables-save > /etc/network/firewall`.**

This program will save all the rules and chains of all the tables in the `/etc/network/firewall` file.

**Step 4: Execute `updatefiles /etc/network/firewall`.**

This program will save the configuration to the flash memory.

Browser method

**Step 1: Point the browser to the Console Server.**

In the Address or Location field of your browser type the IP Address or the alias of your console server.

**Step 2: Log in.**


Log in as root, and type the password configured for the root user. This will take you to the Configuration and Administration page.

# Chapter 3 - Additional Features

Step 3: Select the IPTables link.

On the Configuration section of this page, select the IPTables link. The following page will appear.

Figure 22: First IP Tables page



The options in this page are:

- List Chains** List all the chains of the table selected.
- Save in File** Save the all the IP tables rules, chains and tables to the file /etc/network/firewall.
- Restore from File** Reads the file /etc/network/firewall and make the IP Tables configuration from that file effective.

Step 4: Select the filter table. Click the List Table button.

A table with all the chains of the table, and the number of bytes/packets which used each chain will appear. The available options are:




Figure 23: IP Tables Chains Table (table filter)

## Filters and Network Address Translation

---

---

### Step 5: Edit the chain list

If the user needs to define new chains, write in the Chain Name text input and click the Insert Chain button. If the default policy for a chain needs to be changed, select the chain and click the Edit Chain button. Select the new policy and click Submit.

### Step 6: Choose one of the chains and click the List Rules button.

A table with all the rules related to the chain selected will appear in the page, containing the rule configuration and the accounting (number of bytes and packets which used the rule). In the beginning, there are no rules in the chain: in this case, the only option is to Append Rule.

When there are rules in the chain, the page will appear like the picture below. The options are:

*Figure 24: IP Tables Rules Table (table: filter; chain: INPUT)*

### Step 7: Click the button Append Rule to start.

The page which follows is for configuring the rule. There are several parameters related to a rule:



# Chapter 3 - Additional Features

Figure 25: IP Tables Append Rule (table: filter, chain: INPUT)

IP Tables Append Rule (table: filter, chain: INPUT)	
General	
Target:	ACCEPT <input type="button" value="v"/>
Source IP:	<input type="text"/> Mask: <input type="text"/> <input type="checkbox"/> inverted
Destination IP:	<input type="text"/> Mask: <input type="text"/> <input type="checkbox"/> inverted
Protocol:	all <input type="button" value="v"/> <input type="checkbox"/> inverted
Input Interface:	<input type="text"/> <input type="checkbox"/> inverted
Fragments:	all packets <input type="button" value="v"/>



Note: For many parameters, there is a checkbox called *inverted*. Checking this box will invert the sense of the parameter.

## Target

Indicates the action to be performed when the IP packet matches the rule. The kernel can ACCEPT the packet, DROP it, LOG it, REJECT it by sending a message, translating the source or the destination IP address/port (in the nat table) or send the packet to another user-defined chain. All the options are in the target list.

## Source/Destination IP

Indicates how the source/destination IP address should be. When a network should be included in the rule, the network mask must be configured too.

## Input/Output interface

Indicates the interface where the IP packet should pass. The Input Interface option will appear only for the chains INPUT, FORWARD and PREROUTING; the Output interface option will appear for the chains FORWARD, OUTPUT and POSTROUTING.

# Filters and Network Address Translation

---

---

<i>Protocol</i>	Indicates the transport protocol to check. If the numeric value is available, select numeric and type the value in the text input; otherwise, select one of the other options.
<i>Fragments</i>	Indicates if the fragments will be checked. The IP Tables can either check for head fragments and unfragmented packets or for the subsequent fragments.
<i>TCP options</i>	This section will appear only when TCP protocol is selected. The source/destination ports can be configured in this section, as well as the TCP flags.
<i>UDP options</i>	This section will appear only when UDP protocol is selected. The source/destination ports can be configured in this section.
<i>ICMP options</i>	This section will appear only when ICMP protocol is selected. The ICMP type can be configured in this section.
<i>LOG options</i>	This section will appear only when the target selected is LOG. It contains parameters to set the way the logs will appear (syslog level, prefix, flags).
<i>REJECT options</i>	This section will appear only when the target selected is REJECT. It indicates what message the filter will send when the IP packet is rejected.

**Step 8:** Configure the rule and click the Submit button.

If there is an error in the configuration, a red message will appear with the page; otherwise, the rule will be included in the chain rules list.

**Step 9:** Repeat steps 7 and 8 to add as many rules as necessary.

**Step 10:** Click on the link [\[IP Tables Chains Table\]](#) if there are rules to be added in other chains.

Repeat steps 6 to 8 to add rules for other chains.

# Chapter 3 - Additional Features

---

Step 11: Click on the link [\[IP Tables\]](#) if the nat table must be edited.

Select the nat table and click on the List Chains button. Repeat steps 5 to 8 to edit the chains and rules in the nat table. The tables presented on the Web page are the same as in the filter table, with the difference that there are more options in the Append/Insert/Replace Rule page:

## *DNAT/SNAT options*

This section will appear only when the target selected is DNAT and SNAT, respectively. The parameters of these sections will determine how the packets matched by the rule will be translated. DNAT translates the destination IP Address/Port, and SNAT translates the source IP Address/Port.

## *MASQUERADE/REDIRECT options*

This section will appear only when the target selected is MASQUERADE or REDIRECT. The parameter of these sections configure the port or the port range used to masquerade the source or to redirect the destination, respectively.

Step 12: Click on the link [\[IP Tables\]](#) and click on the Save to File button.

This will cause the rules and chains to be saved in the `/etc/network/firewall` file.

Step 13: Click on the link Administration > Load/Save Configuration and click the Save to Flash button.

This will save the rules and chains in the flash memory.

## Generating Alarms

This feature helps the administrator to manage the servers. It filters the messages received by the serial port (the server's console) based on the contents of the messages. It then performs an action, such as sending an email or pager message. To configure this feature, you need to configure filters and actions in the `syslog-ng.conf` file. (You can read more about `syslog-ng` in the Syslog section.)

### Port Slave Parameters Involved with Generating Alarms

- |                         |   |
|-------------------------|---|
| <i>conf.DB_facility</i> | This value (0-7) is the Local facility sent to the <code>syslog-ng</code> with data when <code>syslog_buffering</code> and/or alarm is active.                    |
| <i>all.alarm</i>        | When nonzero, all data received from the port is captured and sent to <code>syslog-ng</code> with INFO level and <code>LOCAL[0+conf.DB_facility]</code> facility. |

### Configuration for CAS, TS, and Dial-in Access

vi Method

Files to be modified:

- `pslave.conf`
- `syslog-ng.conf`

Browser Method

To configure PortSlave parameters involved with `syslog-ng` and the `syslog-ng` configuration file with your browser:

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

# Chapter 3 - Additional Features

---

**Step 3: Select the General link.**

Click on the General link on the Link Panel to the left of the page in the Configuration section. This will take you to the General page.

**Step 4: Scroll down to the Data Buffering section.**

You can change the Data Buffering Facility value (conf.DB\_facility). Click the Submit button.

**Step 5: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page in the Configuration section. This will take you to the Port Selection page.

**Step 6: Select port(s).**

On the Port Selection page, choose all ports or an individual port to configure from the dropdown menu. Click the Submit button. This will take you to the Serial Port Configuration page.

**Step 7: Scroll down to the Data Buffering section.**

You can change the "Alarm for Data Buffering" (.alarm) value. Click the Submit button.

**Step 8: Select the Syslog link.**

Click on the Syslog link on the Link Panel to the left of the page in the Configuration section. This will take you to the Edit the Syslog-ng Configuration File page.

**Step 9: Make the changes effective.**

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 10: Click on the link Administration > Load/Save Configuration.**

**Step 11: Click the Save Configuration to Flash button.**

The configuration was saved in flash.

## Wizard Method

The Alarm Generation custom wizard configures the ALL.ALARM parameter.

### Step 1: Bring up the wizard.

At the command prompt, type the following to bring up the Alarm Generation custom wizard:

```
wiz --al
```

Screen 1 (below) will appear.

#### *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

```
ALL.ALARM - When non zero, all data received from the port  
are captured and sent to syslog-ng with INFO level and  
LOCAL[0+conf.DB_facility] facility. The syslog-ng.conf  
file should be set accordingly, for the syslog-ng to take  
some action.
```

```
(Please see the 'Syslog-ng Configuration to use with Alarm  
Feature' section under Generating Alarms in Chapter 3 of  
the system's manual for the syslog-ng configuration file.)
```

```
all.alarm[0] :
```

# Chapter 3 - Additional Features

---

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.alarm : 0
```

```
Set to defaults? (y/n) [n] :
```

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.ALARM - When non zero, all data received from the port are captured and sent to syslog-ng with DAEMON facility and ALERT level. The syslog-ng.conf file should be set accordingly, for the syslog-ng to take some action.

(Please see the 'Syslog-ng Configuration to use with Alarm Feature' section under Generating Alarms in Chapter 3 of the system's manual for the syslog-ng configuration file.)

```
all.alarm[0] :
```



**Note:** conf.DB\_facility is configured under the syslog parameters (wiz - - sl).

## *Screen 4:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

all.alarm : 0

Are these configuration(s) all correct? (y/n) [n] :

### *If you type 'n'*

Type 'c' to go back and CORRECT these parameters or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

### *If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 5, typing 'q' leads to Screen 6.*



# Chapter 3 - Additional Features

---

## *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You have 8 available ports on this system.

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 6.

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## Screen 7:

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

### To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be tty<serial port number> :

```
config configure line <serial port number> tty <string>
```

To configure conf.DB\_facility:

```
config configure conf dbfacility <number>
```

To configure alarm:

```
config configure line <serial port number> alarm <number>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
alarm <number>
```

# Chapter 3 - Additional Features

---

## Step 2: Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## Syslog-ng Configuration to use with Alarm Feature

This configuration example is used for the alarm feature.

### Step 1: Configure the pslave.conf file parameter.

In the pslave.conf file the parameters of the alarm feature are configured as:

```
all.alarm 1
conf.DB_facility 2
```

### Step 2: Add lines to syslog-ng.conf.

The syslog-ng.conf file needs these lines:

```
# local syslog clients
source sysl { unix-stream("/dev/log"); };
# To filter ALARM message with the string "kernel panic" :
filter f_kpanic {facility(local2) and level(info) and
match("ALARM") and match("kernel panic"); };
# To filter ALARM message with the string "root login" :
filter f_root { facility(local2) and level(info) and
match("ALARM") and match("root login"); };
# To send e-mail to z@none.com (SMTP's IP address 10.0.0.2)
# from the e-mail address a@none.com with subject "ALARM".
# The message will carry the current date, the hostname
```

## Generating Alarms

---

```
# of this unit and the message that was received from the
source.

destination d_maill {

    pipe("/dev/cyc_alarm"

        template("sendmail -t z@none.com -f a@none.com -s
\"ALARM\" -m \"\$FULLDATE \$HOST \$MSG\" -h 10.0.0.2"));

    };

# Example to send a pager to phone number 123 (Pager server
at 10.0.0.1) with message

# carrying the current date, the hostname of this BLACK BOX ®
Advanced Console Server and the message that was received
from the source :

destination d_pager {

    pipe("/dev/cyc_alarm"

        template("sendsms -d 123 -m \"\$FULLDATE \$HOST \$MSG\"
10.0.0.1"));

    };

# Example to send a Link Down trap to server at 10.0.0.1 with
message carrying the current

# date, the hostname of this unit and the message that
received from the source :

destination d_trap {

    pipe("/dev/cyc_alarm"

        template("snmptrap -v 1 -c public 10.0.0.1 \"\" \"\" 2 0 \"\"
\
.1.3.6.1.2.1.2.2.1.2.1 s \"\$FULLDATE \$HOST \$MSG\" ");

    };

# To send e-mail and snmptrap if message received from local
syslog client has the string "kernel panic" :
```

# Chapter 3 - Additional Features

---

```
log { source(sysl); filter(f_kpanic); destination(d_mail1);
destination(d_trap); };

# To send e-mail and pager if message received from local
syslog client has the string

# "root login":

log { source(sysl); filter(f_root); destination(d_mail1);
destination(d_pager); };
```

## Alarm, Sendmail, Sendsms and Snpmptrap

### Alarm

**This feature is available only for the Console Server Application. The BLACK BOX<sup>®</sup> Advanced Console Server sends messages using pager, e-mail, or snmptrap if the serial port receives messages with specific string. To configure this feature:**

**Step 1: Activate alarm in Portslave configuration file.**

Parameter `all.alarm` - 0 inactive or `<> 0` active.

**Step 2: Configure filters in the syslog-ng configuration file.**

```
filter f_alarm { facility(local[0+conf.DB_facility]) and
level(info) and match("ALARM") and match("<your string>"); }
;
```

**Example: to filter the ALARM message with the string "kernel panic" (conf.DB\_facility is configured with value 1):**

```
filter f_kpanic {facility(local1) and level(info) and
match("ALARM") and match ("kernel panic"); };
```

**Example: to filter the ALARM message with the string "root login" :**

```
filter f_root { facility(local1) and level(info) and
match("ALARM") and match("root login"); };
```

**Step 3: Configure actions in the syslog-ng configuration file.**

(See more details in syslog-ng examples.)

**Example: alarm is active and if the serial port receives the string "kernel panic," one message will be sent to the pager.**

```
log (source(sysl); filter(f_kpanic); destination(d_pager);  
};
```

### To send e-mail:

```
destination d_mail { pipe("/dev/cyc_alarm" template("send-  
mail <pars>")); };
```

### To send a pager message:

```
destination d_pager {pipe("/dev/cyc_alarm" template("sendsms  
<pars>")); };
```

### To send snmptrap:

```
destination d_trap {pipe("/dev/cyc_alarm" template("snmptrap  
<pars>")); };
```

## Step 4: Connect filters and actions in the syslog-ng configuration file.

**Example:** alarm is active and if the serial port receives the string "kernel panic," one message will be sent to the pager.

```
log (source(sysl); filter(f_kpanic); destination(d_trap);  
destination(d_pager); );
```

## Sendmail

Sendmail sends a message to a SMTP server. It is not intended as a user interface routine; it is used only to send pre-formatted messages. Sendmail reads all parameters in the command line. If the SMTP server does not answer the SMTP protocol requests sent by sendmail, the message is dropped.

# Chapter 3 - Additional Features

---

## *Synopsis:*

```
sendmail -t <name>[,<name>] [-c <name> [,<name>]] [-b <name>
[,<name>]] [-r <name>] -f <name> -s <text> -m <text> -h <SMTP
server> [-p <smtp-port>]
```

where:

<i>-t &lt;name&gt;[,&lt;name&gt;]</i>	“To:” Required. Multi-part allowed (multiple names are separated by commas). Names are expanded as explained below.
<i>[-c &lt;name&gt; [,&lt;name&gt;]]</i>	“Cc:” Optional. Multi-part allowed (multiple names are separated by commas).
<i>[-b &lt;name&gt; [,&lt;name&gt;]]</i>	“Bcc:” Optional. Multi-part allowed (multiple names are separated by commas).
<i>[-r &lt;name&gt; ]</i>	“Reply-To:” Optional. Use the Reply-To: field to make sure the destination user can send a reply to a regular mailbox.
<i>-f &lt;name&gt;</i>	“From:” Required.
<i>-s &lt;text&gt;</i>	“Subject:” Required.
<i>-m &lt;text&gt;</i>	“body” The message body.
<i>-h &lt;SMTP server&gt;</i>	Required. IP address or name of the SMTP server.
<i>[-p &lt;SMTP port&gt;</i>	Optional. The port number used in the connection with the server. Default: 25.
<i>&lt;name&gt;</i>	Any email address.
<i>&lt;text&gt;</i>	A text field. As this kind of field can contain blank spaces, please use the quotation marks to enclose the text.

For example, to send e-mail to z@none.com (SMTP's IP address 10.0.0.2) from the e-mail address a@none.com with subject “sendmail test.”

```
sendmail -t z@none.com -f a@none.com -s "sendmail test" -m "Send-
mail test. \n Is it OK???" -h 10.0.0.2
```

## Sendsms

The `sendsms` is the Linux command line client for the SMSLink project. It accepts command line parameters that define the message to be sent, and transmits them to the SMS server process running on the designated server. The `sendsms` was developed specifically for easy calling from shell scripts or similar situations.

### *Synopsis:*

```
sendsms [-r] [-g] [-v] -d dest (-m message or -f msgfile)
[-u user] [-p port] server
```

where:

- r** Reporting. Additional info will be included in the message printed on stderr (namely, the device name used by the server to send the SMS out, and the message ID attributed to the SMS by the module's SIM card). If any of these items is missing or can't be parsed, a value of "???" will be returned.
- g** Turns debugging on. Will output the entire dialog with the server on stderr (and more).
- h** Displays a short help message and exits.
- v** Displays version information and exits.
- d dest** Required. The GSM network address (i.e. phone number) of the mobile phone the message is to be sent to. Supported format is: [int. prefix - country code] area code - phone number. The international prefix can be either "+" or "00" (or any other value supported by the GSM network provider the server is subscribed to). Some separation characters can be used to beautify the number, but they are purely cosmetic and will be stripped by the server. Those characters are [./- ]. The pause character (',') is not supported. Regarding the international country code, don't forget that its necessity is to be considered respective to the SMS gateway location (the host this client program is connecting to), not the location where the client is run from.



# Chapter 3 - Additional Features

---

- d dest (cont.)* If there are any doubts, please contact the SMS server administrator for your network. Please always include the area code (even when sending to a destination in the same “area”, i.e., on the same network). The number without the area code, though syntactically correct and accepted by the network, may never get delivered.
- m message* Required (Use one and only one of “-m” or “-f”). The text of the message to be sent. Unless made up of a single word, it will have to be quoted for obvious reasons. Maximum length is 160 characters. A longer message will be truncated (you will be warned about it), but the message will still be sent. At the present time, only 7-bit ASCII is supported for the message text.
- f msgfile* Required (use one and only one of “-m” or “-f”). The name of a text file where the message to send is to be read from. This file can contain multiple lines of text (they will be concatenated), but its total length can't exceed 160 characters. A longer text will be truncated (you will be warned about it), but the message will still be sent. The special file '-' means that input will be read from stdin. At the present time, only 7-bit ASCII is supported for the message text.
- u user* Optional. The server module requires the user to identify her/himself for logging purposes. No authentication is performed on this information, however. If this parameter is omitted, sendsms will send the UNIX username of the current user. This parameter allows you to override this default behavior (might be useful in the case of automated sending).
- p port* Optional. Communication port on the target server. If provided here, this value will be used to connect to the server. If omitted, the client will query the local system for the port number associated with the “well known service” sms (as defined in /etc/services). If that doesn't return an answer, the compiled-in default value 6701 will be used.

*server*

Required. The host name or IP address of the computer where the SMS gateway server process is running. By default, this server will be listening on TCP port 6701.

Upon success (when the server module reports that the message was successfully sent), `sendsms` returns 0. When a problem occurs, a non zero value is returned. Different return values indicate different problems. A return value of 1 indicates a general failure of the client program.

COPYRIGHT: SMSLink is (c) Les Ateliers du Heron, 1998 by Philippe Andersson.

Example to send a pager message to phone number 123 (Pager server at 10.0.0.1) with message:

```
sendsms -d 123 -m "Hi. This is a test message send from BLACK BOX ®  
Advanced Console Server using sendsms" 10.0.0.1
```

## *Snmpttrap*

`Snmpttrap` is an SNMP application that uses the TRAP-PDU Request to send information to a network manager. One or more fully qualified object identifiers can be given as arguments on the command line. A type and a value must accompany each object identifier. Each variable name is given in the format specified. If any of the required version 1 parameters—enterprise-oid, agent and uptime—are specified as empty, it defaults to “.1.3.6.1.4.1.3.1.1”, hostname, and host-uptime respectively.

## *Synopsis*

```
snmptrap -v 1 [-Ci] [common arguments] enterprise-oid agent  
generic-trap specific-trap uptime [objectID type value]...
```

```
snmptrap -v [2c|3] [-Ci] [common arguments] uptime trap-oid  
[objectID type value]...
```

# Chapter 3 - Additional Features

---

where:

<i>-Ci</i>	Optional. It sends INFORM-PDU.
<i>common arguments</i>	Required. They are: "-c <community name> <SNMP server IP address>"
<i>enterprise-oid</i>	Required, but it can be empty (").
<i>agent</i>	Required, but it can be empty ("). The agent name.
<i>generic-trap</i>	The generic trap number: 2 (link down), 3 (link up), 4 (authentication failure), ...
<i>specific-trap</i>	Required. The specific trap number.
<i>uptime</i>	Required.
<i>[objectID type value]</i>	Optional. objectID is the object oid. You want to inform its value to server.

If the network entity has an error processing the request packet, an error packet will be returned and a message will be shown, helping to pinpoint in what way the request was malformed. If there were other variables in the request, the request will be resent without the bad variable.

For example, to send a Link Down trap to server at 10.0.0.1 with interfaces.iftable.ifentry.ifde-scr:

```
snmptrap -v 1 -c public 10.0.0.1 "" 2 0 "" .1.3.6.1.2.1.2.2.1.2.1
s "BLACK BOX ® Advanced Console Server: serial port number 1 is
down"
```

<i>-Ci</i>	Optional. It sends INFORM-PDU.
<i>common arguments</i>	Required. They are: SNMP server IP address and community.
<i>enterprise-oid</i>	Required, but it can be empty (").


---



---

**Help**
Help Wizard Information

Synopsis: `wiz [--OPTIONS] [--port <port number>]`



Note: To directly configure a feature for a specific serial port, use the "-port <port number>" option after "wiz -[option]."



Note: Make sure there are two hyphens before any of the options listed on the following table.

Table 10: General Options for the Help Wizard

Option	Description
<i>ac</i> <cas or ts>	Configuration of access method parameters
<i>al</i>	Configuration of alarm parameter
<i>all</i> <cas or ts>	Configuration of all parameters
<i>auth</i>	Configuration of authentication parameters
<i>db</i>	Configuration of data buffering parameters
<i>help</i>	Print this help message
<i>pm</i>	Configuration of power management parameters.

# Chapter 3 - Additional Features

Table 10: General Options for the Help Wizard

Option	Description
<i>sl</i>	Configuration of syslog parameters
<i>snf</i>	Configuration of sniffing parameters
<i>sset</i> < <i>cas</i> or <i>ts</i> >	Configuration of serial setting parameters
<i>tl</i>	Configuration of terminal login display parameters
<i>tso</i>	Configuration of other parameters specific to the TS profile

Step 1: Bring up the wizard.

At the command prompt, type the following to bring up the Help custom wizard (you can also type `wiz -h`):

```
wiz --help
```

## Help Command Line Interface Information



**Note:** To enter into CLI mode, type `config` at the terminal prompt. You will then get a CLI prompt similar to `config@hostname>>`. Once in CLI mode, you eliminate the need to type `config` at the beginning of your CLI commands. To exit from this mode, type `exit` or `quit`.

### Synopsis 1 - Configuration of Port Specific Parameters

```
config configure line [serial port number] [options]
```

or in CLI mode:

```
configure line [serial port number] [options]
```

The following table shows Help CLI Options and the actual parameter modified for Synopsis 1.

Table 11: Help CLI Options - Synopsis 1

Option	Actual Parameter Modified
<i>accthost1</i> <string>	accthost1
<i>accthost2</i> <string>	accthost2
<i>adminusers</i> <string>	admin_users
<i>alarm</i> <number>	alarm
<i>authhost1</i> <string>	authhost1
<i>authhost2</i> <string>	authhost2
<i>authtype</i> <string>	authtype
<i>auto_input</i> <string>	auto_answer_input
<i>auto_output</i> <string>	auto_answer_output
<i>break</i> <string>	break_sequence
<i>datasize</i> <number>	datasize
<i>atabuffering</i> <number>	data_buffering
<i>dbmenu</i> <number>	dont_show_DBmenu
<i>dbmode</i> <string>	DB_mode
<i>dbtimestamp</i> <number>	DB_timestamp
<i>dcd</i> <number>	dcd
<i>dtr_reset</i> <number>	DTR_reset
<i>escape</i> <string>	escape_char
<i>flow</i> <string>	flow
<i>host</i> <string>	host
<i>idletimeout</i> <number>	idletimeout

# Chapter 3 - Additional Features

Table 11: Help CLI Options - Synopsis 1

Option	Actual Parameter Modified
<i>ipno</i> <string>	ipno
<i>issue</i> <string>	issue
<i>lf</i> <number>	lf_suppress
<i>modbus</i> <string>	modbus_smode
<i>multipleless</i> <string>	multiple_sessions
<i>parity</i> <string>	parity
<i>pmkey</i> <string>	pmkey
<i>pmnumofoutlets</i> <number>	pmNumOfOutlets
<i>pmoutlet</i> <string>	pmoutlet
<i>pmtype</i> <string>	pmtype
<i>pmusers</i> <string>	pmusers
<i>pollinterval</i> <number>	poll_interval
<i>prompt</i> <string>	prompt
<i>protocol</i> <string>	protocol
<i>retries</i> <number>	timeout
<i>secret</i> <string>	secret
<i>sniffmode</i> <string>	sniff_mode
<i>socket</i> <number>	socket_port
<i>speed</i> <number>	speed
<i>stopbits</i> <number>	stopbits
<i>sttycmd</i> <string>	sttyCmd
<i>syslogdb</i> <number>	syslog_buffering

Table 11: Help CLI Options - Synopsis 1

Option	Actual Parameter Modified
<i>syslogsess</i> <number>	syslog_sess
<i>telnetclientmode</i> <number>	telnet_client_mode
<i>term</i> <string>	term
<i>timeout</i> <number>	timeout
<i>tty</i> <string>	tty
<i>txinterval</i> <number>	tx_interval
<i>userauto</i> <string>	userauto
<i>users</i> <string>	users

(Refer to Appendix C for more info on the parameters.)

#### Synopsis 2 - Configuration of Network-related Parameters

```
config configure ether [options]
```

or in CLI mode:

```
configure ether [options]
```

Table 12: Help CLI Options - Synopsis 2

Option	Description	Actual Parameters Modified
<i>ip</i> <string>	Configuration of the IP of the Ethernet interface.	<i>conf.eth_ip</i>
<i>mask</i> <string>	Configuration of the mask for the Ethernet network.	<i>conf.eth_mask</i>
<i>mtu</i> <number>	Configuration of the Maximum Transmission Unit size.	<i>conf.eth_mtu</i>



# Chapter 3 - Additional Features

---

(Refer to Appendix C for more info on the parameters.)

Synopsis 3 - Configuration of other Conf. Parameters

```
config configure conf [options]
```


or in CLI mode:

```
configure conf [options]
```

Table 13: Help CLI Options - Synopsis 3

Option	Actual Parameter Modified
<i>dbfacility</i> <number>	conf.DB_facility
<i>facility</i> <number>	conf.facility
<i>group</i> <string>	conf.group
<i>locallogins</i> <number>	conf.locallogins
<i>nfsdb</i> <string>	conf.nfs_data_buffering

(Refer to Appendix C for more info on the parameters.)



**Note:** To include spaces within the string you are configuring, encapsulate the string within single or double quotes. For instance, to configure `s2.sttyCmd -igncr -onlcr`, type (do not put a space after a comma):

```
config configure line 2 sttycmd "-igncr -onlcr"
```



**Tip.** You can specify the range or list of serial ports if you wish to configure the same parameters for several ports. For instance, to configure parameters for ports 2 through 4, you can type this command: `config configure line 2-4 [options]`. Or to configure parameters for just ports 4, 6, and 9, you can type:

```
config configure line 4,6,9 [options]
```

(Do not put a space after the commas when listing the serial ports.)

### Requesting Help for the CLI

There are two methods for requesting help for the CLI:

- To obtain general help on the format of CLI, type `config help / more` at the terminal prompt.
- Help may be requested at any point in a command by entering a “?”. If nothing matches, the help list will be empty and you must backup until entering a “?” shows the available options.

For example:

- To find out possible commands that can come after `config`, type:

```
config ?
```

- To find out what parameters are configurable through CLI, type:

```
config configure line <serial port number> ?
```

# Chapter 3 - Additional Features

---

## NTP

The `ntpclient` is a *Network Time Protocol* (RFC-1305) client for UNIX- and Linux-based computers. In order for the BLACK BOX ® Advanced Console Server to work as a NTP client, the IP address of the NTP server must be set in the file `/etc/ntpclient.conf`.

The script shell `/bin/ntpclient.sh` reads the configuration file (`/etc/ntpclient.conf`) and build the line command to call `/bin/ntpclient` program.

### Parameters Involved and Passed Values

The file `/etc/ntpclient.conf` has the value of two parameters:

<i>NTPSERVER</i>	The IP address of the NTP server.
<i>INTERVAL</i>	Check time every interval seconds (default 300).

The data and time will be update from the NPT server according to the parameter options. The `ntpclient` program has this syntax:

```
ntpclient [options]
```

#### *Options:*

<i>-c count</i>	Stop after count time measurements (default 0 means go forever).
<i>-d</i>	Print diagnostics.
<i>-h hostname</i>	NTP server host (mandatory).
<i>-i interval</i>	Check time every interval seconds.
<i>-l</i>	Attempt to lock local clock to server using <code>adjtimex(2)</code> .
<i>-p port</i>	Local NTP client UDP port.
<i>-r</i>	Replay analysis code based on stdin.
<i>-s</i>	Clock set (if count is not defined this sets count to 1).

---

---

## Configuration for CAS, TS, and Dial-in Access

vi Method

**Files to be changed:**

`/etc/ntpclient.conf`

Browser Method

**To configure NTP with your browser:**

**Step 1: Point your browser to the Console Server.**

**In the address or location field of your browser type the Console Access Server's IP address. For example:**

`http://10.0.0.0`

**Step 2: Log in as root and type the Web root password configured by the Web server.**

**This will take you to the Configuration and Administration page.**

**Step 3: Click on the Edit Text File link.**

**Click on this link on the Link Panel or on the Configuration section of the Configuration and Administration page. (See .) You can then pull up the appropriate file and edit it.**


# Chapter 3 - Additional Features

---

## PCMCIA



**Warning!** Although there are two PCMCIA slots in the BLACK BOX<sup>®</sup> Advanced Console Server, only one is currently supported: the bottom slot. Future software versions will allow for use of the second slot.



**Note:** This section applies only to the model of the BLACK BOX<sup>®</sup> Advanced Console Server that has a dual power supply.

### Supported Cards

The BLACK BOX<sup>®</sup> Advanced Console Server supports the 16-bit PC Cards. The 32-bit Card-Bus PC Cards are not supported. For an updated list of supported cards, please check the Black Box Web site.

### Tools for Configuring and Monitoring PCMCIA Devices

During the BLACK BOX<sup>®</sup> Advanced Console Server boot, the `/etc/init.d/pcmcia` script loads the PCMCIA core drivers and the `cardmgr` daemon. The `cardmgr` daemon is responsible for monitoring PCMCIA sockets, loading client drivers when needed, and running user-level scripts in response to card insertions and removals.

### Ejecting Cards

You can insert the card anytime, and the drivers should be loaded automatically. But you will need to run `cardctl eject` before ejecting the card to stop the application using the card. Otherwise the BLACK BOX<sup>®</sup> Advanced Console Server may hang during the card removal. You must specify the slot number when using the `cardctl` command. For example:

```
cardctl eject 0 for the lower slot  
and
```

---

---

```
cardctl eject 1 for the upper slot
```

## PCMCIA Network Configuration



**Note:** Due to a known problem in the current release, the I/O ports used by the card cannot be re-used after card re-insertion. In each card insertion, the card gets a different I/O port. This limits the number of times the card can be ejected and inserted. When all the I/O ports known by the card are used, the *RequestIO: No more items* message is displayed, and the only way to reset the I/O port usage is to reboot the system.

The onboard Ethernet device has the *eth0* name. The first PCMCIA Ethernet card or wireless LAN card detected will receive the *eth1* name, the second card will be *eth2*.

*cardmgr* will read the network settings from the */etc/network/interfaces* and assign an IP to *eth1*.



**Note:** Before changing the */etc/network/interfaces* file, unload the network client driver using *cardctl eject*.

The factory default */etc/network/interfaces* has the following lines:

```
# auto eth1
# iface eth1 inet static
#     address 192.168.0.42
#     network 192.168.0.0
#     netmask 255.255.255.0
#     broadcast 192.168.0.255
#     gateway 192.168.0.1
```

# Chapter 3 - Additional Features

---

Remove the # in the beginning of the line, and change the IPs to suit your network configuration. For instance, you may want the following configuration:

```
auto eth1

iface eth1 inet static
    address 192.168.162.10
    network 192.168.162.0
    netmask 255.255.255.0
    broadcast 192.168.162.255
    gateway 192.168.162.1
```

Don't forget to run *saveconf* to save this configuration in the flash, so that it can be restored in the next boot. Run *cardctl insert* to load the network drivers with the new configuration.

## Wireless LAN PC Cards



**Note:** Do not use *ifconfig* to change the network settings for the PCMCIA device. Otherwise, you may be unable to unload the network driver during *cardctl eject* and the BLACK BOX® Advanced Console Server may hang. The correct way is to change the */etc/network/interfaces* file.

First do the appropriate PCMCIA network configuration. Additionally, the configuration of the wireless driver is done in the following file:

```
/etc/pcmcia/wireless.opts
```

For instance, to configure the network name as *MyPrivateNet*, and the WEP encryption key as *secul*, the following settings could be added to the default "*\*, \*, \*, \**)" entry :

```
*, *, *, *)
    INFO="This is a test "
    ESSID="MyPrivateNet "
    KEY="s:secul "
```

---

---

There is a generic sample in the end of the *wireless.opts* file that explains all possible settings.



Note: The "s:" prefix in the KEY line indicates that the key is an ASCII string, as opposed to hex digits. Five characters or ten digits could be entered for WEP 40-bit and 13 characters or 26 digits could be entered for WEP 128-bit.

For more details in wireless configuration, search for *manpage iwconfig* on the Internet. The parameters in *wireless.opts* are used by the *iwconfig* utility. After changing any of the parameters, run *cardctl eject* followed by *cardctl insert* to load the new settings. Also, run *saveconf* to save the new settings to flash. *iwconfig eth1* shows the basic wireless parameters set in *eth1*. *iwlist* allows to list frequencies, bit-rates, encryption, etc. The usage is:

```
iwlist eth1 frequency
iwlist eth1 channel
iwlist eth1 ap
iwlist eth1 accesspoints
iwlist eth1 bitrate
iwlist eth1 rate
iwlist eth1 encryption
iwlist eth1 key
iwlist eth1 power
iwlist eth1 txpower
iwlist eth1 retry
```

## Modem PC Cards

The modem device gets the */dev/ttySn* name, where *n* is the number of embedded serial devices plus 1. For instance, if the BLACK BOX® Advanced Console Server has 32 onboard serial devices, the modem card becomes the */dev/ttyS33*.



# Chapter 3 - Additional Features

---

When a modem card is detected, *cardmgr* starts a script which loads *mgetty* for the modem device automatically. *mgetty* provides the login screen to the remote user. *mgetty* may also be configured to start PPP (*pppd*) and let PPP login the caller. The steps to allow PPP connections are:

**Step 1: Enable login and PAP authentication in `/etc/mgetty/login.config`.**

Enable the desired authentication in `/etc/mgetty/login.config`. For instance, you may want the following authentication in `/etc/mgetty/login.config` to enable PAP and system password database authentication:

```
/AutoPPP/ - a_ppp /usr/local/sbin/pppd auth -chap +pap login
nobsdcomp nodeflate
```

**Step 2: Create a user name in `/etc/ppp/pap-secrets`.**

If `+pap` authentication was selected, create a user name in `/etc/ppp/pap-secrets`. For instance, you may add the following line:

```
"mary" * "marypassword" *
```

**Step 3: Create the user for login in the Radius server.**

If the `login` option was used, create the user either locally (by running `adduser`) or create the user in the Radius server for Radius authentication. When the `login` option is used, `/etc/pam.conf` may also need to be changed. (By default, `/etc/pam.conf` has the `ppp` and `login` services configured for local authentication. You will have to change them if you want Radius authentication. More information can be found in "Appendix D - Linux-PAM".)

**Step 4: Copy the `/etc/ppp/options.ttyXX` as `/etc/ppp/options.ttyS33` (the modem port).**

Copy the `/etc/ppp/options.ttyXX` to have the device name assigned to the `pcmcia` modem. For instance, if the modem is the `ttyS33`, `/etc/ppp/options.ttyXX` should be copied as `/etc/ppp/options.ttyS33`. If you are not sure which `ttySxx` is the modem device, do a `"ls -al /dev/modem"` with the modem inserted.

**Step 5: Uncomment local and remote IPs in `/etc/ppp/options.ttyS33`.**

Uncomment the line that assigns the local and remote IPs in `/etc/ppp/options.ttyS33` (or whatever is the `tty` name in your system). For instance, you may want to assign `192.168.0.1` for local ip, and `192.168.0.2` for the remote ip.

---

---

**Step 6:** Save `/etc/ppp/options.ttyS33` in flash.

**Step 7:** Create an entry in `/etc/config_files`.

It should have the name of the file you created, so that the new file can be saved to the flash. For instance, you will have to add a line with `/etc/ppp/options.ttyS33` in `/etc/config_files`.

**Step 8:** Run `saveconf` to save the files listed in `/etc/config_files` to the flash.

**Step 9:** Insert the pcmcia modem if not inserted yet.

**Step 10:** Run `ps` to see that `mgetty` is running.

The BLACK BOX ® Advanced Console Server is ready to receive dial in calls.

**Step 11:** Establish PPP connection with the BLACK BOX ® Advanced Console Server.

From the remote system, use `pppd` to dial and establish a PPP connection with the BLACK BOX ® Advanced Console Server. The remote system should have the login user name set in their `/etc/ppp/pap-secrets` to have a successful login in the BLACK BOX ® Advanced Console Server.

## Establishing a Callback with your Modem PC Card

Setting up a callback system serves two purposes:

1. **Cost savings:** reversing line charges - allows your company to call you back.
2. **Security:** makes sure users are who they pretend to be by calling a well-known or preconfigured number back.

The steps to allow callback are divided into two parts. Part One is the configuration for the Advanced Secure Console Port Server (Server Side BLACK BOX ® Advanced Console Server Setup). Part Two is the configuration for the client side.

# Chapter 3 - Additional Features

---

## Server Side BLACK BOX ® Advanced Console Server Setup

### Step 1: Enable authentication.

Enable the desired authentication in `/etc/mgetty/login.config`. For instance, you may want the following authentication in `/etc/mgetty/login.config` to enable PAP and system password database authentication:

```
/AutoPPP/ - a_ppp /usr/local/sbin/pppd auth -chap +pap login  
nobsdcomp nodeflate
```

### Step 2: Configure a pseudo callback user.

Add the following line to `/etc/mgetty/login.config` with the appropriate values. Do this before the line `/* - - /bin/login @/` at the end of the file.

```
<pseudo callback name> - - /sbin/callback -S <phone  
number of the client>/
```

ie:

```
call - - /sbin/callback -S 12345
```

'call' is the pseudo callback name. '123456' is the number to dial back.

### Step 3: (If you plan to login through PPP with PAP authentication) create pap user name in `/etc/ppp/pap-secrets`.

Add a line similar to the following: (include the quotes and the two asterisks).

```
"myUserName" * "myUserNamePassword" *
```

### Step 4: (If you plan to login through PPP) follow steps 4 - 9 in the section above on Modem PC Cards.

### Step 5: Create users.

**Step A:** Create a new user with the command `adduser myUserName`.

This will create an entry in `/etc/passwd` that resembles this:

```
myUserName:$1$/3Qc1pGe$/h3hzkaJQJ/:503:503:Embedix  
User,,,:/home/myUserName:/bin/sh
```

---

---

**Step B:** If you want to limit myUserName to getting ONLY PPP access and NOT shell access to the server, edit the entry for myUserName in /etc/passwd..

Do this by replacing /bin/sh with a pathname to a script that you will be creating later. In the following example, the script is: */usr/ppp/ppplogin*

```
myUserName:$1$/3Qc1pGe$/h3hzkaJQJ/:503:503:Embedix
User,,,:/home/myUserName:/usr/ppp/ppplogin
```

**Step 6:** If you executed Step 5b, create the ppp login script.

**Step A:** Create a script called /etc/ppp/ppplogin following this format:

```
#!/bin/sh
exec /usr/local/sbin/pppd <ppp options>
```

**Step B:** Make script executable.

Type *chmod 755 /etc/ppp/ppplogin*.

**Step C:** Save this file to flash.

Save this file to flash so the next time the BLACK BOX ® Advanced Console Server gets rebooted, you

won't lose the new file. Add /etc/ppp/ppplogin into /etc/config\_files.

Now execute *saveconf*.

**Step 7:** Change permission of pppd.

Type *chmod u+s /usr/local/sbin/pppd*

**Step 8:** Your BLACK BOX ® Advanced Console Server is ready to establish a callback connection.

See Client Side Setup to start the callback connection.

# Chapter 3 - Additional Features

---

## Client Side Setup

### Step 1: Activate Show Terminal Window option.

(From Win2000) Go to your Connection window (the window to dial the BLACK BOX ® Advanced Console Server) -> Properties -> Security -> look for Interactive Logon and Scripting -> click on Show Terminal Window.

### Step 2: Disable/enable encryption protocols.

If you are going to be using PPP connection with PAP authentication, make sure you disable all other encryption protocols.

(from Win2000) go to your Connection window (the window to dial the BLACK BOX ® Advanced Console Server)

-> Properties -> Security -> click on Advanced (custom settings) ->

click on Settings -> click on Allow these protocols -> disable all protocols except the PAP one.

### Step 3: Set up modem init string.

It is *very* important that before callback hangs the call, the modem in the Windows box does not tell Windows that the call has been dropped. Otherwise, Windows Dial-up Networking will abort everything (because it thinks the call was dropped with no reason).

(From Win2000) Go to Windows' control panel -> Phone and Modem -> Modems -> choose your modem -> Properties -> Advanced -> add &c0s0=1 to Extra Settings.

### Step 4: Call your BLACK BOX ® Advanced Console Server.

Step A: Dial to the BLACK BOX ® Advanced Console Server modem using either the normal username or the ppp username that you created in Step 5 when configuring the server side.

Step B: Once a connection is made, you get a login prompt.

Step C: Login with the pseudo callback name to start the callback.

Step D: Your connection gets dropped. The BLACK BOX ® Advanced Console Server is now calling you back.

Step E: After reconnection to you, you get a login prompt again.

Step F: Now you can:

- Log in through character mode: Log in with username and password. You will get the BLACK BOX® Advanced Console Server shell prompt.
- Log in through ppp: Click on Done on the Terminal Window.

## ISDN PC Cards

You can establish synchronous PPP connections with ISDN cards. The `pppd` is the daemon that handles the synchronous PPP connections.

How to configure dial in

**Step 1: Create a user.**

Create a user in `/etc/ppp/pap-secrets` or in `/etc/ppp/chap-secrets`, depending if you want PAP or CHAP authentication. You will also have to create a user in `/etc/ppp/pap-secrets` if you want radius or local authentication. In case you don't want to repeat all the user database from the radius server an option is to use `!*` as the user in `/etc/ppp/pap-secrets`:

```
*      *      " "      *
```

**Step 2: Change the options in `/etc/pcmcia/isdn.opts` to fit your environment.**

Make sure that `$DIALIN` is set to "yes." Set the desired authentication in `DIALIN_AUTHENTICATION`. For instance, "+pap" for PAP, "+chap" for CHAP, "login auth" or "login +pap" for radius, "login auth" or "login +pap" for local. When "login auth" or "login +pap" are used, PAM libraries are used so `/etc/pam.conf` should be also configured.

**Step 3: Run `saveconf` to save your changes to the flash.**

**Step 4: If the ISDN card is not inserted, it is time to insert the card.**

`pppd` is started automatically. Go to step 6.

**Step 5: Restart script.**

If the card was already inserted, you will need to restart the `isdn` script to re-load any changed configuration. To restart the script, issue:

# Chapter 3 - Additional Features

---

```
/etc/pcmcia/isdn stop ipp0
```

```
/etc/pcmcia/isdn start ipp0
```

**Step 6:** You can dial from the remote system to the BLACK BOX<sup>®</sup> Advanced Console Server, and get a PPP connection.

**Step 7:** To hang up the connection from the BLACK BOX<sup>®</sup> Advanced Console Server side, just issue:

```
isdnctrl hangup ipp0
```

How to configure dial out

**Step 1:** Create a user.

Create a user in `/etc/ppp/pap-secrets` or in `/etc/ppp/chap-secrets`, depending if you want PAP or CHAP authentication.

**Step 2:** Change options.

Change the options in `/etc/pcmcia/isdn.opts` to fit your environment. Make sure that `$DIALIN` is set to "no". Set `$USERNAME` to the user name provided by your ISP.

**Step 3:** Run `saveconf` to save your changes to the flash.

**Step 4:** If the ISDN card is not inserted, it is time to insert the card.

`pppd` is started automatically. Go to step 6.

**Step 5:** Restart script.

If the card was already inserted, you will need to restart the `isdn` script to re-load any changed configuration. To restart the script, issue:

```
/etc/pcmcia/isdn stop ipp0
```

```
/etc/pcmcia/isdn start ipp0
```

**Step 6:** To dial out, issue the command:

```
isdnctrl dial ipp0
```

---

---

**Step 7: To hangup the connection from the BLACK BOX ® Advanced Console Server side, just issue:**

```
isdnctrl hangup ipp0
```

## Establishing a Callback with your ISDN PC Card

For the same cost saving reasons explained in [Establishing a Callback with your Modem PC Card](#), the ISDN card in the BLACK BOX ® Advanced Console Server can be configured to call-back client machines after receiving dial in calls.

The steps to allow callback are divided into two parts. Part One is the configuration for the BLACK BOX ® Advanced Console Server (BLACK BOX ® Advanced Console Server Setup) as callback server. Part Two is the configuration of a Windows 2000 Professional computer as callback client.

BLACK BOX ® Advanced Console Server setup (Callback Server)

**Step 1: Change the parameters in /etc/pcmcia/isdn.opts to fit your environment.**

**Step 2: Set the callback number in DIALOUT\_REMOTENUMBER:**

```
DIALOUT_REMOTENUMBER="8358662" # Remote phone that you want to  
                                # dial to
```

**Step 3: If your isdn line supports caller id, it is recommended that you also configure the DIALIN\_REMOTENUMBER and enable secure calls. Otherwise skip to step 4.**

```
DIALIN_REMOTENUMBER="8358662" # Remote phone from which you will  
                                # receive calls
```

```
SECURE="on"      # "on" = incoming calls accepted only if remote  
                 # phone matches DIALIN_REMOTENUMBER; "off" =  
                 # accepts calls from any phone. "on" will work  
                 # only if your line has the caller id info.
```



# Chapter 3 - Additional Features

---

**Step 4:** Make sure the CALLBACK is set to "in" in /etc/pcmcia/isdn.opts.

CALLBACK="in" # "in" will enable callback for incoming calls.

**Step 5:** Uncomment line with user "mary" in /etc/ppp/pap-secrets.

**Step 6:** Save changes to flash.

```
saveconf
```

**Step 7:** Activate the changes by stopping and starting the isdn script:

```
/etc/pcmcia/isdn stop ipp0
```

```
/etc/pcmcia/isdn start ipp0
```

The BLACK BOX ® Advanced Console Serverside is done.

Windows 2000 Professional configuration (Callback Client)

**Step 1:** Create user "mary" with password "marypasswd" in Control Panel -> "User and Passwords".

**Step 2:** Create a dial-up connection that uses "Modem - AVM ISDN Internet (PPP over ISDN) (AVMISDN1)".

(To create a dial-up connection, go to Start->Settings->Network and Dial-up Connections->Make New Connection, select "I want to set up my Internet connection manually, or I want to connect through a local area network", select "I connect through a phone line and a modem", select the "AVM ISDN Internet (PPP over ISDN)" modem, type the phone number you dial to connect to the BLACK BOX ® Advanced Console Server, and enter mary as User name and marypasswd as password.). After creating this dial-up, click on the Properties of this dial-up, select the "Options" panel, and change the Redial attempts to 0.

**Step 3:** Accept incoming connections.

To accept incoming connections, go to Start->Settings->Network and Dial-up Connections->Make New Connection, select "Accept incoming connections" (the words are slightly different in XP), select AVM ISDN Internet (PPP over ISDN), select "Do not allow virtual private connections", click the user "mary", then click on Properties of TCP/IP to specify the IP addresses for the calling computers. Also in

---

---

“mary” Properties, select the Callback tab and make sure the option “Do not allow callback” is selected. After any change in the Incoming Connection Properties, it is recommended that the Windows is rebooted to apply the changes.

The Windows side is done.

Now you can dial from Windows to the BLACK BOX® Advanced Console Server. Go to Start-> Settings-> “Network and Dial-up Connections” and select the dial-up that you created. After the “Dialing” message, you will see a window with a warning message:

```
Opening port....  
Error 676: The phone line is busy.
```

Just click Cancel. In a few seconds, the BLACK BOX® Advanced Console Server will call you back, and you will see the connection icon in the taskbar.

### Establishing a Callback with your ISDN PC Card (2nd way)

The previous section explained how to do callback at D-Channel level. The advantages of having callback at D-Channel level is that it works independent of the Operating System on the client side. But a big disadvantage is that the callback call happens before the authentication phase in PPP. The only security is by that only calls from predefined phone numbers are accepted.

To fix that drawback, this section explains another way to have callback with the BLACK BOX® Advanced Console Server. The steps described here will work when the remote side is a UNIX machine, not Windows. The callback call will happen after the PPP authentication is successful.

### BLACK BOX® Advanced Console Server Setup (Callback Server)

**Step 1: Change the parameters in /etc/pcmcia/isdn.opts to fit your environment.**

**Step 1.1: Set the callback number in DIALOUT\_REMOTENUMBER.**

```
DIALOUT_REMOTENUMBER="8358662" # Remote phone that you want to  
                                # dial to
```

# Chapter 3 - Additional Features

---

## Step 1.2: Configure the DIALIN\_REMOTENUMBER.

If your ISDN line supports caller id, it is recommended that you also configure the DIALIN\_REMOTENUMBER and enable secure calls. Otherwise skip to Step 1.3.

```
DIALIN_REMOTENUMBER="8358662" # Remote phone from which you will
                                # receive calls
SECURE="on"                    # "on" = incoming calls accepted only if remote
                                # phone matches DIALIN_REMOTENUMBER; "off" =
                                # accepts calls from any phone. "on" will work
                                # only if your line has the caller id info.
```

## Step 1.3: Set the desired IPs for local and remote machines.

## Step 1.4: Set DIALIN to "yes".

```
DIALIN="yes" # "yes" if you want dial in, "no" if you want dial out
```

## Step 1.5: Make sure the CALLBACK parameter is disabled.

```
CALLBACK="off" # "off" = callback disabled.
```

## Step 1.6: Add the user that will callback the client in DIALIN\_AUTHENTICATION.

```
DIALIN_AUTHENTICATION="auth login user mary"
```

## Step 2: Make sure /etc/pam.conf has the configuration you want (e.g., radius).

This step is only required if you are using "auth login" in DIALIN\_AUTHENTICATION. When using "auth login," /etc/pam.conf is what defines which authentication will be used.

## Step 3: Add the user "mary" in /etc/ppp/pap-secrets.

## Step 4: Uncomment lines in /etc/ppp/auth-up.

## Step 5: Save changes to flash:

---

---

```
saveconf
```

**Step 6: Activate the changes by stopping and starting the isdn script:**

```
/etc/pcmcia/isdn stop ipp0
```

```
/etc/pcmcia/isdn start ipp0
```

Linux (Callback Client)

**Step 1: Configure the ippd to have user mary and pap authentication.**

**Step 2: Dial to the BLACK BOX ® Advanced Console Server:**

```
isdnctrl dial ipp0
```

**Step 3: As soon the BLACK BOX ® Advanced Console Server authenticates the user mary, the BLACK BOX ® Advanced Console Server will disconnect and callback.**

# Chapter 3 - Additional Features

---

## Ports Configured as Terminal Servers

There are TS-specific parameters that are required to be configured when using the serial ports with the TS profile. The configuration of these TS-specific parameters are described in this section. Additional configuration for TS is described in Access Method and Serial Settings in Chapter 3, and in Appendix C – The pslave Configuration File.

### TS Setup Wizard

The Wizard can be used to configure TS-specific parameters. (TSO stands for “TS Other”- other parameters specific to the TS profile):

**Step 1: At the command line interface type the following:**

```
wiz --tso
```

#### *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

# Ports Configured as Terminal Servers

---

---

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.host : 192.168.160.8  
all.term : vt100  
conf.locallogins : 0
```

Set to defaults? (y/n) [n] :

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.HOST - The IP address of the host to which the terminals will connect.

```
all.host[192.168.160.8] :
```

ALL.TERM - This parameter defines the terminal type assumed when performing rlogin or telnet to other hosts.

```
all.term[vt100] :
```

## *Screen 4:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

CONF.LOCALLOGINS - This parameter is only necessary when authentication is being performed for a port. When set to 1, it is possible to log into the system directly by

# Chapter 3 - Additional Features

---

placing a '!' before users' login name, then using their normal password. This is useful if the Radius authentication server is down.

```
conf.locallogins[0] :
```

## *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.host : 192.168.160.8
```

```
all.term : vt100
```

```
conf.locallogins : 0
```

Are these configuration(s) all correct? (y/n) [n] :

## *If you type 'n'*

Type 'c' to go back and CORRECT these parameters

or 'q' to QUIT :

***Typing 'c' repeats the application, typing 'q' exits the entire wiz application***

## *If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

***Typing 'c' leads to Screen 6, typing 'q' leads to Screen 7.***

# Ports Configured as Terminal Servers

---

---

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You have 8 available ports on this system.

Type 'q' to quit, a valid port number[1-8], or anything  
else to refresh :



**Tip.** The number of available ports depends on the system you are on.  
Typing in a valid port number repeats this program except this time it's config-  
uring for the port number you have chosen. Typing 'q' leads to Screen 7.

## *Screen 7:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [n]:



# Chapter 3 - Additional Features

---

## *Screen 8:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

# Ports Configured as Terminal Servers

---

---

## CLI Method

To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be `ttys<serial port number>` :

```
config configure line <serial port number> tty <string>
```

To configure host:

```
config configure line <serial port number> host <string>
```

To configure term:

```
config configure line <serial port number> term <string>
```

To configure `conf.locallogins`:

```
config configure conf locallogins <number>
```

**Step 2:** Activate and Save.



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
host <string> term <string> locallogins <number>
```

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing `signal_ras hup` and `saveconf` from the normal terminal prompt.)

# Chapter 3 - Additional Features

---

## Serial Settings

This feature controls the speed, data size, parity, and stop bits of all ports. It also sets the flow control to hardware, software, or none; the DCD signal; and tty settings after a socket connection to that serial port is established.

### Parameters Involved and Passed Values

Terminal Settings involve the following parameters (the first four are physical parameters):

<i>all.speed</i>	The speed for all ports. Default value: <i>9600</i> .
<i>all.datasize</i>	The data size for all ports. Default value: <i>8</i> .
<i>all.stopbits</i>	The number of stop bits for all ports. Default value: <i>1</i> .
<i>all.parity</i>	The parity for all ports. Default value: <i>none</i> .
<i>all.flow</i>	This sets the flow control to hardware, software, or none. Default value: <i>none</i> .
<i>all.dcd</i>	DCD signal (sets the tty parameter CLOCAL). Valid values are 0 or 1. If <i>all.dcd=0</i> , a connection request will be accepted regardless of the DCD signal and the connection will not be closed if the DCD signal is set to DOWN. If <i>all.dcd=1</i> a connection request will be accepted only if the DCD signal is UP and the connection will be closed if the DCD signal is set to DOWN. Default value: <i>0</i> .

*all.sttyCmd (for CAS only)* The TTY is programmed to work as configured and this user-specific configuration is applied over that serial port. Parameters must be separated by a space. The following example sets :

*-igncr*

This tells the terminal not to ignore the carriage-return on input,

*-onlcr*

Do not map newline character to a carriage return or newline character sequence on output,

*opost*

Post-process output,

*-icrnl*

Do not map carriage-return to a newline character on input.

```
all.sttyCmd -igncr -onlcr opost -icrnl
```

*DTR\_reset (for CAS only)* This parameter specifies the behavior of the DTR signal in the serial port configured with buffering or sniff session. If set to zero the DTR signal will be ON if there is a connection to the serial port, otherwise OFF. If set from 1 to 99 the DTR signal will be always ON. A value greater or equal 100 specifies for how long (in milliseconds) the DTR signal will be turned off before it is turned back on again when a connection to the serial port is closed. Example value: 3.

## Configuration for CAS

### Browser Method

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

# Chapter 3 - Additional Features

---

**Step 3: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page or in the Configuration section of the page. This will take you to the Port Selection page.

**Step 4: Select port(s).**

On the Port Selection page, choose all ports or an individual port to configure, from the dropdown menu. Click the Submit button. This will take you to the Serial Port Configuration page.

**Step 5: Click the "CAS Profile" button.**

**Step 6: Scroll down to the Physical section.**

You can change the settings for Speed, Data Size, Stop Bit, Parity, Flow Control, and DCD-sensitivity here.

**Step 7: Click on the Submit button.**

**Step 8: Make the changes effective.**

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 9: Click on the link Administration > Load/Save Configuration.**

**Step 10: Click the Save Configuration to Flash button.**

The configuration was saved in flash.

## Wizard Method

**Step 1: Bring up the wizard.**

At the command prompt, type the following to bring up the CAS Terminal Settings custom wizard:

```
wiz --sset cas
```

Screen 1 will appear.

## *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.speed : 9600  
all.datasize : 8  
all.stopbits : 1  
all.parity : none  
all.flow : none  
all.dcd : 0  
all.DTR_reset : 100
```

# Chapter 3 - Additional Features

---

```
all.sttyCmd : #  
Set to defaults? (y/n) [n] :
```

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****  
ALL.SPEED - The data speed in bits per second (bps) of  
all ports.  
  
all.speed[9600] :  
  
ALL.DATASIZE - The data size in bits per character of  
all ports.  
  
all.datasize[8] :
```

## *Screen 4:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****  
  
ALL.STOPBITS - The number of stop bits for all ports.  
  
all.stopbits[1] :  
  
ALL.PARITY - The parity for all ports.  
(e.g. none, odd, even)  
  
all.parity[none] :
```

## *Screen 5:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.FLOW - This sets the flow control to hardware, software, or none. (e.g. hard, soft, none)

all.flow[none] :

ALL.DCD - DCD signal (sets the tty parameter CLOCAL). Valid values are 0 or 1. In a socket session, if all.dcd=0, a connection request (telnet or ssh) will be accepted regardless of the DCD signal and the connection will not be closed if the DCD signal is set to DOWN. In a socket connection, if all.dcd=1 a connection request will be accepted only if the DCD signal is UP and the connection (telnet or ssh) will be closed if the DCD signal is set to DOWN.

all.dcd[0] :

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.DTR\_RESET - This parameter specifies the behavior of the DTR signal in the serial port. If set to 0 the DTR signal will be ON if there is a connection to the serial port, otherwise it will be OFF. If set from 1 to 99 the DTR signal will be always ON. A value greater or equal to 100 specifies for how long (in milliseconds) the DTR signal will be turned off before it is turned back on again when a connection to the serial port is closed.

all.DTR\_reset[100] :



# Chapter 3 - Additional Features

---

ALL.STTYCMD - Tty settings after a socket connection to that serial port is established. The tty is programmed to work as a CAS profile and this user specific configuration is applied over that serial port. Parameters must be separated by space.(e.g. all.sttyCmd -igncr -onlcr opost -icrnl)-igncr tells the terminal not to ignore the carriage-return on input, -onlcr means do not map newline character to a carriage return/newline character sequence on output, opost represents post-process output, -icrnl means do not map carriage-return to a newline character on input.

all.sttyCmd[#] :

## *Screen 7:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.speed : 9600  
all.datasize : 8  
all.stopbits : 1  
all.parity : none  
all.flow : none  
all.dcd : 0  
all.DTR_reset : 100  
all.sttyCmd : #
```

Are these configuration(s) all correct? (y/n) [n] :

### *If you type 'n'*

Type 'c' to go back and CORRECT these parameters  
or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

### *If you type 'y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 8, typing 'q' leads to Screen 9.*

**Screen 8:**

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
You have 8 available ports on this system.
```

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 9.

# Chapter 3 - Additional Features

---

## *Screen 9:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [n]:

## *Screen 10:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

To configure line parameters for a specific serial port.

**Step 1: At the command prompt, type in the appropriate command to configure desired parameters.**

To activate the serial port. <string> should be ttyS<serial port number> :

```
config configure line <serial port number> tty <string>
```

**To configure speed:**

```
config configure line <serial port number> speed <number>
```

**To configure datasize:**

```
config configure line <serial port number> datasize <number>
```

**To configure stopbits:**

```
config configure line <serial port number> stopbits <number>
```

**To configure parity:**

```
config configure line <serial port number> parity <string>
```

**To configure flow:**

```
config configure line <serial port number> flow <string>
```

**To configure dcd:**

```
config configure line <serial port number> dcd <number>
```

**To configure DTR\_reset:**

```
config configure line <serial port number> dtr_reset  
<number>
```

**To configure sttyCmd:**

```
config configure line <serial port number> sttycmd <string>
```

# Chapter 3 - Additional Features

---



**Tip.** You can configure all the parameters for a serial port in one line:

```
config configure line <serial port number> tty <string>  
speed <number> datasize <number> stopbits <number> par-  
ity <string> flow <string> dcd <number> dtr_reset <num-  
ber> sttycmd <string>
```

## Step 2: Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## Configuration for TS

### Browser Method

See the browser method for the CAS, earlier in this section. The only difference for TS is that “TS Profile” button should be clicked in Step 5.

### Wizard Method

#### Step 1: Bring up the wizard.

At the command prompt, type the following to bring up the TS Terminal Settings custom wizard:

```
wiz --sset ts
```



**Note:** Screens 1- 5 are the same as those of the previous wizard for sset cas, thus, they are omitted here. The only difference between this feature and the CAS wizard is the parameter sttyCmd and DTR\_reset. In the TS configuration, neither of these parameters is requested.

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.speed : 9600  
all.datasize : 8  
all.stopbits : 1  
all.parity : none  
all.flow : none  
all.dcd : 0
```

Are these configuration(s) all correct? (y/n) [n] :

### *If you type 'n':*

Type 'c' to go back and CORRECT these parameters  
or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application.*

### *If you type 'y':*

Type 'c' to CONTINUE to set these parameters for specific  
ports or 'q' to QUIT :

*Typing 'c' leads to Screen 7 typing 'q' leads to Screen 8.*

# Chapter 3 - Additional Features

---

## *Screen 7:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
You have 8 available ports on this system.
```

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :



**Note:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 8.

## *Screen 8:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## *Screen 9:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

**To configure line parameters for a specific serial port:**

**Step 1: At the command prompt, type in the appropriate command to configure desired parameters.**

**To activate the serial port. <string> should be tty<serial port number> :**

```
config configure line <serial port number> tty <string>
```

**To configure speed:**

```
config configure line <serial port number> speed <number>
```

**To configure datasize:**

```
config configure line <serial port number> datasize <number>
```

**To configure stopbits:**

```
config configure line <serial port number> stopbits <number>
```



# Chapter 3 - Additional Features

---

To configure parity:

```
configure line <serial port number> parity <string>
```

To configure flow:

```
config configure line <serial port number> flow <string>
```

To configure dcd:

```
config configure line <serial port number> dcd <number>
```



**Tip.** You can configure all the parameters for a serial port in one line:

```
config configure line <serial port number> tty <string>  
speed <number> datasize <number> stopbits <number>  
parity <string> flow <string> dcd <number>
```

**Step 2: Activate and Save.**

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## Configuration for Dial-in Access

### Browser Method

See the browser method for the CAS, earlier in this section. The only difference for Dial-in is that the “Dial-in Profile” button should be clicked in Step 5.

## CLI Method

To configure line parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be ttyS<serial port number> :

```
config configure line <serial port number> tty <string>
```

To configure speed:

```
config configure line <serial port number> speed <number>
```

To configure datasize:

```
config configure line <serial port number> datasize <number>
```

To configure stopbits:

```
config configure line <serial port number> stopbits <number>
```

# Chapter 3 - Additional Features

---

## Session Sniffing

### Versions 2.1.0 and later

You can open more than one common and sniff session at the same port. For this purpose, the following configuration items are available in the file `pslave.conf`:

- `all.multiple_sessions`: If it is configured as *no*, only two users can connect to the same port simultaneously. If it is configured as *yes*, more than two simultaneous users can connect to the same serial port. A “Sniffer menu” will be presented to the user and they can choose either to open a sniff session; to open a read and/or write session; to cancel a connection; or to send a message to other users connected to the same serial port. If it is configured as “`RW_sessions`,” only read and/or write sessions will be opened, and the sniffer menu won’t be presented. If it is configured as “`sniff_session`” only, a sniff session will be opened, and the sniffer menu won’t be presented. Default value: *no*.
- `sN.multiple_sessions`: Valid only for port N. If it is not defined, it will assume the value of `all.multiple_sessions`.
- `all.escape_char`: Valid for all the serial ports; this parameter will be used to present the menus below to the user. Only characters from ‘^a’ to ‘^z’ (i.e., CTRL-A to CTRL-Z) will be accepted. The default value is ‘^z’ (CTRL-Z).
- `sN.escape_char`: Valid only for port N; this parameter will be used to present the menus below to the user. Only characters from ‘^a’ to ‘^z’ (i.e. CTRL-A to CTRL-Z) will be accepted. If it is not defined, it will assume the value of `all.escape_char`.

When multiple sessions are allowed for one port, the behavior of the BLACK BOX® Advanced Console Server will be as follows:

1. The first user to connect to the port will open a common session.
2. From the second connection on, only admin users will be allowed to connect to that port. The BLACK BOX® Advanced Console Server will send the following menu to these administrators (defined by the parameter `all.admin_users` or `sN.admin_users` in the file `pslave.conf`):

```
*
* * * ttySN is being used by (<first_user_name>) !!!
*
1 - Initiate a regular session
2 - Initiate a sniff session
3 - Send messages to another user
4 - Kill session(s)
5 - Quit
Enter your option:
-----
```

If the user selects *1 - Initiate a regular session*, s/he will share that serial port with the users that were previously connected. S/he will read everything that is received by the serial port, and will also be able to write to it.

If the user selects *2 - Initiate a sniff session*, s/he will start reading everything that is sent and/or received by the serial port, according to the parameter `all.sniff_mode` or `sN.sniff_mode` (that can be in, out or i/o).

When the user selects *3 - Send messages to another user*, the BLACK BOX® Advanced Console Server will send the user's messages to all the sessions, but not to the tty port. Everyone connected to that port will see all the "conversation" that's going on, as if they were physically in front of the console in the same room. These messages will be formatted as:

```
[Message from user/PID] <<message text goes here>> by the
```

To inform the BLACK BOX® Advanced Console Server that the message is to be sent to the serial port or not, the user will have to use the menu.

If the administrator chooses the option *4 - Kill session(s)*, the BLACK BOX® Advanced Console Server will show him/her a list of the pairs `PID/user_name`, and s/he will be able to select one session typing its PID, or "all" to kill all the sessions. If the administrator kills all the regular sessions, his session initiates as a regular session automatically.

*Option 5 - Quit* will close the current session and the TCP connection.

# Chapter 3 - Additional Features

---

Only for the administrator users:

Typing *all.escape\_char* or *sN.escape\_char* from the sniff session or “send message mode” will make the BLACK BOX® Advanced Console Server show the previous menu. The first regular sessions will not be allowed to return to the menu. If you kill all regular sessions using the option 4, your session initiates as a regular session automatically.

## Parameters Involved and Passed Values

Sniffing involves the following parameters:

- |                        |   |
|------------------------|---|
| <i>all.admin_users</i> | This parameter determines which users can receive the sniff menu. When users want access per port to be controlled by administrators, this parameter is obligatory and <i>authtype</i> must not be none. User groups (defined with the parameter <i>conf.group</i> ) can be used in combination with user names in the parameter list. Example values: peter, john, user_group.   |
| <i>all.sniff_mode</i>  | This parameter determines what other users connected to the very same port (see parameter <i>admin_users</i> below) can see of the session of the first connected user (main session): <i>in</i> shows data written to the port, <i>out</i> shows data received from the port, and <i>i/o</i> shows both streams. The second and later sessions are called sniff sessions and this feature is activated whenever the protocol parameter is set to <i>socket_ssh</i> or <i>socket_server</i> . Example value: out. |
| <i>all.escape_char</i> | This parameter determines which character must be typed to make the session enter <i>menu mode</i> . The possible values are <CTRL-a> to <CTRL-z>. Represent the CTRL with caret: ^. This parameter is only valid when the port protocol is <i>socket_server</i> or <i>socket_ssh</i> . Default value is ^z.  |

*all.multiple\_sessions* If it is configured as *no*, only two users can connect to the same port simultaneously. If it is configured as *yes*, more than two simultaneous users can connect to the same serial port. A “Sniffer menu” will be presented to the user and they can choose either to open a sniff session; to open a read and/or write session; to cancel a connection; or to send a message to other users connected to the same serial port. If it is configured as “RW\_sessions,” only read and/or write sessions will be opened, and the sniffer menu won’t be presented. If it is configured as “sniff\_session” only, a sniff session will be opened, and the sniffer menu won’t be presented. Default value: no.

### Configuration for CAS

vi Method

Only the file `/etc/portslave/pslave.conf` has to be changed.

Browser Method

To configure Session Sniffing with your browser:

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server’s IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

**Step 3: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page or in the Configuration section of the page. This will take you to the Port Selection page.

**Step 4: Select port(s).**

On the Port Selection page, choose all ports or an individual port to configure, from the dropdown menu. Click the Submit button. This will take you to the Serial Port Configuration page.

# Chapter 3 - Additional Features

---

**Step 5:** Scroll down to the Sniff Session section.

You can configure the appropriate values here.

Sniff session	
Sniff Session Mode:	Output ▾
Administrative Users:	<input type="text"/>
Escape char from sniff mode:	<input type="text"/>
Allows multiple sniff sessions:	<input type="radio"/> yes <input checked="" type="radio"/> no

*Figure 26: Sniff Session section of the Serial Port Configuration page*

**Step 6:** Click on the Submit button.

**Step 7:** Make the changes effective.

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.

**Step 8:** Click on the link Administration > Load/Save Configuration.

**Step 9:** Click the Save Configuration to Flash button.

The configuration was saved in flash.

## Wizard Method

**Step 1:** Bring up the wizard.

At the command prompt, type the following to bring up the Sniffing custom wizard:

```
wiz --snf
```

## *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.admin_users : #  
all.sniff_mode  : out  
all.escape_char : ^z  
all.multiple_sessions : no
```

Set to defaults? (y/n) [n] :



# Chapter 3 - Additional Features

---

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

ALL.ADMIN\_USERS - This parameter determines which users can open a sniff session, which is where other users connected to the very same port can see everything that the first user is doing. The other users connected to the very same port can also cancel the first user's session (and take over). If the parameter, all.multiple\_sessions, is configured as 'no', then only two users can connect to the same port simultaneously. If it is configured as 'yes', more simultaneous users can sniff the session or have read/write permissions.

(Please see details in Session Sniffing in Chapter 3 of the system's manual.)

```
all.admin_users[#] :
```

ALL.SNIFF\_MODE - This parameter determines what other users connected to the very same port can see of the session of the first connected user (main session). The second session is called a sniff session and this feature is activated whenever the protocol is set to socket\_ssh or socket\_server.

(e.g. in -shows data written to the port, out -shows data received from the port, i/o -shows both streams.)

```
all.sniff_mode[out] :
```

## Screen 4:

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

ALL.ESCAPE\_CHAR - This parameter determines which character must be typed to make the session enter into "menu mode." The possible values are <CTRL-a> to <CTRL-z>, and this is only valid when the port protocol is socket\_server or socket\_ssh. Represent the CTRL character with '^'. Default value is ^z.

```
all.escape_char[^z] :
```

ALL.MULTIPLE\_SESSIONS - Allows users to open multiple common and sniff sessions on the same port. The options are "yes," "no," "RW\_session," or "sniff\_session." Default is set to "no."

```
all.multiple_sessions[no] :
```

## Screen 5:

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

Current configuration:  
(The ones with the '#' means it's not activated.)

```
all.admin_users : #
all.sniff_mode : out
all.escape_char : ^z
all.multiple_sessions : no
```

```
Are these configuration(s) all correct? (y/n) [n] :
```

# Chapter 3 - Additional Features

---

## *If you type 'N'*

Type 'c' to go back and CORRECT these parameters  
or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

## *If you type 'Y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for  
specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 6, typing 'q' leads to Screen 7.*

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****  
You have 8 available ports on this system.
```

Type 'q' to quit, a valid port number[1-8], or anything  
else to refresh :



**NOTE:** The number of available ports depends on the system you are on. Typing in a valid port number repeats this program except this time it's configuring for the port number you have chosen. Typing 'q' leads to Screen 7.

## Screen 7:

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## Screen 8:

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

# Chapter 3 - Additional Features

---

## CLI Method

To configure certain parameters for a specific serial port:

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be ttyS<serial port number> :

```
config configure line <serial port number> tty <string>
```

To configure admin\_users:

```
config configure line <serial port number> adminusers  
<string>
```

To configure sniff\_mode:


```
config configure line <serial port number> sniffmode  
<string>
```

To configure escape\_char:

```
config configure line <serial port number> escape <string>
```

To configure multiple\_sessions:

```
config configure line <serial port number> multiplesess  
<string>
```



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
adminusers <string> sniffmode <string> escape <string>  
multiplesess <string>
```

**Step 2:** Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

---

---

## SNMP

Short for Simple Network Management Protocol: a set of protocols for managing complex networks. The first versions of SNMP were developed in the early 80s. SNMP works by sending messages, called protocol data units (PDUs), to different parts of a network. SNMP-compliant devices, called agents, store data about themselves in Management Information Bases (MIBs) and return this data to the SNMP requesters.

The BLACK BOX® Advanced Console Server uses the net-snmp package (<http://www.net-snmp.org>).



**Important!** Check the SNMP configuration before gathering information about BLACK BOX® Advanced Console Server by SNMP. There are different types of attacks an unauthorized user can implement to retrieve sensitive information contained in the MIB. By default, the SNMP configuration in BLACK BOX® Advanced Console Server cannot permit the public community to read SNMP information.

The net-snmp supports snmp version 1, 2 and 3. To use SNMP version 3 (username/password), perform the following steps:

**Step 1:** Create a file `/etc/snmp/snmpd.local.conf` with the following line:

```
createUser <username> MD5 <password> DES
```

**Step 2:** Include the following line in `/etc/snmp/snmpd.conf`, if the user has permission to read only:

```
rouser <username>
```

**Step 3:** Include the following line in `/etc/config_files`:

```
/etc/snmp/snmpd.local.conf
```

# Chapter 3 - Additional Features

---

You can configure the `/etc/snmp/snmpd.conf` file as indicated later in this section.

1. Snmp version 1
  - RFC1155 - SMI for the official MIB tree
  - RFC1213 - MIB-II
2. Snmp version 2
  - RFC2578 - Structure of Management Information Version 2 (SMIv2)
  - RFC2579 - Textual Conventions for SMIv2
  - RFC2580 - Conformance Statements for SMIv2
3. Snmp version 3
  - RFC2570 - Introduction to Version 3 of the Internet-standard Network Management Framework
  - RFC2571 - An Architecture for Describing SNMP Management Frameworks
  - RFC2572 - Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)
  - RFC2573 - SNMP Applications
  - RFC2574 - User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)
  - RFC2575 - View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)
  - RFC2576 - Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework
4. Private UCD SNMP mib extensions (enterprises.2021)
  - Information about memory utilization (`/proc/meminfo`)
  - Information about system status (`vmstat`)
  - Information about net-snmp packet
5. Private Black Box Vendor MIB ( enterprises.2925 )

- 
- 
- **Black Box LS1032A-xx Remote Management Object Tree (blackbox.4).** This MIB permits you to get informations about the product, to read/write some configuration items and to do some administration commands. (For more details see the blackbox.mib file.)

## Configuration for CAS, TS, and Dial-in Access

vi Method

Files to be changed:

`/etc/snmp/snmpd.conf`

This file has information about configuring for SNMP.

Browser Method

To configure SNMP with your browser:

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

`http://10.0.0.0`

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

**Step 3: Click on the SNMP link.**

Select the SNMP link. The SNMP configuration file will appear in text mode.

**Step 4: Edit the configuration file and click on the Submit button**

**Step 5: Make changes effective.**

Click on the Administration > Run Configuration link. Check the SNMP box and click on the Activate Configuration button.

**Step 6: Click on the Administration > Load/Save Configuration and click on the Save to Flash button.**

This will save the file in the flash.



# Chapter 3 - Additional Features

---

## Syslog

The syslog-ng daemon provides a modern treatment to system messages. Its basic function is to read and log messages to the system console, log files, other machines (remote syslog servers) and/or users as specified by its configuration file. In addition, syslog-ng is able to filter messages based on their content and to perform an action (e.g. to send an e-mail or pager message). In order to access these functions, the *syslog-ng.conf* file needs some specific configuration.

The configuration file (default: *syslog-ng.conf*) is read at startup and is reread after reception of a hangup (HUP) signal. When reloading the configuration file, all destination files are closed and reopened as appropriate. The syslog-ng reads from sources (files, TCP/UDP connections, syslogd clients), filters the messages and takes an action (writes in files, sends snmptrap, pager, e-mail or syslogs to remote servers).

There are five tasks required for configuring syslog-ng:

- Task 1: Define Global Options.
- Task 2: Define Sources.
- Task 3: Define Filters.
- Task 4: Define Actions (Destinations).
- Task 5: Connect all of the above.

The five tasks are explained in the following section [“Syslog-ng and its Configuration” on page 256](#).

---

---

## Port Slave Parameters Involved with syslog-ng

<i>conf.facility</i>	This value (0-7) is the Local facility sent to the syslog-ng from PortSlave.
<i>conf.DB_facility</i>	This value (0-7) is the Local facility sent to the syslog-ng with data when syslog_buffering and/or alarm is active. When nonzero, the contents of the data buffer are sent to the syslogng every time a quantity of data equal to this parameter is collected. The syslog level for data buffering is hard coded to level five (notice) and facility local[0+ conf.DB_facility]. The file /etc/syslog-ng/syslog-ng.conf should be set accordingly for the syslog-ng to take some action. Example value: 0.
<i>all.syslog_buffering</i>	When nonzero, the contents of the data buffer are sent to the syslog-ng every time a quantity of data equal to this parameter is collected. The syslog message is sent to syslog-ng with NOTICE level and LOCAL[0+conf.DB_facility] facility.

## Configuration for CAS, TS, and Dial-in Access

### vi Method

To change the PortSlave parameters: edit the */etc/portslave/pslave.conf* file.

To change the syslog-ng configuration: edit the */etc/syslog-ng/syslog-ng.conf* file.

### Browser Method

To configure the PortSlave parameters, see the Data Buffering section. To configure syslog via your Web browser:

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**


This will take you to the Configuration and Administration page.

# Chapter 3 - Additional Features

---

**Step 3: Click Syslog on the Configuration section.**

Select the Syslog link. The following page will appear, giving information for configuring syslog:



*Figure 27: Syslog page 1*

**Step 4: Edit the configuration file and click on the Submit button**

**Step 5: Make changes effective.**

Click on the Administration > Run Configuration link. Check the Syslog-ng box and click on the Activate Configuration button.

**Step 6: Click on the Administration > Load/Save Configuration and click on the Save to Flash button.**

This will save the file in the flash.

## Wizard Method

**Step 1: Bring up the wizard.**

At the command prompt, type the following to bring up the PortSlave parameters involved with the Syslog custom wizard:

```
wiz --sl
```

Screen 1 will appear.

*Screen 1:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

*Screen 2:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
conf.facility : 7
conf.DB_facility : 0
```

Set to defaults? (y/n) [n] :

# Chapter 3 - Additional Features

---

## *Screen 3:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

CONF.FACILITY - This value (0-7) is the Local facility sent to the syslog. The file /etc/syslog-ng/syslog-ng.conf contains a mapping between the facility number and the action.

(Please see the 'Syslog-ng Configuration to use with Syslog Buffering Feature' section under Generating Alarms in Chapter 3 the system's manual for the syslog-ng configuration file.)

```
conf.facility[7] :
```

CONF.DB\_FACILITY - This value (0-7) is the Local facility sent to the syslog with the data when syslog\_buffering is active. The file /etc/syslog-ng/syslog-ng.conf contains a mapping between the facility number and the action.

(Please see the 'Syslog-ng Configuration to use with Syslog Buffering Feature' section under Generating Alarms in Chapter 3 the system's manual for the syslog-ng configuration file.)

```
conf.DB_facility[0] :
```



**Note:** all.syslog\_buffering is configured under the wiz - - db.

---

---

**Screen 4:**

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

Current configuration:  
(The ones with the '#' means it's not activated.)

```
conf.facility : 7
conf.DB_facility : 0
```

Are these configuration(s) all correct? (y/n) [n] :

***If you type 'n'***

Type 'c' to go back and CORRECT these parameters  
or 'q' to QUIT :

***Typing 'c' repeats the application, typing 'q' exits the entire wiz application***

***If you type 'y' it leads to Screen 5.***

**Screen 5:**

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

# Chapter 3 - Additional Features

---

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

**To configure certain parameters for a specific serial port:**

**Step 1:** At the command prompt, type in the appropriate command to configure desired parameters.

To activate the serial port. <string> should be ttyS<serial port number> :


```
config configure line <serial port number> tty <string>
```

**To configure conf.facility:**

```
config configure conf facility <number>
```

**To configure DB\_facility:**

```
config configure conf dbfacility <number>
```



**Tip.** You can configure all the conf parameters in one line.

```
config configure conf facility <number> dbfacility  
<number>
```

## Step 2: Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

## The Syslog Functions

This section shows the characteristics of the syslog-ng that is implemented for all members of the BLACK BOX ® Advanced Console Server. It is divided into three parts:

1. [Syslog-ng and its Configuration](#)
2. [Syslog-ng Configuration to use with Syslog Buffering Feature](#)
3. [Syslog-ng Configuration to use with Multiple Remote Syslog Servers](#)

### Syslog-ng and its Configuration

The five tasks previously mentioned are detailed below.

#### Task 1: Specify Global Options.

You can specify several global options to syslog-ng in the options statement:

```
options { opt1(params); opt2(params); ... };
```

where *optn* can be any of the following:



# Chapter 3 - Additional Features

---

<i>time_reopen(n)</i>	The time to wait before a dead connection is reestablished.
<i>time_reap(n)</i>	The time to wait before an idle destination file is closed.
<i>sync_freq(n)</i>	The number of lines buffered before written to file. (The file is synced when this number of messages has been written to it.)
<i>mark_freq(n)</i>	The number of seconds between two MARKS lines.
<i>log_fifo_size(n)</i>	The number of lines fitting to the output queue.
<i>chain_hostname (yes/no) or long_hostname (yes/no)</i>	Enable/disable the chained hostname format.
<i>use_time_recvd (yes/no)</i>	Use the time a message is received instead of the one specified in the message.
<i>use_dns (yes/no)</i>	Enable or disable DNS usage. syslog-ng blocks on DNS queries, so enabling DNS may lead to a Denial of Service attack.
<i>gc_idle_threshold(n)</i>	Sets the threshold value for the garbage collector, when syslog-ng is idle. GC phase starts when the number of allocated objects reach this number. Default: 100.
<i>gc_busy_threshold(n)</i>	Sets the threshold value for the garbage collector. When syslog-ng is busy, GC phase starts.
<i>create_dirs(yes/no)</i>	Enable the creation of new directories.
<i>owner(name)</i>	Set the owner of the created file to the one specified. Default: root.
<i>group(name)</i>	Set the group of the created file to the one specified. Default: root.
<i>perm(mask)</i>	Set the permission mask of the created file to the one specified. Default: 0600.

---

---

**Task 2: Define sources.**

To define sources use this statement:

```
source <identifier> { source-driver([params]); source  
driver([params]); ...};
```

where:

<i>identifier</i>	Has to uniquely identify this given source.
<i>source-driver</i>	Is a method of getting a given message.
<i>params</i>	Each source-driver may take parameters. Some of them are required, some of them are optional.

The following source-drivers are available:

<i>a) internal()</i>	Messages are generated internally in syslog-ng.
<i>b) unix-stream (filename [options])</i>	They open the given AF_UNIX socket, and start listening for messages. Options: owner(name), group(name), perm(mask) are equal global options
<i>and</i>	
<i>unix-dgram (filename [options])</i>	<i>keep-alive(yes/no)</i> - Selects whether to keep connections opened when syslog-ng is restarted. Can be used only with <i>unix_stream</i> . Default: yes <i>max-connections(n)</i> - Limits the number of simultaneously opened connections. Can be used only with <i>unix_stream</i> . Default: 10.

# Chapter 3 - Additional Features

---

- c) tcp([options])* These drivers let you receive messages from the network, and as the name of the drivers show, you can use both TCP and UDP.
- and* None of tcp() and udp() drivers require positional parameters. By default they bind to 0.0.0.0:514, which means that syslog-ng will listen on all available interfaces.
- udp([options])*
- Options:
- ip(<ip address>)* - The IP address to bind to. Default: 0.0.0.0.
  - port(<number>)* - UDP/TCP port used to listen messages. Default: 514.
  - max-connections(n)* - Limits the number of simultaneously opened connections. Default: 10.
- d) file(filename)* Opens the specified file and reads messages.
- e) pipe(filename)* Opens a named pipe with the specified name, and listens for messages. (You'll need to create the pipe using mkfifo command).

## Some Examples of Defining Sources

### 1) To read from a file:

```
source <identifier> {file(filename);};
```

### Example to read messages from “/temp/file1” file:

```
source file1 {file(`/temp/file1`);};
```

### Example to receive messages from the kernel:

```
source s_kernel { file(`/proc/kmsg`); };
```

### 2) To receive messages from local syslogd clients:

```
source sysl {unix-stream(`/dev/log`);};
```

### 3) To receive messages from remote syslogd clients:

```
source s_udp { udp(ip(<cliente ip>) port(<udp port>)); };
```

### Example to listen to messages from all machines on UDP port 514:

```
source s_udp { udp(ip(0.0.0.0) port(514));};
```

---



---

Example to listen to messages from one client (IP address=10.0.0.1) on UDP port 999:

```
source s_udp_10 { udp(ip(10.0.0.1) port(999)); };
```

### Task 3: Define filters.

To define filters use this statement:

```
filter <identifier> { expression; };
```

where:

*identifier* Has to uniquely identify this given filter.

*expression* Boolean expression using internal functions, which has to evaluate to true for the message to pass.

The following internal functions are available:

- |  |   |
|--|---|
| a) <i>facility(&lt;facility code&gt;)</i>                                  | Selects messages based on their facility code.                            |
| b) <i>level(&lt;level code&gt;)</i> or <i>priority(&lt;level code&gt;)</i> | Selects messages based on their priority.                                 |
| c) <i>program(&lt;string&gt;)</i>  | Tries to match the <string> to the program name field of the log message. |
| d) <i>host(&lt;string&gt;)</i>   | Tries to match the <string> to the hostname field of the log message.     |
| e) <i>match(&lt;string&gt;)</i>  | Tries to match the <string> to the message itself.                        |

Some Examples of Defining Filters

#### 1) To filter by facility:

```
filter f_facilty { facility(<facility name>); };
```

# Chapter 3 - Additional Features

---

## Examples:

```
filter f_daemon { facility(daemon); };
filter f_kern { facility(kern); };
filter f_debug { not facility(auth, authpriv, news, mail); };
```

## 2) To filter by level:

```
filter f_level { level(<level name>);};
```

## Examples:

```
filter f_messages { level(info .. warn)};
filter f_emergency { level(emerg); };
filter f_alert { level(alert); };
```

## 3) To filter by matching one string in the received message:

```
filter f_match { match('string'); };
```

## Example to filter by matching the string “named”:

```
filter f_named { match('named'); };
```

## 4) To filter ALARM messages (note that the following three examples should be one line):

```
filter f_alarm { facility(local[0+<conf.DB_facility>]) and
level(info) and match('ALARM') and match('<your string>'); } ;
```

## Example to filter ALARM message with the string “kernel panic”:

```
filter f_kpanic { facility(local[0+<conf.DB_facility>]) and
level(info) and match('ALARM') and match('kernel panic'); };
```

## Example to filter ALARM message with the string “root login”:

```
filter f_root { facility(local[0+<conf.DB_facility>]) and
level(info) and match('ALARM') and match('root login'); };
```

---

---

5) To eliminate sshd debug messages:

```
filter f_sshd_debug { not program('sshd') or not level(debug); };
```

6) To filter the syslog buffering:

```
filter f_syslog_buf { facility(local[0+<conf.DB_facility>]) and level(notice); };
```

#### Task 4: Define Actions.

To define actions use this statement (note that the statement should be one line):

```
destination <identifier> { destination-driver([params]);  
destination-driver([param]); ..};
```

where:

<i>identifier</i>	Has to uniquely identify this given destination.
<i>destination driver</i>	Is a method of outputting a given message.
<i>params</i>	Each destination-driver may take parameters. Some of them required, some of them are optional.

The following destination drivers are available:

##### *a) file(filename [options])*

This is one of the most important destination drivers in syslog-ng. It allows you to output log messages to the named file. The destination filename may include macros (by prefixing the macro name with a '\$' sign) which gets expanded when the message is written. Since the state of each created file must be tracked by syslog-ng, it consumes some memory for each file. If no new messages are written to a file within 60 seconds (controlled by the `time_reap` global option), it's closed, and its state is freed.

# Chapter 3 - Additional Features

---

Available macros in filename expansion:

HOST - The name of the source host where the message originated from.

FACILITY - The name of the facility the message is tagged as coming from.

PRIORITY or LEVEL - The priority of the message.

PROGRAM - The name of the program the message was sent by.

YEAR, MONTH, DAY, HOUR, MIN, SEC - The year, month, day, hour, min, sec of the message was sent.

TAG - Equals FACILITY/LEVEL.

FULLHOST - The name of the source host and the source-driver:

<source-driver>@<hostname>

MSG or MESSAGE - The message received.

FULLDATE - The date of the message was sent.

Available options:

*log\_fifo\_size(number)* - The number of entries in the output file.

*sync\_freq(number)* - The file is synced when this number of messages has been written to it.

*owner(name), group(name), perm(mask)* - Equals global options.

*template("string")* - Syslog-ng writes the "string" in the file. You can use the MACROS in the string.

*encrypt(yes/no)* - Encrypts the resulting file.

*compress(yes/no)* - Compresses the resulting file using zlib.

## b) *pipe(filename [options])*

This driver sends messages to a named pipe. Available options:

*owner(name), group(name), perm(mask)* - Equals global options.

*template("string")* - Syslog-ng writes the "string" in the file. You can use the MACROS in the string.

## c) *unix-stream(filename) and unix-dgram(filename)*

This driver sends messages to a UNIX socket in either SOCKET\_STREAM or SOCK\_DGRAM mode.

## d) *udp("<ip address>" port(number);) and tcp("<ip address>" port(number);)*

This driver sends messages to another host (ip address/port) using either UDP or TCP protocol.

## e) *usertty(<username>)*

This driver writes messages to the terminal of a logged-in username.

f) *program*(*<program name and arguments>*)

This driver fork()'s executes the given program with the arguments and sends messages down to the stdin of the child.

Some Examples of Defining Actions

1) To send e-mail:

```
destination <ident> { pipe(`/dev/cyc_alarm' template('sendmail
<pars>')));};
```

where *ident*: uniquely identifies this destination. Parameters:

<i>-t &lt;name&gt;[,&lt;name&gt;]</i>	To address
<i>[-c &lt;name&gt;[,&lt;name&gt;]]</i>	CC address
<i>[-b &lt;name&gt;[,&lt;name&gt;]]</i>	Bcc address
<i>[-r &lt;name&gt;[,&lt;name&gt;]]</i>	Reply-to address
<i>-f &lt;name&gt;</i>	From address
<i>-s \<i>"&lt;text&gt;"</i></i>	Subject
<i>-m \<i>"&lt;text message&gt;"</i></i>	Message
<i>-h &lt;IP address or name&gt;</i>	SMTP server
<i>[-p &lt;port&gt;]</i>	Port used. default:25

To mount the message, use this macro:

\$FULLDATE	The complete date when the message was sent.
\$FACILITY	The facility of the message.
\$PRIORITY or \$LEVEL	The priority of the message.
\$PROGRAM	The message was sent by this program (BUFFERING or SOCK).



# Chapter 3 - Additional Features

---

<code>\$HOST</code>	The name of the source host.
<code>\$FULLHOST</code>	The name of the source host and the source driver. Format: <source>@<hostname>
<code>\$MSG</code> or <code>\$MESSAGE</code>	The message received.

**Example to send e-mail to z@none.com (SMTP's IP address 10.0.0.2) from the e-mail address a@none.com with subject "BLACK BOX ® Advanced Console Server-ALARM". The message will carry the current date, the host-name of this BLACK BOX ® Advanced Console Server and the message that was received from the source.**

```
destination d_maill {
    pipe('/dev/cyc_alarm'
        template('sendmail -t z@none.com -f a@none.com -s \'BLACK BOX ®
Advanced Console Server-ALARM\' \
            -m \'$FULLDATE $HOST $MSG\' -h 10.0.0.2'));
};
```

## 2) To send to pager server (sms server):

```
destination <ident> {pipe('/dev/cyc_alarm' template('sendsms
<pars>'))};
```

where ident: uniquely identify this destination

pars: -d <mobile phone number>

-m '<message - max.size 160 characters>\'

-u <username to login on sms server>

-p <port sms - default : 6701>

<server IP address or name>

**Example to send a pager to phone number 123 (Pager server at 10.0.0.1) with message carrying the current date, the hostname of this BLACK BOX ® Advanced Console Server and the message that was received from the source:**

---

```
destination d_pager {
pipe(`/dev/cyc_alarm`
template(`sendsms -d 123 -m \`${FULLDATE} $HOST $MSG\` 10.0.0.1`));
};
```

### 3) To send snmptrap:

```
destination <ident> {pipe(`/dev/cyc_alarm` template(`snmptrap
<pars>`));};
```

where ident : uniquely identify this destination

pars : -v 1

<snmptrapd IP address>

public : community

\"\" : enterprise-oid

\"\" : agent/hostname

<trap number> : 2-Link Down, 3-Link Up, 4-Authentication Failure

0 : specific trap

\"\" : host-uptime

.1.3.6.1.2.1.2.2.1.2.1 :interfaces.iftable.ifentry.ifdescr.1

s : the type of the next field (it is a string)

\"<message - max. size 250 characters>\"

**Example to send a Link Down trap to server at 10.0.0.1 with message carrying the current date, the hostname of this BLACK BOX ® Advanced Console Server and the message that was received from the source:**

```
destination d_trap {
pipe("/dev/cyc_alarm"
```

# Chapter 3 - Additional Features

---

```
template("snmptrap -v 1 -c public 10.0.0.1 \"\" \"\" 2 0 \"\" \"\" \
.1.3.6.1.2.1.2.2.1.2.1 s \"$FULLDATE $HOST $MSG\" ");
};
```

#### 4) To write in file :

```
destination d_file { file(<filename>);};
```

Example send message to console :

```
destination d_console { file("/dev/ttyS0");};
```

#### Example to write a message in /var/log/messages file:

```
destination d_message { file("/var/log/messages");};
```

#### 5) To write messages to the session of a logged-in user:

```
destination d_user { usertty("<username>");};
```

#### Example to send message to all sessions with root user logged:

```
destination d_userroot { usertty("root");};
```

#### 6) To send a message to a remote syslogd server:

```
destination d_udp { udp("<remote IP address>" port(514));};
```

#### Example to send syslogs to syslogd located at 10.0.0.1 :

```
destination d_udp1 { udp("10.0.0.1" port(514));};
```

#### Task 5: Connect all of the above.

To connect the sources, filters, and actions, use the following statement. (Actions would be any message coming from one of the listed sources. A match for each of the filters is sent to the listed destinations.)

```
log { source(S1); source(S2); ...
filter(F1);filter(F2);...
```

---

---

```
destination(D1); destination(D2);...
```

```
};
```

where :

*Sx*                      Identifier of the sources defined before.

*Fx*                      Identifier of the filters defined before.

*Dx*                      Identifier of the actions/destinations defined before.

#### Examples:

1) To send all messages received from local syslog clients to console:

```
log { source(sysl); destination(d_console);};
```

2) To send only messages with level alert and received from local syslog clients to all logged root user:

```
log { source(sysl); filter(f_alert); destination(d_userroot); };
```

3) To write all messages with levels info, notice, or warning and received from syslog clients (local and remote) to /var/log/messages file:

```
log { source(sysl); source(s_udp); filter(f_messages); destination(d_messages); };
```

4) To send e-mail if message received from local syslog client has the string “kernel panic”:

```
log { source(sysl); filter(f_kpanic); destination(d_maill); };
```

5) To send e-mail and pager if message received from local syslog client has the string “root login”:

```
log { source(sysl); filter(f_root); destination(d_maill); destination(d_pager); };
```

6) To send messages with facility kernel and received from syslog clients (local and remote) to remote syslogd:

# Chapter 3 - Additional Features

---

```
log { source(sysl); source(s_udp); filter(f_kern); destination(d-udp1); };
```

Syslog-ng Configuration to use with Syslog Buffering Feature

**This configuration example uses the syslog buffering feature, and sends messages to the remote syslogd (10.0.0.1).**

**Step 1: Configure pslave.conf parameters.**

In the pslave.conf file the parameters of the syslog buffering feature are configured as:

```
conf.DB_facility 1
all.syslog_buffering 100
```

**Step 2: Add lines to syslog-ng.conf.**

Add the following lines by vi or browser to the file:

```
# local syslog clients
source src { unix-stream("/dev/log"); };
destination d_buffering { udp("10.0.0.1"); };
filter f_buffering { facility(local1) and level(notice); };
# send only syslog_buffering messages to remote server
log { source(src); filter(f_buffering); destination(d_buffering); };
```

Syslog-ng Configuration to use with Multiple Remote Syslog Servers

**This configuration example is used with multiple remote syslog servers.**

**Step 1: Configure pslave.conf parameters.**

In the pslave.conf file the facility parameter is configured as:

```
conf.facility 1
```

**Step 2: Add lines to syslog-ng.conf.**

The syslog-ng.conf file needs these lines:

```
# local syslog clients
```

```
source src { unix-stream("/dev/log"); };
# remote server 1 - IP address 10.0.0.1 port default
destination d_udp1 { udp("10.0.0.1"); };
# remote server 2 - IP address 10.0.0.2 port 1999
destination d_udp2 { udp("10.0.0.2" port(1999));};
# filter messages from facility local1 and level info to warning
filter f_local1 { facility(local1) and level(info..warn);};
# filter messages from facility local 1 and level err to alert
filter f_critic { facility(local1) and level(err .. alert);};
# send info, notice and warning messages to remote server udp1
log { source(src); filter(f_local1); destination(d_udp1); };
# send error, critical and alert messages to remote server udp2
log { source(src); filter(f_critic); destination(d_udp2); };
```

# Chapter 3 - Additional Features

---

## Terminal Appearance

You can change the format of the login prompt and banner that is issued when a connection is made to the system. Prompt and banner appearance can be port-specific as well.

### Parameters Involved and Passed Values

Terminal Appearance involves the following parameters:

- |                              |  |
|------------------------------|--|
| <i>all.prompt</i>            | This text defines the format of the login prompt. Expansion characters can be used here. Example value: %h login:  |
| <i>all.issue</i>             | <p>This text determines the format of the login banner that is issued when a connection is made to the BLACK BOX ® Advanced Console Server.</p> <p>\n represents a new line and \r represents a carriage return. Expansion characters can be used here.</p> <p><i>Value for this Example:</i></p> <pre>\r\n\<br/>Welcome to terminal server %h port S%p \n\<br/>\r\n</pre>   |
| <i>all.If_suppress</i>       | This activates line feed suppression. When configured as 0, line feed suppression will not be performed. When 1, extra line feed will be suppressed.   |
| <i>all.auto_answer_input</i> | This parameter is used in conjunction with the next parameter, auto_answer_output. If configured and if there is no session established to the port, this parameter will constantly be compared and matched up to the string of bytes coming in remotely from the server. If a match is found, the string configured in auto_answer_output is sent back to the server. To represent the ESC character as part of this string, use the control character, ^[. |

*all.auto\_answer\_output* This parameter is used in conjunction with the previous parameter, *auto\_answer\_input*. If configured, and if there is no session established to the port, this parameter is sent back to the server when there is a match between the incoming data and *auto\_answer\_input*. To represent the ESC character as part of this string, use the control character, `^[]`.

## Configuration for CAS, TS, and Dial-in Access

### Browser Method

**Step 1: Point your browser to the Console Server.**

In the address or location field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in as root and type the Web root password configured by the Web server.**

This will take you to the Configuration and Administration page.

**Step 3: Select the Serial Ports link.**

Click on the Serial Ports link on the Link Panel to the left of the page or in the Configuration section of the page. This will take you to the Port Selection page.

**Step 4: Select port(s).**

On the Port Selection page, choose all ports or an individual port to configure, from the dropdown menu. Click the Submit button. This will take you to the Serial Port Configuration page.

**Step 5: Scroll down to the Terminal Server section.**

You can change the settings for Banner Field (issue) and Login Prompt field here.

**Step 6: Click on the Submit button.**

**Step 7: Make the changes effective.**

Click on the Administration > Run Configuration link, check the Serial Ports/Ethernet/Static Routes box and click on the Activate Configuration button.



# Chapter 3 - Additional Features

---

**Step 8:** Click on the link Administration > Load/Save Configuration.

**Step 9:** Click the Save Configuration to Flash button.

The configuration was saved in flash.

## Wizard Method

**Step 1: Bring up the wizard.**

At the command prompt, type the following to bring up the Terminal Appearance custom wizard:

```
wiz --tl
```

Screen 1 will appear.

### *Screen 1:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

INSTRUCTIONS for using the Wizard:

You can:

- 1) Enter the appropriate information for your system and press ENTER. Enter '#' if you want to deactivate that parameter or
- 2) Press ENTER if you are satisfied with the value within the brackets [ ] and want to go on to the next parameter or
- 3) Press ESC if you want to exit.

NOTE: For some parameters, if there is nothing within the brackets, it will continue to ask for a value. In that case, you must enter a valid value or # if you do not wish to configure the value.

Press ENTER to continue...

## *Screen 2:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
Current configuration:
(The ones with the '#' means it's not activated.)

all.issue : \r\n>Welcome to terminal server %h port S%p \n\
\r\n\
all.prompt : %h login:
all.lf_suppress : 0
all.auto_answer_input : #
all.auto_answer_output : #

Set to defaults? (y/n) [n] :
```

## *Screen 3:*

```
*****
***** C O N F I G U R A T I O N W I Z A R D *****
*****
ALL.ISSUE - This text determines the format of the login
banner that is issued when a connection is made to the
system. \n represents a new line and \r represents a
carriage return.

all.issue[\r\n>Welcome to terminal server %h port S%p \n\
\r\n] :

ALL.PROMPT - This text defines the format of the login
prompt.

all.prompt[%h login:] :
```

# Chapter 3 - Additional Features

---

## *Screen 4:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
ALL.LF_SUPPRESS - This activates line feed suppression.
When configured as 0, line feed suppression will not be
performed. When 1, extra line feed will be suppressed.
```

all.lf\_suppress[0] :

ALL.AUTO\_ANSWER\_INPUT - This parameter is used in conjunction with the next parameter, auto\_answer\_output. Please refer to the manual for more info.

If configured and if there is no session established to the port, this parameter will constantly be compared and matched up to the string of bytes coming in remotely from the server. If a match is found, the string configured in auto\_answer\_output is sent back to the server. To represent the ESC character as part of this string, use the control character, ^[.

all.auto\_answer\_input[#] :

## *Screen 5:*

```
*****
***** C O N F I G U R A T I O N   W I Z A R D *****
*****
```

ALL.AUTO\_ANSWER\_OUTPUT - This parameter is used in conjunction with the previous parameter, auto\_answer\_input. Please refer to the manual for more info.

If configured, and if there is no session established to the port, this parameter is sent back to the server when there is a match between the incoming data and auto\_answer\_input. To represent the ESC character as part of this string, use the control character, ^[.

```
all.auto_answer_output[#] :
```

## *Screen 6:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Current configuration:

(The ones with the '#' means it's not activated.)

```
all.issue : \r\n>Welcome to terminal server %h port S%p \n\  
\r\n\  
all.prompt : %h login:  
all.lf_suppress : 0  
all.auto_answer_input : #  
all.auto_answer_output : #
```

Are these configuration(s) all correct? (y/n) [n] :

### *If you type 'N'*

Type 'c' to go back and CORRECT these parameters  
or 'q' to QUIT :

*Typing 'c' repeats the application, typing 'q' exits the entire wiz application*

### *If you type 'Y'*

Discard previous port-specific parameters? (y/n) [n] :



**Note:** Answering yes to this question will discard only the parameter(s) which you are currently configuring if they were configured for a specific port in a previous session. For instance, if you are currently configuring parameter, all.x, and there was a specific port, s2.x, configured; then, answering yes to this question will discard s2.x.

Type 'c' to CONTINUE to set these parameters for  
specific ports or 'q' to QUIT :

*Typing 'c' leads to Screen 7, typing 'q' leads to Screen 8.*

# Chapter 3 - Additional Features

---

## *Screen 7:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

You have 8 available ports on this system.

Type 'q' to quit, a valid port number[1-8], or anything else to refresh :

## *Screen 8:*

```
*****  
***** C O N F I G U R A T I O N W I Z A R D *****  
*****
```

(Note: If you are NOT connected to this unit through a console, and you have just reconfigured the IP of this unit, activating the new configurations may cause you to lose connection. In that case, please reconnect to the unit by the new IP address, and manually issue a saveconf to save your configurations to flash.)

Do you want to activate your configurations now? (y/n) [y] :

## *Screen 9:*

```
*****  
***** C O N F I G U R A T I O N   W I Z A R D *****  
*****
```

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

If you choose to save to flash, your configurations thus

# Terminal Appearance

---

---

far will still be in the memory of the system even after you reboot it. If you don't save to flash and if you were to reboot the system, all your new configurations will be lost and you will have to reconfigure the system.

Do you want to save your configurations to flash? (y/n) [n] :

## CLI Method

**To configure certain parameters for a specific serial port:**

**Step 1: At the command prompt, type in the appropriate command to configure desired parameters.**

**To activate the serial port. <string> should be tty\$<serial port number> :**

```
config configure line <serial port number> tty <string>
```

**To configure issue:**

```
config configure line <serial port number> issue <string>
```

**To configure prompt:**

```
config configure line <serial port number> prompt <string>
```

**To configure lf\_suppress:**

```
config configure line <serial port number> lf <number>
```

**To configure auto\_answer\_input:**


```
config configure line <serial port number> auto_input  
<string>
```

**To configure auto\_answer\_output:**

```
config configure line <serial port number> auto_output  
<string>
```

# Chapter 3 - Additional Features

---



**Tip.** You can configure all the parameters for a serial port in one line.

```
config configure line <serial port number> tty <string>  
issue <string> prompt <string> lf <number> auto_input  
<string> auto_output <string>
```

## Step 2: Activate and Save.

To activate your new configurations and save them to flash, type:

```
config write
```

(This is essentially typing *signal\_ras hup* and *saveconf* from the normal terminal prompt.)

---



---

## Time Zone

The content of the file `/etc/TIMEZONE` can be in one of two formats. The first format is used when there is no daylight savings time in the local time zone:

```
std offset
```

The *std* string specifies the name of the time zone and must be three or more alphabetic characters. The offset string immediately follows *std* and specifies the time value to be added to the local time to get *Coordinated Universal Time* (UTC). The offset is positive if the local time zone is west of the Prime Meridian and negative if it is east. The hour must be between 0 and 24, and the minutes and seconds must be between 0 and 59.

The second format is used when there is daylight savings time:

```
std offset dst [offset],start[/time],end[/time]
```

There are no spaces in the specification. The initial *std* and *offset* specify the Standard Time zone, as described above. The *dst* string and *offset* specify the name and offset for the corresponding daylight savings time zone. If the *offset* is omitted, it defaults to one hour ahead of Standard Time.

The *start* field specifies when daylight savings time goes into effect and the *end* field specifies when the change is made back to Standard Time. These fields may have the following formats:

- Jn* This specifies the Julian day, with *n* being between 1 and 365. February 29 is never counted even in leap years.
- n* This specifies the Julian day, with *n* being between 1 and 365. February 29 is counted in leap years.
- Mm.w.d* This specifies day, *d* ( $0 < d < 6$ ) of week *w* ( $1 < w < 5$ ) of month *m* ( $1 < m < 12$ ). Week 1 is the first week in which day *d* occurs and week 5 is the last week in which day *d* occurs. Day 0 is a Sunday.

The time fields specify when, in the local time currently in effect, the change to the other time occurs. If omitted, the default is 02:00:00.



# Chapter 3 - Additional Features

---

In the example below:

```
GST+7DST+6M4.1.0/14:30.M10.5.6/10
```

Daylight Savings Time starts on the first Sunday of April at 2:30 p.m. and it ends on the last Saturday of October at 10:00 a.m.

## How to set Date and Time

The date command prints or sets the system date and time. Format of the command:

```
date [MMDDhhmm[[CC]YY]
^ ^ ^ ^ ^ ^
^ ^ ^ ^ ^ year
^ ^ ^ ^ century
^ ^ ^ minute
^ ^ hour
^ day
month
```

For example:

```
date 101014452002
```

produces:

```
Thu Oct 10 14:45:00 DST 2002
```

The DST is because it was specified in /etc/TIMEZONE.

This page has been left intentionally blank.

# Appendix A - New User Background Information

---

---

## Users and Passwords

A username and password are necessary to log in to the BLACK BOX® Advanced Console Server. The user *root* is predefined, with a password *tslinux*. A password should be configured as soon as possible to avoid unauthorized access. Type the command:

```
passwd
```

to create a password for the root user. To create a regular user (without root privileges), use the commands:

```
adduser user_name
```

```
passwd user_password
```

To log out, type “logout” at the command prompt.

## How to show who is logged in and what they are doing

The command “w” displays information about the users currently on the machine, and their processes. It calls two commands: *w\_ori* and *w\_cas*. The *w\_ori* is the new name of the original command “w” and the *w\_cas* shows the CAS sessions information.

The header of *w\_ori* shows, in this order: the current time, how long the system has been running, how many users are currently logged on (excluded the CAS users), and the system load averages for the past 1, 5, and 15 minutes.

The following entries are displayed for each user (excluded the CAS users): login name, the tty name, the remote host, login time, idle time, JCPU time (it is the time used by all processes attached to the tty), PCPU time (it is the time used by the current process, named in the “what” field), and the command line of their current process.

The header of *w\_cas* shows how many CAS users are currently logged on. The following entries are displayed for each CAS user: login name, the tty name, the remote host and remote port, login time, the process ID and the command line of the current process.

# Appendix A - New User Background Information

---

---

## Linux File Structure

The Linux file system is organized hierarchically, with the base (or root) directory represented by the symbol “/”. All folders and files are nested within each other below this base directory. The directories located just below the base directory are:

- /home* Contains the work directories of system users.
- /bin* Contains applications and utilities used during system initialization.
- /dev* Contains files for devices and ports.
- /etc* Contains configuration files specific to the operating system.
- /lib* Contains shared libraries.
- /proc* Contains process information.
- /mnt* Contains information about mounted disks.
- /opt* Location where packages not supplied with the operating system are stored.
- /tmp* Location where temporary files are stored.
- /usr* Contains most of the operating system files.
- /var* Contains operating system data files.

# Appendix A - New User Background Information

---

---

## Basic File Manipulation Commands

The basic file manipulation commands allow the user to copy, delete, and move files and create and delete directories.

<i>cp file_name destination</i> a) cp text.txt /tmp b) cp /chap/robo.php ./excess.php	Copies the file indicated by <i>file_name</i> to the path indicated by <i>destination</i> . a) Copies the file text.txt in the current directory to the tmp directory. b) Copies the file robo.php in the chap directory to the current directory and renames the copy excess.php.
<i>rm file_name</i>	Removes the file indicated by <i>file_name</i> .
<i>mv file_name destination</i>	Moves the file indicated by <i>file_name</i> to the path indicated by <i>destination</i> .
<i>mkdir directory_name</i> a) mkdir spot b) mkdir /tmp/snuggles	Creates a directory named <i>directory_name</i> . a) creates the directory spot in the current directory. b) creates the directory snuggles in the directory tmp.
<i>rmdir directory_name</i>	Removes the directory indicated by <i>directory_name</i> .

Other commands allow the user to change directories and see the contents of a directory.

<i>pwd</i>	Supplies the name of the current directory. While logged in, the user is always “in” a directory. The default initial directory is the user's home directory: /home/<username>
<i>ls [options] directory_name</i>	Lists the files and directories within <i>directory_name</i> . Some useful options are -l for more detailed output and -a which shows hidden system files.
<i>cd directory_name</i>	Changes the directory to the one specified.
<i>cat file_name</i>	Prints the contents of <i>file_name</i> to the screen.

# Appendix A - New User Background Information

---

---

## Shortcuts:

- . (one dot) Represents the current directory.
- .. (two dots) Represents one directory above the current directory (i.e. one directory closer to the base directory).

## The vi Editor

To edit a file using the vi editor, type:

```
vi file_name
```

Vi is a three-state line editor: it has a command mode, a line mode and an editing mode. If in doubt as to which mode you are in, press the <ESC> key which will bring you to the command mode.

Table 14: vi modes

Mode	What is done there	How to get there
Command mode	Navigation within the open file.	Press the <ESC> key.
Editing mode	Text editing.	See list of editing commands below.
Line mode	File saving, opening, etc. Exiting from vi.	From the command mode, type ":" (colon).

When you enter the vi program, you are automatically in command mode. To navigate to the part of the file you wish to edit, use the following keys:

# Appendix A - New User Background Information

---

---

Table 15: vi navigation commands

<i>h</i>	Moves the cursor to the left (left arrow).
<i>j</i>	Moves the cursor to the next line (down arrow).
<i>k</i>	Moves the cursor to the previous line (up arrow).
<i>l</i>	Moves the cursor to the right (right arrow).

Having arrived at the location where text should be changed, use these commands to modify the text (note commands “i” and “o” will move you into edit mode and everything typed will be taken literally until you press the <ESC> key to return to the command mode).

Table 16: vi file modification commands

<i>i</i>	Inserts text before the cursor position (everything to the right of the cursor is shifted right).
<i>o</i>	Creates a new line below the current line and insert text (all lines are shifted down).
<i>dd</i>	Removes the entire current line.
<i>x</i>	Deletes the letter at the cursor position.

After you have finished modifying a file, enter line mode (by typing “:” from command mode) and use one of the following commands:

Table 17: vi line mode commands

<i>w</i>	Saves the file (w is for write).
<i>wq</i>	Saves and closes the file (q is for quit).
<i>q!</i>	Closes the file without saving.
<i>w file</i>	Saves the file with the name <file>.
<i>e file</i>	Opens the file named <file>.

# Appendix A - New User Background Information

---

---

## The Routing Table

The BLACK BOX ® Advanced Console Server has a static routing table that can be seen using the commands:

```
route
```

or

```
netstat -rn
```

The file `/etc/network/st_routes` is the BLACK BOX ® Advanced Console Server's method for configuring static routes. Routes should be added to the file (which is a script run when the BLACK BOX ® Advanced Console Server is initialized) or at the prompt (for temporary routes) using the following syntax:

```
route [add|del] [-net|-host] target netmask nt_msk [gw gt_way]
interf
```

- [add|del]* One of these tags must be present. Routes can be either added or deleted.
- [-net|-host]* Net is for routes to a network and -host is for routes to a single host.
- target* Target is the IP address of the destination host or network.
- netmask* The tag *netmask* and *nt\_mask* are necessary only when subnetting is used, otherwise, a mask appropriate to the target is assumed. *nt\_msk* must be specified in dot notation.
- gw gt\_way* Specifies a gateway, when applicable. *gt\_way* is the IP address or hostname of the gateway.
- interf* The interface to use for this route. Must be specified if a gateway is not. When a gateway is specified, the operating system determines which interface is to be used.



# Appendix A - New User Background Information

---

---

## Secure Shell Session

Ssh is a command interface and protocol often used by network administrators to connect securely to a remote computer. Ssh replaces its non-secure counterpart rsh and rlogin. There are two versions of the protocol, ssh and ssh2. The BLACK BOX ® Advanced Console Server offers both. The command to start an ssh client session from a UNIX workstation is:

```
ssh -t <user>@<hostname>
```

where

```
<user> = <username>:ttySnn or  
        <username>:socket_port or  
        <username>:ip_addr or  
        <username>:serverfarm
```

**Note:** “serverfarm” is a physical port alias. It can be configured in the file pslave.conf.  
**An example:**

```
username:                mycompany  
16-port IP address:      192.168.160.1  
host name:               16-port  
servername for port 1:  file_server
```

**ttyS1 is addressed by IP 10.0.0.1 or socket port 7001. The various ways to access the server connected to the port are:**

```
ssh -t mycompany:ttyS1@16-port  
ssh -t mycompany:7001@16-port  
ssh -t mycompany:10.0.0.1@16-port  
ssh -t mycompany:file_server@16-port
```

# Appendix A - New User Background Information

---

---

```
ssh -t -l mycompany:10.0.0.116-port
```

```
ssh -t -l mycompany:7001 16-port
```

For openssh clients, version 3.1p1 or later ssh2 is the default. In that case, the -1 flag is used for ssh1.

```
ssh -t mycompany:7001@16-port
```

(openssh earlier than 3.1p1 - Advanced Secure Console Port Server

```
ssh -t -2 mycompany:7001@16-port
```

(openssh earlier than 3.1p1 - BLACK BOX® Advanced Console Servers  
ssh -t mycompany:7001@16-port

(openssh 3.1p1 or later - BLACK BOX® Advanced Console Server version 2.1.0 or later -> ssh2 will be used)

```
ssh -t -l mycompany:7001@16-port
```

(openssh 3.1p1 or later - BLACK BOX® Advanced Console Server version 2.1.0 or later -> ssh1 will be used)

To log in to a port that does not require authentication, the username is not necessary:

```
ssh -t -2 :ttyS1@16-port
```

Note: In this case, the file sshd\_config must be changed in the following way:

```
PermitRootLogin Yes
```

```
PermitEmptyPassword Yes
```

Configuring sshd's client authentication using SSH Protocol version 1

**Step 1: Only RhostsAuthentication yes in sshd\_config.**

In the linux host enable in the file /etc/ssh/ssh\_config the parameters:

```
Host *
```

```
    RhostsAuthentication yes
```

# Appendix A - New User Background Information

---

UsePrivilegedPort yes

- One of these:

hostname or ipaddress in /etc/hosts.equiv or  
/etc/ssh/shosts.equiv

hostname or ipaddress and username in ~/.rhosts or ~/.shosts  
and IgnoreRhosts no in sshd\_config

- Client start-up command: `ssh -t <BLACK BOX® Advanced Console Server_ip or Serial_port_ip>` (if the ssh client is running under a session belonging to a username present both in the workstation's database and the BLACK BOX® Advanced Console Server's database).
- Client start-up command: `ssh -t -l <username> <BLACK BOX® Advanced Console Server_ip or Serial_port_ip>` (if the ssh client is running under a session belonging to a username present only in the workstation's database. In this case, the <username> indicated would have to be a username present in the BLACK BOX® Advanced Console Server's database).



**Note:** For security reasons, some ssh clients do not allow just this type of authentication. To access the serial port, the BLACK BOX® Advanced Console Server must be configured for local authentication. No root user should be used as username.

## Step 2: Only RhostsRSAAuthentication yes in sshd\_config.

- One of the RhostsAuthentication settings, described in Step 1.
- Client machine's host key (/etc/ssh\_host\_key.pub) copied into the /tmp/known\_hosts file. The client hostname plus the information inside this file must be appended in one single line inside the file /etc/ssh/ssh\_known\_hosts or ~/.ssh/known\_hosts and IgnoreUserKnownHosts no inside sshd\_config. The following commands can be used for example:

```
echo `n`client_hostname ` >> /etc/ssh/ssh_known_hosts or ~/.ssh/  
known_hosts
```

# Appendix A - New User Background Information

---

---

```
cat /tmp/known_hosts >> /etc/ssh/ssh_known_hosts or ~/.ssh/  
known_hosts
```

- client start-up command: `ssh -t <BLACK BOX ® Advanced Console Server_ip or Serial_port_ip>`



Note: “client\_hostname” should be the DNS name. To access the serial port, the BLACK BOX ® Advanced Console Server must be configured for local authentication. No root user should be used as username.

**Step 3: Only RSAAuthentication yes in sshd\_config.**

- Removal of the BLACK BOX ® Advanced Console Server’s \*.equiv, ~/.?hosts, and \*known\_hosts files.
- Client identity created by ssh-keygen and its public part (~/.ssh/identity.pub) copied into BLACK BOX ® Advanced Console Server’s ~/.ssh/authorized\_keys.
- Client start-up command: `ssh -t <BLACK BOX ® Advanced Console Server_ip or Serial_port_ip>`.

**Step 4: Only PasswordAuthentication yes in sshd\_config.**

- Removal of the BLACK BOX ® Advanced Console Server’s \*.equiv, ~/.?hosts, \*known\_hosts, and \*authorized\_keys files.
- Client startup command: `ssh -t -l <username> <BLACK BOX ® Advanced Console Server_ip or Serial_port_ip>` or `ssh -t -l <username:alias><BLACK BOX ® Advanced Console Server_ip>`.

Configuring sshd's client authentication using SSH Protocol version 2

Only PasswordAuthentication yes in sshd\_config DSA Authentication is the default. (Make sure the parameter PubkeyAuthentication is enabled.)

- Client DSA identity created by ssh-keygen -d and its public part (~/.ssh/id\_dsa.pub) copied into the BLACK BOX ® Advanced Console Server’s ~/.ssh/authorized\_keys2 file.
- Password Authentication is performed if DSA key is not known to the BLACK BOX ® Advanced Console Server. Client start-up command: `ssh -2 -t <TS_ip or Serial_port_ip>`.

# Appendix A - New User Background Information

---

---



Note: All files “~/\*” or “~/.ssh/\*” must be owned by the user and readable only by others. All files created or updated must have their full path and file name inside the file `config_files` and the command `saveconf` must be executed before rebooting the BLACK BOX® Advanced Console Server.

## The Process Table

The process table shows which processes are running. Type `ps -a` to see a table similar to that below.

Table 18: Process table

PID	UID	State	Command
1	root	S	/sbin/inetd
31	root	S	/sbin/sshd
32	root	S	/sbin/cy_ras
36	root	S	/sbin/cy_wdt_led wdt led
154	root	R	/ps -a

To restart the `cy_ras` process use its process ID or execute the command:

```
signal_ras hup
```

This executes the `ps` command, searches for the `cy_ras` process id, then sends the signal `hup` to the process, all in one step. Never kill `cy_ras` with the signals `-9` or `SIGKILL`.

# Appendix A - New User Background Information

---

---

## TS Menu Script

The `ts_menu` script can be used to avoid typing long telnet or ssh commands. It presents a short menu with the names of the servers connected to the serial ports of the BLACK BOX® Advanced Console Server. The server is selected by its corresponding number. `ts_menu` must be executed from a local session: via console, telnet, ssh, dumb terminal connected to a serial port, etc. Only ports configured for console access (protocols `socket_server` or `socket_ssh`) will be presented. To start having familiarity with this application, run `ts_menu -h`:

```
> ts_menu -h
```

```
USAGE: ts_menu options
```

```
-p : Display Ethernet Ip and Tcp port
```

```
-i : Display local Ip assigned to the serial port
```

```
-u <name> : Username to be used in ssh/telnet command
```

```
-U : Allows choosing of different usernames for different ports
```

```
-h : print this help message
```

```
> ts_menu
```

```
Master and Slaves Console Server Connection Menu
```

```
1 TSJen800
```

```
2 edson-r4.mycompany.com
```

```
3 az84.mycompanys.com
```

```
4 64.186.190.85
```

```
5 az85.mycompany.com
```

```
Type 'q' to quit, a valid option [1-5], or anything else to  
refresh:
```

By selecting 1 in this example, the user will access the local serial ports on that BLACK BOX® Advanced Console Server. If the user selects 2 through 5, remote serial ports will be

# Appendix A - New User Background Information

---

---

accessed. This is used when there is clustering (one BLACK BOX ® Advanced Console Server master box and one or more BLACK BOX ® Advanced Console Server slave boxes).

If the user selects 1, the following screen is displayed:

```
Serial Console Server Connection Menu for your Master Terminal
Server
```

```
1 ttyS1 2 ttyS2 3 s3serverfarm
```

```
Type 'q' to quit, 'b' to return to previous menu, a valid option[1-
3], or anything else to refresh:
```

Options 1 to 3 in this case are serial ports configured to work as a CAS profile. Serial port 3 is presented as an alias name (s3serverfarm). When no name is configured in pslave.conf, ttyS<N> is used instead. Once the serial port is selected, the username and password for that port (in case there is a per-user access to the port and -U is passed as parameter) will be presented, and access is granted.

To access remote serial ports, the presentation will follow a similar approach to the one used for local serial ports.

The ts\_menu script has the following line options:

**-p** : Displays Ethernet IP Address and TCP port instead of server names.

```
BLACK BOX ® Advanced Console Server: Serial Console Server Connec-
tion menu
```

```
1 209.81.55.79 7001 2 209.81.55.79 7002 3 209.81.55.79 7003
```

```
4 209.81.55.79 7004 5 209.81.55.79 7005 6 209.81.55.79 7006
```

```
Type 'q' to quit, a valid option [1-6], or anything else to refresh
:
```

**-i** : Displays Local IP assigned to the serial port instead of server names.

```
BLACK BOX ® Advanced Console Server: Serial Console Server Connec-
tion menu
```

# Appendix A - New User Background Information

---

---

1 192.168.1.101 2 192.168.1.102 3 192.168.1.103 4 192.168.1.104  
5 192.168.1.105 6 192.168.1.106

Type 'q' to quit, a valid option [1-6], or anything else to refresh  
:

**-u <name>** : Username to be used in the ssh/telnet command. The default username is that used to log onto the BLACK BOX ® Advanced Console Server.

**-h** : Lists script options.



# Appendix B - Cabling, Hardware, & Electrical

## General Hardware Specifications

The power requirements, environmental conditions and physical specifications of the BLACK BOX ® Advanced Console Server are listed below.

Table 20: BLACK BOX ® Advanced Console Server power requirements

Power Specifications		
	LS1016A	LS10132A
Input Voltage Range	Internal 100-240VAC autorange (-48VDC option available)	Internal 100-240VAC autorange (-48VDC option available)
Input Frequency Range	50/60H	50/60H
Power @120VAC	22 W max	26 W max
Power @220 VAC	28 W max	37 W max

Table 21: BLACK BOX ® Advanced Console Server environmental conditions

Environmental Information		
	LS1016A	LS1032A
Operating Temperature	50F to 112F (10°C to 44°C)	50F to 112F (10°C to 44°C)
Relative Humidity	10 - 90%, non-condensing	10 - 90%, non-condensing

# Appendix B - Cabling, Hardware, & Electrical

---

---

Table 22: BLACK BOX ® Advanced Console Server physical conditions

Physical Information		
	LS1016A	LS1032A
External Dimensions	17 in. x 8.5 in. x 1.75 in.	17 in. x 8.5 in. x 1.75 in.
Weight	6 lb.	6.2 lb.

Table 23: BLACK BOX ® Advanced Console Server safety specifications

Safety Information		
	LS1016A	LS1032A
Approvals	FCC and CE, Class A	

The following section has all the information you need to quickly and successfully purchase or build cables to the Advanced Secure Console Port Server. It focuses on information related to the RS-232 interface, which applies not only to the Advanced Secure Console Port Server but also to any RS-232 cabling.

# Appendix B - Cabling, Hardware, & Electrical

---

## Rear Panel LEDs

The Advanced Secure Console Port Server rear panel has connectors (serial, console and Ethernet) with some LEDs that have the following functionalities:

### Ethernet Connector

<i>Col</i> ( <i>collision</i> )	Shows <i>collision</i> on the LAN every time the unit tries to transmit an Ethernet packet.
<i>DT/LK</i> ( <i>data transaction</i> <i>/link state</i> )	DT flashes when there's data transmitted to or received from the LAN. It's hardware-controlled. LK keeps steady if the LAN is active. The green LED is <i>Data Transaction</i> activity and the yellow one is <i>LinK state</i> .
<i>100</i>	If 100BT is detected the LED lights on. If 10BT is detected it turns off.

### Console Connector

<i>CP</i>	CPU activity. It flashes at roughly 1 second intervals.
<i>P1</i>	Power supply #1 ON.
<i>P2</i>	Power supply #2 ON.

### Serial Connector

<i>LK</i>	DTR. It's software-controlled.
<i>DT</i>	Data transmitted to or received from the serial line. It's hardware-controlled.

# Appendix B - Cabling, Hardware, & Electrical

---

---

## The RS-232 Standard

RS-232C, EIA RS-232, or simply RS-232 refer to a standard defined by the Electronic Industries Association in 1969 for serial communication. More than 30 years later, more applications have been found for this standard than its creators could have imagined. Almost all electronic devices nowadays have serial communication ports.

RS-232 was defined to connect Data Terminal Equipment, (DTE, usually a computer or terminal) to Data Communication Equipment (DCE, usually a modem):

DTE > RS-232 > DCE > communication line > DCE > RS-232 > DTE

RS-232 is now mostly being used to connect DTE devices directly (without modems or communication lines in between). While that was not the original intention, it is possible with some wiring tricks. The relevant signals (or wires) in a RS-232 cable, from the standpoint of the computer (DTE), are:

<i>Receive Data (RxD) and Transmit Data (TxD)</i>	The actual data signals
<i>Signal Ground (Gnd)</i>	Electrical reference for both ends
<i>Data Terminal Ready (DTR)</i>	Indicates that the computer (DTE) is active
<i>Data Set Ready (DSR)</i>	Indicates that the modem (DCE) is active.
<i>Data Carrier Ready (DCD)</i>	Indicates that the connection over the communication line is active
<i>CTS (Clear to Send, an input)</i>	Flow control for data flowing from DTE to DCE
<i>RTS (Request to Send, an output)</i>	Flow control for data flowing from DCE to DTE

Not all signals are necessary for every application, so the RS-232 cable may not need all 7 wires. The RS-232 interface defines communication parameters such as parity, number of bits per character, number of stop-bits and the baud rate. Both sides must be configured with the same parameters. That is the first thing to verify if you think you have the correct cable and things still do not work. The most common configuration is 8N1 (8 bits of data per character, no parity bit included with the data, 1 stop-bit to indicate the end of a character). The baud rate in a RS-232 line translates directly into the data speed in bits per second (bps). Usual

# Appendix B - Cabling, Hardware, & Electrical

---

---

transmission speeds range between 9,600 bps and 19,200bps (used in most automation and console applications) to 115,200 bps (used by the fastest modems).

## Cable Length

The original RS-232 specifications were defined to work at a maximum speed of 19,200 bps over distances up to 15 meters (or about 50 feet). That was 30 years ago. Today, RS-232 interfaces can drive signals faster and through longer cables.

As a general rule, consider:

- If the speed is lower than 38.4 kbps, you are safe with any cable up to 30 meters (100 feet)
- If the speed is 38.4 kbps or higher, cables should be shorter than 10 meters (30 feet)
- If your application is outside the above limits (high speed, long distances), you will need better quality (low impedance, low-capacitance) cables.

Successful RS-232 data transmission depends on many variables that are specific to each environment. The general rules above are empirical and have a lot of safety margins built-in.

# Appendix B - Cabling, Hardware, & Electrical

## Connectors

The connector traditionally used with RS-232 is the 25-pin D-shaped connector (DB-25). Most analog modems and most older computers and serial equipment use this connector. The RS-232 interface on DB-25 connector always uses the same standard pin assignment.

The 9-pin D-shaped connector (DB-9) saves some space and is also used for RS-232. Most new PC COM ports and serial equipment (specially when compact size is important) uses this connector. RS-232 interfaces on DB-9 connectors always use the same standard pin assignment.

The telephone-type modular RJ-45 plug and jack are very compact, inexpensive and compatible with the phone and Ethernet wiring systems present in most buildings and data centers. Most networking equipment and new servers use RJ-45 connectors for serial communication. Unfortunately there is no standard RS-232 pin assignment for RJ-45 connectors. Every equipment vendor has its own pin assignment.

Most connectors have two versions. The ones with pins are said to be “male” and the ones with holes are said to be “female.”

Table 24: Cables and their pin specifications

RS-232 Signal	Name/Function (Input/Output)	DB-25 pins (Standard)	DB-9 pins (Standard)	RJ-45 pins (Black Box)
Chassis	Safety Ground	1	Shell	Shell
TxD	Transmit Data (O)	2	3	3
RxD	Receive Data (I)	3	2	6
DTR	Data Terminal Ready (O)	20	4	2
DSR	Data Set Ready (I)	6	6	8
DCD	Data Carrier Detect (I)	8	1	7
RTS	Request To Send (O)	4	7	1
CTS	Clear To Send (I)	5	8	5
Gnd	Signal Ground	7	5	4

# Appendix B - Cabling, Hardware, & Electrical

---

---

## Straight-Through vs. Crossover Cables

The RS-232 interface was originally intended to connect a DTE (computer, printer and other serial devices) to a DCE (modem) using a straight-through cable (all signals on one side connecting to the corresponding signals on the other side one-to-one). By using some “cabling tricks,” we can use RS-232 to connect two DTEs as is the case in most modern applications.

A crossover (a.k.a. null-modem) cable is used to connect two DTEs directly, without modems or communication lines in between. The data signals between the two sides are transmitted and received and there are many variations on how the other control signals are wired. A “complete” crossover cable would connect TxD with RxD, DTR with DCD/DSR, and RTS with CTS on both sides. A “simplified” crossover cable would cross TxD and RxD and locally short-circuit DTR with DCD/DSR and RTS with CTS.

## Which cable should be used?

First, look up the proper cable for your application in the table below. Next, purchase standard off-the-shelf cables from a computer store or cable vendor. For custom cables, refer to the cable diagrams to build your own cables or order them from Black Box or a cable vendor.

Table 25: Which cable to use

To Connect To	Use Cable
DCE DB-25 Female (standard) <ul style="list-style-type: none"><li>• Analog Modems</li><li>• ISDN Terminal Adapters</li></ul>	Cable 1: RJ-45 to DB-25 M straight-through (Custom). This custom cable can be ordered from Black Box or other cable vendors. A sample is included with the product (“straight-through”).

# Appendix B - Cabling, Hardware, & Electrical

Table 25: Which cable to use

To Connect To	Use Cable
DTE RJ-45 Black Box (custom) <ul style="list-style-type: none"><li>All Black Box Console Ports</li></ul>	Cable 2: RJ-45 to RJ-45 crossover (custom). A sample is included with the product (“straight-through”) This custom cable can be ordered from Black Box or other cable vendors using the provided wiring diagram.

## Cable Diagrams

Before using the following cable diagrams refer to the tables above to select the correct cable for your application. Sometimes, crossover cables are wired slightly differently depending on the application. A “complete” crossover cable would connect the TxD with RxD, DTR with DCD/DSR, and RTS with CTS across both sides. A “simplified” crossover cable would cross TxD and RxD and locally short-circuit DTR with DCD/DSR and RTS with CTS.

Most of the diagrams in this document show the “complete” version of the crossover cables, with support for modem control signals and hardware flow control. Applications that do not require such features have just to configure NO hardware flow control and NO DCD detection on their side. Both ends should have the same configuration for better use of the complete version of the cables.


*These cables appear in Cable Package #1 and/or Cable Package #2. You may or may not find them in your box depending on which package you received.*



# Appendix B - Cabling, Hardware, & Electrical

## Cable #1: Black Box RJ-45 to DB-25 Male, straight-through


Application: This cable connects Black Box products (serial ports) to modems and other DCE RS-232 devices. It is included in both Cable Package #1 and #2.



*Figure 28: Cable 1 - Black Box RJ-45 to DB-25 Male, straight-through*

## Cable #2: Black Box RJ-45 to DB-25 Female/Male, crossover

This cable connects Black Box products (serial ports) to console ports, terminals, printers and other DTE RS-232 devices. If you are using Cable Package #1, after connecting the appropriate adapter to the RJ-45 straight-through cable, you will essentially have the cable shown in this picture. If you are using Cable Package #2, no assembly is required. You will have the cable shown below.





*Figure 29: Cable 2 - Black Box RJ-45 to DB-25 Female/Male, crossover*

# Appendix B - Cabling, Hardware, & Electrical

## Cable #3: Black Box RJ-45 to DB-9 Female, crossover



This cable connects Black Box products (serial ports) to console ports, terminals, printers and other DTE RS-232 devices. If you are using Cable Package #1, after connecting the appropriate adapter to the RJ-45 straight-through cable, you will essentially have the cable shown in this picture. If you are using Cable Package #2, no assembly is required. You will have the cable shown below.



*Figure 30: Cable 3 - Black Box RJ-45 to DB-9 Female, crossover*

## Cable #4: Black Box RJ-45 to Black Box RJ-45, straight-through

This cable is the main cable that you will use. Along with one of the adapters provided (RJ-45 to DB-9 or RJ-45 to DB-25) you can create a crossover cable like the ones explained in Cable #2 or #3 for configuration or to connect to a server. This cable is only included in Cable Package. #1.




*Figure 31: Cable 4 - Black Box RJ-45 to Black Box RJ-45, straight-through*

# Appendix B - Cabling, Hardware, & Electrical

## Cable #5: Black Box/Sun Netra Cable

This Adapter attaches to a Cat 3 or Cat 5 network cable. It is usually used in console management applications to connect Black Box products to a Sun Netra server or to a Cisco product. This cable is included in Cable Package #2.




*Figure 32: Cable 5 - Black Box/Sun Netra Cable*

## Adapters

The following four adapters are included in the product box. A general diagram is provided below and then a detailed description is included for each adapter.

### Loop-Back Connector for Hardware Test

The use of the following DB-25 connector is explained in the Troubleshooting chapter. It is included in both Cable Package #1 and #2.




*Figure 33: Loop-Back Connector*

# Appendix B - Cabling, Hardware, & Electrical

## Black Box\Sun Netra Adapter



This Adapter attaches to a Cat 3 or Cat 5 network cable. It is usually used in console management applications to connect Black Box products to a Sun Netra server or to a Cisco product. At one end of the adapter is the black CAT.5e Inline Coupler box with a female RJ-45 terminus, from which a 3-inch-long black Sun Netra-labeled cord extends, terminating in an RJ-45 male connector. This adapter is included in Cable Package #2.



*Figure 34: Black Box\Sun Netra Adapter*

## RJ-45 Female to DB-25 Male Adapter

The following adapter may be necessary. It is included in Cable Package #1.




*Figure 35: RJ-45 Female to DB-25 Male Adapter*

# Appendix B - Cabling, Hardware, & Electrical

## RJ-45 Female to DB-25 Female Adapter


The following adapter may be necessary. It is included in Cable Package #1.



**Figure 36: RJ-45 Female to DB-25 Female Adapter**

## RJ-45 Female to DB-9 Female Adapter

The following adapter may be necessary. This is included in Cable Package #1.



**Figure 37: RJ-45 Female to DB-9 Female Adapter**

## Appendix B - Cabling, Hardware, & Electrical

---

---

This page has been left intentionally blank.

# Appendix C - The pslave Configuration File

## Introduction

This chapter begins with a table containing parameters common to all profiles, followed by tables with parameters specific to a certain profile. You can find samples of the pslave configuration files (pslave.conf, .cas, .ts, and .ras) in the /etc/portslave directory in the BLACK BOX® Advanced Console Server box.

## Configuration Parameters

### CAS, TS, and Dial-in Common Parameters

The parameters on the following table are common to all three profiles:

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
conf.dhcp_client	It defines the dhcp client operation mode. Valid values: 0 - DHCP disabled 1 - DHCP active 2 - DHCP active and the unit saves in flash the last IP assigned by the DHCP server (default).	1 Also see Description column .
conf.eth_ip_alias	Secondary IP address for the Ethernet interface (needed for clustering feature).	209.81.55.10
conf.eth_mask_alias	Mask for the secondary IP address above.	255.255.255.0
conf.rlogin	It defines the location of rlogin utility <i>Note: This is a parameter specific to TS profile.</i>	Ex: /bin/rlogin

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
conf.facility	The local facility sent to syslog-ng from PortSlave.	1 - 7
conf.group	Used to group users to simplify the configuration of the parameter all.users later on. This parameter can be used to define more than one group.	group_name: user1, user2
conf.eth_ip	Configured in <a href="#">Task 4: Edit the pslave.conf file in Chapter 2 - Installation, Configuration, and Usage</a> . This is the IP address of the Ethernet interface. This parameter, along with the next two, is used by the cy_ras program to OVERWRITE the file /etc/network/ifcfg_eth0 as soon as the command “signal_ras hup” is executed. The file /etc/network/ifcfg_eth0 should not be edited by the user unless the cy_ras configuration is not going to be used.	200.200.200. 1
conf.eth_mask	The mask for the Ethernet network.	255.255.255. 0
conf.eth_mtu	The Maximum Transmission Unit size, which determines whether or not packets should be broken up.	1500
conf.lockdir	The lock directory, which is /var/lock for the BLACK BOX® Advanced Console Server. It should not be changed unless the user decides to customize the operating system.	/var/lock



# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.dcd	DCD signal (sets the tty parameter CLOCAL). Valid values are 0 or 1. If all.dcd=0, a connection request will be accepted regardless of the DCD signal and the connection will not be closed if the DCD signal is set to DOWN. If all.dcd=1 a connection request will be accepted only if the DCD signal is UP and the connection will be closed if the DCD signal is set to DOWN.	0
all.users	Restricts access to ports by user name (only the users listed can access the port or, using the character “!”, all but the users listed can access the port.) In this example, the users joe, mark and members of user_group cannot access the port. A single comma and spaces/tabs may be used between names. A comma may not appear between the “!” and the first user name. The users may be local, Radius or TacacsPlus. User groups (defined with the parameter conf.group) can be used in combination with user names in the parameter list. Notice that these are common users, not administrators.	! joe, mark, user_group

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.issue	<p>This text determines the format of the login banner that is issued when a connection is made to the BLACK BOX® Advanced Console Server. \n represents a new line and \r represents a carriage return. Expansion characters can be used here.</p> <p><i>Value for this Example:</i></p> <pre>\r\n\ Welcome to terminal server %h port S%p \r\n\</pre>	See Description column
all.prompt	<p>This text defines the format of the login prompt. Expansion characters can be used here.</p>	%h login:
all.media	<p>It defines media type RS232/RS484 and operation mode half/full duplex.</p> <p><i>Valid values for all products :</i></p> <pre>rs232           - RS232 (default value). rs232_half     - RS232 with RTS legacy                 half duplex rs232_half_cts - RS232 with RTS legacy                 half duplex and CTS control</pre>	See Description column
all.netmask	<p>It defines the network mask for the serial port.</p>	255.255.255.255
all.mtu	<p>It defines the maximum transmit unit</p>	1500
all.mru	<p>It defines the maximum receive unit</p>	1500
all.sysutmp	<p>It defines whether portslave must write login records.</p>	yes/no

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
<code>all.syswtm</code>	It defines whether portslave must write login records.	yes/no
<code>all.sttyCmd</code>	<p>The TTY is programmed to work as configured and this user-specific configuration is applied over that serial port. Parameters must be separated by a space. The following example sets :</p> <p><i>-igncr</i> This tells the terminal not to ignore the carriage-return on input,</p> <p><i>-onlcr</i> Do not map newline character to a carriage return or newline character sequence on output,</p> <p><i>opost</i> Post-process output,</p> <p><i>-icrnl</i> Do not map carriage-return to a newline character on input.</p> <pre>all.sttyCmd -igncr -onlcr opost -icrnl</pre>	commented

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.utmpfrom	<p>It allow the administrator to customize the field "FROM" in the login records (utmp file). It is displayed in the "w" command.</p> <p>Ex: "%g:%P.%3.%4"</p> <p>%g : process id            %P : Protocol            %3 : Third nibble of remote IP            %J : Remote IP</p> <p>Note: In the pslave.conf file there is a list of all expansion variables available.</p>	See Description Column
all.radnullpass	It defines whether the access to users with null password in the radius server must be granted or not.	yes/no
all.speed	The speed for all ports.	9600
all.datasize	The data size for all ports.	8
all.stopbits	The number of stop bits for all ports.	1
all.parity	The parity for all ports.	none
all.authhost1	This address indicates the location of the Radius/TacacsPlus authentication server and is only necessary if this option is chosen in the previous parameter. A second Radius/TacacsPlus authentication server can be configured with the parameter all.authhost2.	200.200.200.2

# Appendix C - The pslave Configuration File

---

---

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.accthost1	This address indicates the location of the Radius/TacacsPlus accounting server, which can be used to track how long users are connected after being authorized by the authentication server. Its use is optional. If this parameter is not used, accounting will not be performed. If the same server is used for authentication and accounting, both parameters must be filled with the same address. A second Radius/TacacsPlus accounting server can be configured with the parameter all.accthost2.	200.200.200.2

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.authtype	<p>Configured in <a href="#">Task 4: Edit the pslave.conf file in Chapter 2 - Installation, Configuration, and Usage</a>. Type of authentication used. There are several authentication type options:</p> <ul style="list-style-type: none"><li>• <i>none</i> (no authentication)</li><li>• <i>local</i> (authentication is performed using the <code>/etc/passwd</code> file)</li><li>• <i>remote</i> (This is for a terminal profile only. The unit takes in a username but does not use it for authentication. Instead it passes it to the remote server where it is then used for authentication.)</li><li>• <i>radius</i> (authentication is performed using a Radius authentication server)</li><li>• <i>TacacsPlus</i> (authentication is performed using a TacacsPlus authentication server)</li><li>• <i>ldap</i> (authentication is performed against an ldap database using an ldap server. The IP address and other details of the ldap server are defined in the file <code>/etc/ldap.conf</code>)</li><li>• <i>kerberos</i> (authentication is performed using a kerberos server. The IP address and other details of the kerberos server are defined in the file <code>/etc/krb5.conf</code>)</li></ul>	local

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
	<ul style="list-style-type: none"> <li>• <i>local/radius</i> (authentication is performed locally first, switching to Radius if unsuccessful)</li> <li>• <i>radius/local</i> (the opposite of the previous option)</li> <li>• <i>local/TacacsPlus</i> (authentication is performed locally first, switching to TacacsPlus if unsuccessful)</li> <li>• <i>TacacsPlus/local</i> (the opposite of the previous option)</li> <li>• <i>RadiusDownLocal</i> (local authentication is tried only when the Radius server is down)</li> <li>• <i>TacacsPlusDownLocal</i> (local authentication is tried only when the TacacsPlus server is down)</li> </ul> <p>Note that this parameter controls the authentication required by the BLACK BOX<sup>®</sup> Advanced Console Server. The authentication required by the device to which the user is connecting is controlled separately.</p>	
all.radtimeout	This is the timeout (in seconds) for a Radius/TacacsPlus authentication query to be answered. The first server (authhost1) is tried “radretries” times, and then the second (authhost2), if configured, is contacted “radretries” times. If the second also fails to respond, Radius/TacacsPlus authentication fails.	3

# Appendix C - The pslave Configuration File

Table 26: Parameters Common to CAS, TS, & Dial-in Access

Parameter	Description	Value for this Example
all.radretries	Defines the number of times each Radius/TacacsPlus server is tried before another is contacted. The default, if not configured, is 5.	5
all.secret	This is the shared secret necessary for communication between the BLACK BOX <sup>®</sup> Advanced Console Server and the Radius/TacacsPlus servers.	secret
all.flow	This sets the flow control to hardware, software, or none.	hard
all.protocol	The default CAS setup was explained in Chapter 2, <a href="#">Task 4: Edit the pslave.conf file</a> . The TS configuration settings are in <a href="#">Table 28, “TS Parameters,” on page 331</a> . The Dial-in configuration settings are in <a href="#">Table 29, “Dial-in configuration Parameters,” on page 333</a> . For Power Management, see the section <a href="#">“Appendix J - Power Management” on page 451</a> .	socket_server
sX.pmoutlet	sX indicates the serial port number to which the PM hardware is connected. The pmoutlet part of the parameter indicates the outlet # on the PM hardware that manages the server/network equipment in question.	8
s1.tty	The device name for the port is set to the value given in this parameter. If a device name is not provided for a port, it will not function.	ttyS1



# Appendix C - The pslave Configuration File

---

## CAS Parameters

You can configure additional CAS features with the parameters given on the following tables. (The is used as an example in some parameters.

In addition to the above parameters which are common to all local and remote access scenarios, you can also configure the following parameters for additional options. Many of the parameters are unique to CAS, but some also apply to TS and Dial-in port profiles. This is indicated in these instances.

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
conf.nfs_data_buffering	This is the Remote Network File System where data captured from the serial port will be written instead of being written to the local directory <i>/var/run/DB</i> . The directory tree to which the file will be written must be NFS-mounted, so the remote host must have NFS installed and the administrator must create, export and allow reading/writing to this directory. The size of this file is not limited by the value of the parameter <i>all.data_buffering</i> , though the value cannot be zero since a zero value turns off data buffering. The size of the file is dependent on the NFS server only (hard drive, partition size, etc.).	commented
conf.DB_facility	This value (0-7) is the Local facility sent to the syslog with the data when <i>syslog_buffering</i> is active. The file <i>/etc/syslog-ng/syslog-ng.conf</i> contains a mapping between the facility number and the action (see more on <a href="#">Syslog</a> in Chapter 3).	0

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
<code>conf.nat_clustering_ip</code>	IP address of any BLACK BOX ® Advanced Console Server interface (master box). It is a public IP address (e.g. Ethernet's interface IP address) and it is the one that must be used to connect the slave's serial ports. You can use the same value assigned to the Ethernet's IP address as that of the master box in the chain.	64.186.161.108
<code>all.ipno</code>	This is the default IP address of the BLACK BOX ® Advanced Console Server 's serial ports. The "+" indicates that the first port should be addressed as 192.168.1.101 and the following ports should have consecutive values. Any host can access a port using its IP address as long as a path to the address exists in the host's routing table.	192.168.170.101+
<code>all.netmask</code>	It defines the network mask for the serial port.	255.255.255.255
<code>all.DTR_reset</code>	This parameter specifies the behavior of the DTR signal in the serial port. If set to zero the DTR signal will be ON if there is a connection to the serial port, otherwise OFF. If set from 1 to 99 the DTR signal will be always ON. A value greater or equal 100 specifies for how long (in milliseconds) the DTR signal will be turned off before it is turned back on again when a connection to the serial port is closed.	100
<code>all.break_sequence</code>	This parameter is the string that is used to send a break to the TTY. It is only valid if TTY protocol is <code>socket_ssh</code> or <code>socket_server</code> .	~break
<code>all.break_interval</code>	This parameter defines the break duration in milliseconds. It is valid if TTY protocol is <code>socket_ssh</code> ,	<code>socket_server</code> or <code>ssh-2 (client)</code>

# Appendix C - The pslave Configuration File

---

---

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
<code>all.lf_suppress</code>	This can be useful because telneting (from DOS) from some OS such as Windows 98 causes produces an extra line feed so two prompts appear whenever you press Enter. When set to 1, line feed suppression is active which will eliminate the extra prompt. When set to 0 (default), line feed suppression is not active.	0
<code>all.auto_answer_input</code>	This parameter works in conjunction with <code>all.auto_answer_output</code> . It allows you to configure a string that will be matched against all data coming in from the tty (remote server). If there is a match, the configured output string ( <code>auto_answer_output</code> ) will then be send back to the tty. This parameter works only when there is no session to the port. If un-commented and a string of bytes is set, matching occurs whenever there is not session established to the port. If this parameter is commented out, then no checking and matching occurs. (See more on the usage of this parameter in Terminal Appearance in Chapter 3.)	commented

# Appendix C - The pslave Configuration File

---

---

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
<code>all.auto_answer_output</code>	This parameter works in conjunction with <code>all.auto_answer_input</code> . It allows you to configure a string that is sent back to the remote server whenever the incoming data remote server matches with <code>all.auto_answer_input</code> . This parameter works only when there is no session to the port. If this parameter is commented, then nothing will be sent back to the remote server even if <code>all.auto_answer_input</code> is uncommented. If this parameter is uncommented and if <code>all.auto_answer_input</code> is also uncommented, then the string configured will be sent back to the remote server. (See more on the usage of this parameter in Terminal Appearance in Chapter 3.)	commented
<code>all.poll_interval</code>	Valid only for protocols <code>socket_server</code> and <code>raw_data</code> . When not set to zero, this parameter sets the wait for a TCP connection keep-alive timer. If no traffic passes through the BLACK BOX® Advanced Console Server for this period of time, the BLACK BOX® Advanced Console Server will send a line status message to the remote device to see if the connection is still up. If not configured, 1000 ms is assumed (the unit for this parameter is ms). If set to zero, line status messages will not be sent to the socket client.	0

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
all.socket_port	<p>In the CAS profile, this defines an alternative labeling system for the BLACK BOX<sup>®</sup> Advanced Console Server ports. The “+” after the numerical value causes the serial interfaces to be numbered consecutively. In this example, serial interface 1 is assigned the port value 7001, serial interface 2 is assigned the port value 7002, etc. One example on how this could be used is in the case of all.protocol or s&lt;n&gt;.protocol socket_ssh and the port value (7001, 7002, etc), if supplied by the ssh client like username:port value, the ssh client will be directly connected with the serial interface.</p> <p>For TS, this parameter is valid only all.protocol is configured as socket_cliente or telnet. It is the TCP port number of the application that will accept connection requested by this serial port.</p>	7001+

# Appendix C - The pslave Configuration File

---

---

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
all.data_buffering	<p>A non zero value activates data buffering (local or remote, according to what was configured in the parameter <code>conf.nfs_data_buffering</code> see <a href="#">Data Buffering</a> in Chapter 3). If local data buffering, a file is created on the BLACK BOX® Advanced Console Server; if remote, a file is created through NFS in a remote server. All data received from the port is captured in this file. If local data buffering, this parameter means the maximum file size (in bytes). If remote, this parameter is just a flag to activate (greater than zero) or deactivate data buffering. When local data buffering is used, each time the maximum is reached the oldest 10% of stored data is discarded, releasing space for new data (FIFO system) - circular file. When remote data buffering is used, there's no maximum file size other than the one imposed by the remote server - linear file. This file can be viewed using the normal Unix tools (<code>cat</code>, <code>vi</code>, <code>more</code>, etc.). <i>Size is in bytes not kilobytes.</i> See <a href="#">Data Buffering</a> for details.</p>	0

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
all.DB_mode	When configured as cir for circular format, the buffer works like a revolving file at all times. The file is overwritten whenever the limit of the buffer size (as configured in all.data_buffering or s<n>.data_buffering) is reached. As for linear format (lin), once the limit of the kernel buffer size is reached (4k), a flow control stop (RTS off or XOFF-depending on how all.f low or s<n>.flow is set) is issued automatically to the remote device so that it will stop sending data to the serial port. Then, when a session is established to the serial port, the data in the buffer is shown to the user if not empty (dont_show_DBmenu parameter assumed to be 2), cleared, and a flow control start (RTS on or XON) is issued to resume data transmission. Once exiting the session, linear data buffering resumes. If all.flow or s<n>.flow is set to none, linear buffering is not possible as there is no way to stop reception through the serial line. Default is cir.	cir
all.DB_timestamp	Records the time stamp in the data buffering file (1) or not (0). If it is configured as 1, the software will accumulate input characters until it receives a CR and LF from the serial port or the accumulated data reaches 256 characters. Either way, the accumulated data will be recorded in the data buffering file along with the current time. The parameter all.data_buffering has to be with a non-zero value for this parameter to be meaningful.	0

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
all.syslog_buffering	When non zero, the contents of the data buffer are sent to the syslogng every time a quantity of data equal to this parameter is collected. The syslog level for data buffering is hard coded to level 5 (notice) and facility local[0+conf.DB_facility]. The file /etc/syslog-ng/syslog-ng.conf should be set accordingly for the syslog-ng to take some action. (See <a href="#">Syslog-ng Configuration to use with Syslog Buffering Feature.</a> )	0
all.syslog_sess	Syslog_buffering must be activated for the following to work. When 0, syslog messages are always generated whether or not there is a session to the port sending data to the unit. When 1, syslog messages are NOT generated when there IS a session to the port sending data to the unit, but resumes generation of syslog messages when there ISN'T a session to the port.	0
all.dont_show_DBmenu	When zero, a menu with data buffering options is shown when a nonempty data buffering file is found. When 1, the data buffering menu is not shown. When 2, the data buffering menu is not shown but the data buffering file is shown if not empty. When 3, the data buffering menu is shown, but without the erase and show and erase options.	1



# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
all.alarm	When non zero, all data received from the port are captured and sent to syslog-ng with level INFO and local[0+conf.DB_facility]facility. The syslogng.conf file should be set accordingly, for the syslog-ng to take some action (please see <a href="#">Generating Alarms</a> in Chapter 3 - Additional Features for the syslog-ng configuration file).	0
all.billing_eor	Defines the character sequence that terminates each billing record. Any character sequence is valid, including '\r' or '^M' (carriage return), '\n' or '^J' (new line), etc..."	Default value: "\n"
all.sniff_mode	This parameter determines what other users connected to the very same port (see parameter admin_users below) can see of the session of the first connected user (main session): <i>in</i> shows data written to the port, <i>out</i> shows data received from the port, and <i>i/o</i> shows both streams. The second and later sessions are called sniff sessions and this feature is activated whenever the protocol parameter is set to socket_ssh or socket_server.	out
all.admin_users	This parameter determines which users can receive the sniff session menu. Then they have options to open a sniff session or cancel a previous session. When users want access per port to be controlled by administrators, this parameter is obligatory and authtype must not be none. User groups (defined with the parameter conf.group) can be used in combination with user names in the parameter list.	peter, john, user_group

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
<code>all.multiple_sessions</code>	Allows users to open more than one common and sniff session on the same port. The options are “yes,” “no,” “RW_session,” or “sniff_session.” Default is set to “no.” Please see <a href="#">Session Sniffing</a> in Chapter 3 for details.	no
<code>all.escape_char</code>	This parameter determines which character must be typed to make the session enter “menu mode”. The possible values are <CTRL-a> to <CTRL-z>. Represent the CTRL with '^'. This parameter is only valid when the port protocol is <code>socket_server</code> or <code>socket_ssh</code> . Default value is '^z'.	^z
<code>all.tx_interval</code>	Valid for protocols <code>socket_server</code> and <code>raw_data</code> . Defines the delay (in milliseconds) before transmission to the Ethernet of data received through a serial port. If not configured, 100ms is assumed. If set to zero or a value above 1000, no buffering will take place.	100
<code>all.idletimeout</code>	Specifies how long (in minutes) a connection can remain inactive before it is cut off. If it set to zero, the connection will not time out.	0
<code>s1.serverfarm</code>	Alias name given to the server connected to the serial port. <code>Server_connected</code> .	serial1
<code>s1.pool_ipno</code>	This is the default IP of the BLACK BOX® Advanced Console Server's pool of serial ports. Any host can access a port from the pool using its pool's IP address as long as a path to the address exists in the host's routing table.	192.168.2.1

# Appendix C - The pslave Configuration File

Table 27: Mostly CAS-specific Parameters

Parameter	Description	Value for this Example
s1.pool_socket_port	In the CAS profile, this defines an alternative labeling system for the BLACK BOX <sup>®</sup> Advanced Console Server pool of ports. In this example, serial interface 1 is assigned to the pool identified by port value 3001. Using s<serial port #>.pool_socket_port one can assign each serial interface to a different pool of ports. One serial interface can belong to just one pool of ports. Each pool of ports can have any number of serial interfaces.	3000
s1.pool_serverfarm	Alias name given to the pool where this serial interface belong to.	pool_1
s2.tty	It defines the physical device name associated to the serial port (without the /dev/).	ttyS2
s8.tty	It defines the physical device name associated to the serial port (without the /dev/).	ttyS8

## TS Parameters

The following parameters are unique to a TS setup except where indicated.

Table 28: TS Parameters

Parameter	Description	Value for this Example
conf.telnet	Location of the telnet utility	/usr/bin/telnet

# Appendix C - The pslave Configuration File

Table 28: TS Parameters

Parameter	Description	Value for this Example
conf.ssh	Location of the ssh utility.	/bin/ssh
conf.locallogins	This parameter is only necessary when authentication is being performed for a port. When set to one, it is possible to log in to the BLACK BOX ® Advanced Console Server directly by placing a “!” before your login name, then using your normal password. This is useful if the Radius authentication server is down.	0
all.host	The IP address of the host to which the terminals will connect.	200.200.200.3
all.term	This parameter defines the terminal type assumed when performing rlogin or telnet to other hosts.	vt100
all.userauto	Username used when connected to a UNIX server from the user’s serial terminal.	
all.protocol (for TS)	For the terminal server configuration, the possible protocols are login (which requests username and password), rlogin (receives username from the BLACK BOX ® Advanced Console Server and requests a password), telnet, ssh, ssh2, or socket_client. See all.socket_port definition if all.protocol is configured as socket_client.	rlogin
all.socket_port	The socket_port is the TCP port number of the application that will accept connection requested by this serial port. That application usually is telnet (23).	

# Appendix C - The pslave Configuration File

---

---

Table 28: TS Parameters

Parameter	Description	Value for this Example
all.telnet_client_mode	When the protocol is TELNET, this parameter configured as BINARY (1) causes an attempt to negotiate the TELNET BINARY option on both input and output with the Telnet server. So it puts the telnet client in binary mode. The acceptable values are "0" or "1", where "0" is text mode (default) and "1" is a binary mode.	
s16.tty (TS)	It defines the physical device name associated to the serial port (without the /dev/).	ttyS16

## Dial-in Access Parameters

The following parameters are unique to a Dial-in setup except where indicated.

Table 29: Dial-in configuration Parameters

Parameter	Description	Value for this Example
conf.pppd	Location of the ppp daemon with Radius.	/usr/local/sbin/pppd
all.netmask	It defines the network mask for the serial port.	255.255.255.255
all.ipno (CAS and Dial-in)	See description in CAS section.	

# Appendix C - The pslave Configuration File

Table 29: Dial-in configuration Parameters

Parameter	Description	Value for this Example
all.initchat	Modem initialization string.	<pre>TIMEOUT 10 "" \d\ \dATZ \ OK\r\n-ATZ-OK\r\n "" \ "" ATMO OK\R\n "" \ TIMEOUT 3600 RING "" \ STATUS Incoming %p:I.HANDSHAKE "" ATA\ TIMEOUT 60 CONNECT@ "" \ STATUS Connected %p:I.HANDSHAKE</pre>
all.autoppp	<p>all.autoppp PPP options to auto-detect a ppp session. The cb-script parameter defines the file used for callback and enables negotiation with the callback server. Callback is available in combination with Radius Server authentication. When a registered user calls the BLACK BOX® Advanced Console Server, it will disconnect the user, then call the user back. The following three parameters must be configured in the Radius Server: attribute Service_type(6): Callback Framed; attribute Framed_Protocol(7): PPP; attribute Callback_Number(19): the dial number (example: 50903300).</p>	<pre>%j novj \ proxyarp modem asyncmap 000A0000 \ noipx noccp login auth require-pap refusechap\ mtu %t mru %t \ cb-script /etc/portslave/cb_script \ plugin /usr/lib/libpsr.so</pre>

# Appendix C - The pslave Configuration File

---

---

Table 29: Dial-in configuration Parameters

Parameter	Description	Value for this Example
all.pppopt	all.pppopt PPP options when user has already been authenticated.	%i:%j novj \ proxyarp modem asynctmap 000A0000 \ noipx noccp mtu %t mru %t netmask%m \ idle %I maxconnect %T \ plugin /usr/lib/libpsr.so
all.protocol	For the Dial-in configuration, the available protocols are PPP, SLIP and CSLIP.	ppp
s32.tty	See the s1.tty entry in the CAS section.	ttyS32

## Appendix C - The pslave Configuration File

---

---

This page has been left intentionally blank.



# Appendix D - Linux-PAM

---

## Introduction

Linux-PAM (Pluggable Authentication Modules for Linux) is a suite of shared libraries that enable the local system administrator to choose how applications authenticate users. In other words, without (rewriting and) recompiling a PAM-aware application, it is possible to switch between the authentication mechanism(s) it uses. Indeed, one may entirely upgrade the local authentication system without touching the applications themselves.

It is the purpose of the Linux-PAM project to separate the development of privilege-granting software from the development of secure and appropriate authentication schemes. This is accomplished by providing a library of functions that an application may use to request that a user be authenticated. This PAM library is configured locally with a system file, `/etc/pam.conf` (or a series of configuration files located in `/etc/pam.d/`) to authenticate a user request via the locally available authentication modules. The modules themselves will usually be located in the directory `/lib/security` and take the form of dynamically loadable object files.

The Linux-PAM authentication mechanism gives to the system administrator the freedom to stipulate which authentication scheme is to be used. S/he has the freedom to set the scheme for any/all PAM-aware applications on your Linux system. That is, s/he can authenticate from anything as generous as simple trust (`pam_permit`) to something as severe as a combination of a retinal scan, a voice print and a one-time password!


Linux-PAM deals with four separate types of (management) task. These are: authentication management, account management, session management, and password management. The association of the preferred management scheme with the behavior of an application is made with entries in the relevant Linux-PAM configuration file. The management functions are performed by modules specified in the configuration file.

Following is a figure that describes the overall organization of Linux-PAM:

# Appendix D - Linux-PAM

---

---



*Figure 38: Data flow diagram of Linux-PAM*

The left of the figure represents the application: Application X. Such an application interfaces with the Linux-PAM library and knows none of the specifics of its configured authentication method. The Linux-PAM library (in the center) consults the contents of the PAM configuration file and loads the modules that are appropriate for Application X. These modules fall into one of four management groups (lower center) and are stacked in the order they appear in the configuration file. These modules, when called by Linux-PAM, perform the various authentication tasks for the application. Textual information, required from or offered to the user can be exchanged through the use of the application-supplied conversation function.

# Appendix D - Linux-PAM

---

## The Linux-PAM Configuration File

Linux-PAM is designed to provide the system administrator with a great deal of flexibility in configuring the privilege-granting applications of their system. The local configuration of those aspects of system security controlled by Linux-PAM is contained in one of two places: either the single system file `/etc/pam.conf` or the `/etc/pam.d/` directory. In this section we discuss the correct syntax of and generic options respected by entries to these files.

### Configuration File Syntax

The reader should note that the Linux-PAM-specific tokens in this file are case-insensitive. The module paths, however, are case-sensitive since they indicate a file's name and reflect the case-dependence of typical Linux file systems. The case-sensitivity of the arguments to any given module is defined for each module in turn.

In addition to the lines described below, there are two special characters provided for the convenience of the system administrator:

- #     Comments are preceded by this character and extend to the next end-of-line.
- \     This character extends the configuration lines.

A general configuration line of the `/etc/pam.conf` file has the following form:

```
Service-name module-type control-flag module-path arguments
```

The meaning of each of these tokens is explained below. The second (and more recently adopted) way of configuring Linux-PAM is via the contents of the `/etc/pam.d/` directory. After the meaning of the above tokens is explained, the method will be described.

# Appendix D - Linux-PAM

---

---

*Service-name* The name of the service associated with this entry. Frequently the service name is the conventional name of the given application. For example, 'ftpd', 'rlogind', 'su', etc. There is a special service-name, reserved for defining a default authentication mechanism. It has the name 'OTHER' and may be specified in either lower or upper case characters. Note, when there is a module specified for a named service, the 'OTHER' entries are ignored.

*Module-type* One of (currently) the four types of module. The four types are as follows:

*Auth*- This module type provides two aspects of authenticating the user. First, it establishes that the user is who they claim to be, by instructing the application to prompt the user for a password or other means of identification. Second, the module can grant group membership, independently of the /etc/groups, or other privileges through its credential-granting properties.

*Account*- This module performs non-authentication-based account management. It is typically used to restrict or permit access to a service based on the time of day, currently available system resources (maximum number of users) or perhaps the location of the applicant user—'root' login only on the console.

*Session*- Primarily, this module is associated with doing things that need to be done for the user before or after they can be given service. Such things include the logging of information concerning the opening or closing of some data exchange with a user, mounting directories, etc.

*Password*- This last module type is required for updating the authentication token associated with the user. Typically, there is one module for each 'challenge/response' based authentication (auth) module-type.

# Appendix D - Linux-PAM

---

*Control-flag* The control-flag is used to indicate how the PAM library will react to the success or failure of the module it is associated with. Since modules can be stacked (modules of the same type execute in series, one after another), the control-flags determine the relative importance of each module. The application is not made aware of the individual success or failure of modules listed in the `/etc/pam.conf` file. Instead, it receives a summary of success or fail responses from the Linux-PAM library. The order of execution of these modules is that of the entries in the `/etc/pam.conf` file: earlier entries are executed before later ones. The control-flag can be defined with one of two syntaxes. The simpler (and historical) syntax for the control-flag is a single keyword defined to indicate the severity of concern associated with the success or failure of a specific module. There are four such keywords: required, requisite, sufficient and optional.

The Linux-PAM library interprets these keywords in the following manner:

*Required* This indicates that the success of the module is required for the module-type facility to succeed. Failure of this module will not be apparent to the user until all of the remaining modules (of the same module-type) have been executed.

*Requisite* This is similar to *required*. However, in the case that such a module returns a failure, control is directly returned to the application. The return value is that associated with the first required or requisite module to fail. Note that this flag can be used to protect against the possibility of a user getting the opportunity to enter a password over an unsafe medium. It is conceivable that such behavior might inform an attacker of valid accounts on a system. This possibility should be weighed against the significant concerns of exposing a sensitive password in a hostile environment.

*Sufficient* The success of this module is deemed 'sufficient' to satisfy the Linux-PAM library that this moduletype has succeeded in its purpose. In the event that no previous required module has failed, no more 'stacked' modules of this type are invoked. (Note: in this case subsequent required modules are not invoked.) A failure of this module is not deemed as fatal to satisfying the application.

# Appendix D - Linux-PAM

---

---

*Optional* As its name suggests, this control-flag marks the module as not being critical to the success or failure of the user's application for service. In general, Linux-PAM ignores such a module when determining if the module stack will succeed or fail. However, in the absence of any definite successes or failures of previous or subsequent stacked modules this module will determine the nature of the response to the application. One example of this latter case is when the other modules return something like PAM\_IGNORE.

## Newest Syntax

The more elaborate (newer) syntax is much more specific and gives the administrator a great deal of control over how the user is authenticated. This form of the control flag is delimited with square brackets and consists of a series of value=action tokens:

```
[value1=action1 value2=action2 ...]
```

Here, value1 is one of the following return values: success; open\_err; symbol\_err; service\_err; system\_err; buf\_err; perm\_denied; auth\_err; cred\_insufficient; authinfo\_unavail; user\_unknown; maxtries; new\_authtok\_reqd; acct\_expired; session\_err; cred\_unavail; cred\_expired; cred\_err; no\_module\_data; conv\_err; authtok\_err; authtok\_recover\_err; authtok\_lock\_busy; authtok\_disable\_aging; try\_again; ignore; abort; authtok\_expired; module\_unknown; bad\_item; and default. The last of these (default) can be used to set the action for those return values that are not explicitly defined.

The action can be a positive integer or one of the following tokens: ignore, ok, done, bad, die, and reset.

*A positive integer* When specified as the action, can be used to indicate that the next J modules of the current type will be skipped. In this way, the administrator can develop a moderately sophisticated stack of modules with a number of different paths of execution. Which path is taken can be determined by the reactions of individual modules.

*Ignore* When used with a stack of modules, the module's return status will not contribute to the return code the application obtains.

# Appendix D - Linux-PAM

---

<i>Bad</i>	This action indicates that the return code should be thought of as indicative of the module failing. If this module is the first in the stack to fail, its status value will be used for that of the whole stack.
<i>Die</i>	Equivalent to <i>bad</i> with the side effect of terminating the module stack and PAM immediately returning to the application.
<i>OK</i>	This tells PAM that the administrator thinks this return code should contribute directly to the return code of the full stack of modules. In other words, if the former state of the stack would lead to a return of PAM_SUCCESS, the module's return code will override this value. Note: if the former state of the stack holds some value that is indicative of a module failure, this 'OK' value will not be used to override that value.
<i>Done</i>	Equivalent to OK with the side-effect of terminating the module stack and PAM immediately returning to the application.
<i>Reset</i>	Clear all memory of the state of the module stack and start again with the next stacked module.

## Module Path

Module Path is the path-name of the dynamically loadable object file--the pluggable module itself. If the first character of the module path is '/', it is assumed to be a complete path. If this is not the case, the given module path is appended to the default module path: /lib/security.

Currently, the BLACK BOX ® Advanced Console Server has the following modules available:

<i>pam_access</i>	Provides logdaemon style login access control.
<i>pam_deny</i>	Deny access to all users.

# Appendix D - Linux-PAM

---

---

<i>pam_env</i>	This module allows the (un)setting of environment variables. The use of previously set environment variables as well as PAM_ITEMS such as PAM_RHOST is supported.
<i>pam_filter</i>	This module was written to offer a plug-in alternative to programs like ttypsnoop (XXX - need a reference). Since a filter that performs this function has not been written, it is currently only a toy. The single filter provided with the module simply transposes upper and lower case letters in the input and output streams. (This can be very annoying and is not kind to termcap-based editors.)
<i>pam_group</i>	This module provides group settings based on the user's name and the terminal they are requesting a given service from. It takes note of the time of day.
<i>pam_issue</i>	This module presents the issue file (/etc/issue by default) when prompting for a username.
<i>pam_lastlog</i>	This session module maintains the /var/log/lastlog file. It adds an open entry when called via the pam_open_session() function and completes it when pam_close_session() is called. This module can also display a line of information about the last login of the user. If an application already performs these tasks, it is not necessary to use this module.
<i>pam_limits</i>	This module, through the Linux-PAM open-session hook, sets limits on the system resources that can be obtained in a user session. Its actions are dictated more explicitly through the configuration file discussed in /etc/security/pam_limits.conf.
<i>pam_listfile</i>	The listfile module provides a way to deny or allow services based on an arbitrary file.
<i>pam_motd</i>	This module outputs the motd file (/etc/motd by default) upon successful login.
<i>pam_nologin</i>	Provides standard Unix nologin authentication.
<i>pam_permit</i>	This module should be used with extreme caution. Its action is to always permit access. It does nothing else.
<i>pam_radius</i>	Provides Radius server authentication and accounting.



# Appendix D - Linux-PAM

---

<i>pam_rootok</i>	This module is for use in situations where the superuser wishes to gain access to a service without having to enter a password.
<i>pam_securetty</i>	Provides standard UNIX <i>securetty</i> checking.
<i>pam_time</i>	Running a well-regulated system occasionally involves restricting access to certain services in a selective manner. This module offers some time control for access to services offered by a system. Its actions are determined with a configuration file. This module can be configured to deny access to (individual) users based on their name, the time of day, the day of week, the service they are applying for and their terminal from which they are making their request.
<i>pam_tacplus</i>	Provides TacacsPlus Server authentication, authorization (account management), and accounting (session management).
<i>pam_unix</i>	This is the standard UNIX authentication module. It uses standard calls from the system's libraries to retrieve and set account information as well as authentication. Usually this is obtained from the <i>etc/passwd</i> and the <i>/etc/shadow</i> file as well when shadow is enabled.
<i>pam_warn</i>	This module is principally for logging information about a proposed authentication or application to update a password.
<i>pam_krb5</i>	

# Appendix D - Linux-PAM

---

---

*pam\_ldap* Pam\_ldap looks for the ldap client configuration file “ldap.conf” in /etc/. Here's an example of the ldap.conf file (partial):

```
# file name: ldap.conf

# This is the configuration file for the LDAP
nameservice

# switch library and the LDAP PAM module.

#

# Your LDAP server. Must be resolvable without using
LDAP.

host 127.0.0.1

# The distinguished name of the search base.

base dc=padl,dc=com
```

## Arguments

The arguments are a list of tokens that are passed to the module when it is invoked. They are much like arguments to a typical Linux shell command. Generally, valid arguments are optional and are specific to any given module. Invalid arguments are ignored by a module, however, when encountering an invalid argument, the module is required to write an error to syslog(3).

The following are optional arguments which are likely to be understood by any module. Arguments (including these) are in general, optional.

- debug* Use the syslog(3) call to log debugging information to the system log files.
- no\_warn* Instruct module to not give warning messages to the application.
- use\_first\_pass* The module should not prompt the user for a password. Instead, it should obtain the previously typed password (from the preceding auth module), and use that. If that doesn't work, then the user will not be authenticated. (This option is intended for auth and password modules only).

# Appendix D - Linux-PAM

---

- try\_first\_pass*      The module should attempt authentication with the previously typed password (from the preceding auth module). If that doesn't work, then the user is prompted for a password. (This option is intended for auth modules only).
- use\_mapped\_pass*      This argument is not currently supported by any of the modules in the Linux-PAM distribution because of possible consequences associated with U.S. encryption exporting restrictions.
- expose\_account*      In general, the leakage of some information about user accounts is not a secure policy for modules to adopt. Sometimes information such as user names or home directories, or preferred shell, can be used to attack a user's account. In some circumstances, however, this sort of information is not deemed a threat: displaying a user's full name when asking them for a password in a secured environment could also be called being 'friendly'. The *expose\_account* argument is a standard module argument to encourage a module to be less discrete about account information as deemed appropriate by the local administrator. Any line in (one of) the configuration file(s), that is not formatted correctly will generally tend (erring on the side of caution) to make the authentication process fail. A corresponding error is written to the system log files with a call to `syslog(3)`.

## Directory-based Configuration

It is possible to configure `libpam` via the contents of the `/etc/pam.d/` directory. This is more flexible than using the single configuration file. In this case, the directory is filled with files—each of which has a filename equal to a service-name (in lower-case)—the personal configuration file for the named service. The BLACK BOX® Advanced Console Server Linux-PAM was compiled to use both `/etc/pam.d/` and `/etc/pam.conf` in sequence. In this mode, entries in `/etc/pam.d/` override those of `/etc/pam.conf`.

The syntax of each file in `/etc/pam.d/` is similar to that of the `/etc/pam.conf` file and is made up of lines of the following form:

```
module-type control-flag module-path arguments
```

# Appendix D - Linux-PAM

---

---

The only difference between the two is that the service-name is not present. The service-name is of course the name of the given configuration file. For example, `/etc/pam.d/login` contains the configuration for the login service.

## Default Policy

If a system is to be considered secure, it had better have a reasonably secure 'OTHER' entry. The following is a "severe" setting (which is not a bad place to start!):

```
#
# default; deny access
#
OTHER auth required pam_deny.so
OTHER account required pam_deny.so
OTHER password required pam_deny.so
OTHER session required pam_deny.so
```

While fundamentally a secure default, this is not very sympathetic to a misconfigured system. For example, such a system is vulnerable to locking everyone out should the rest of the file become badly written.

The module `pam_deny` not very sophisticated. For example, it logs no information when it is invoked, so unless the users of a system contact the administrator when failing to execute a service application, the administrator may not know for a long while that his system is misconfigured.

The addition of the following line before those in the above example would provide a suitable warning to the administrator.

```
#
# default; wake up! This application is not configured
#
```

# Appendix D - Linux-PAM

---

```
OTHER auth required pam_warn.so
OTHER password required pam_warn.so
```

**Having two “OTHER auth” lines is an example of stacking.**

**On a system that uses the /etc/pam.d/ configuration, the corresponding default setup would be achieved with the following file:**

```
#
# default configuration: /etc/pam.d/other
#
auth required pam_warn.so
auth required pam_deny.so
account required pam_deny.so
password required pam_warn.so
password required pam_deny.so
session required pam_deny.so
```

**On a less sensitive computer, the following selection of lines (in /etc/pam.conf) is likely to mimic the historically familiar Linux setup:**

```
#
# default; standard UNIX access
#
OTHER auth required pam_unix_auth.so
OTHER account required pam_unix_acct.so
OTHER password required pam_unix_passwd.so
OTHER session required pam_unix_session.so
```

**In general this will provide a starting place for most applications.**

# Appendix D - Linux-PAM

---

---

In addition to the normal applications: login, su, sshd, passwd, and pppd. Black Box also has made portslave a PAM-aware application. The portslave requires four services configured in pam.conf. They are local, remote, radius, and tacplus. The portslave PAM interface takes any parameter needed to perform the authentication in the serial ports from the file pslave.conf. The pslave.conf parameter all.authtype determines which service(s) should be used.

```
# -----#
# /etc/pam.conf                                     #
#                                                  #
# Last modified by Andrew G. Morgan <morgan@kernel.org> #
# -----#
# $Id: pam.conf,v 1.9 2003/06/12 20:34:13 regina Exp $
# -----#
# serv.module   ctrl      module [path]...[args..]      #
# nametype     flag                               #
# -----#

# WARNING. The services tacacs, s_tacacs, radius, s_radius, local, s_local,
#          and remote are used by the Cyclades applications portslave,
#          socket_server, socket_ssh, and raw_data and should not be changed
#          by the administrators unless he knows what he is doing.

#
# The PAM configuration file for the `kerberos' service
#
kerberosauthrequiredpam_krb5.so no_ccache
kerberos auth      optional pam_auth_srv.so
kerberos accountrequiredpam_krb5.so no_ccache
kerberosessionrequiredpam_krb5.so no_ccache
#
#
# The PAM configuration file for the `kerberosdownlocal' service
```

# Appendix D - Linux-PAM

---

```
# If Kerberos server is down, uses the local service
#
kerberosdownlocal auth requisite pam_securetty.so
kerberosdownlocal auth optionalpam_auth_srv.so
kerberosdownlocal auth\
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_krb5.so no_ccache
kerberosdownlocal auth requiredpam_unix2.so
kerberosdownlocal account \
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_krb5.so no_ccache
kerberosdownlocal account requiredpam_unix2.so
kerberosdownlocal session \
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_krb5.so no_ccache
kerberosdownlocal session requiredpam_unix2.so
#
# The PAM configuration file for the `ldap' service
#
ldapauth    sufficientpam_ldap.so
ldapaccount required pam_ldap.so
ldapsession required pam_ldap.so
#
# The PAM configuration file for the `ldapdownlocal' service
# If LDAP server is down, uses the local service
#
ldapdownlocal auth\
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_ldap.so
```

# Appendix D - Linux-PAM

---

---

```
ldapdownlocal auth requiredpam_unix2.so
ldapdownlocal account \
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_ldap.so
ldapdownlocal account requiredpam_unix2.so
ldapdownlocal session \
    [ success=done new_authtok_reqd=done authinfo_unavail=ignore default=die ] \
    pam_ldap.so
ldapdownlocal session requiredpam_unix2.so

#
# The PAM configuration file for the `tacplus' service
#
tacplus auth    requisite pam_securetty.so
tacplus auth    required pam_tacplus.so encrypt
tacplus auth    optional pam_auth_srv.so
tacplus account required pam_tacplus.so encrypt service=ppp protocol=lcp
tacplus session required pam_tacplus.so encrypt service=ppp protocol=lcp

s_tacplus auth    requisite pam_securetty.so
s_tacplus auth    required pam_tacplus.so encrypt use_first_pass
s_tacplus account required pam_tacplus.so encrypt service=ppp protocol=lcp
s_tacplus session required pam_tacplus.so encrypt service=ppp protocol=lcp

#
# The PAM configuration file for the `radius' service
#
radius auth      requisite pam_securetty.so
radius auth      required pam_radius_auth.so
radius auth      optional pam_auth_srv.so
```



# Appendix D - Linux-PAM

---

```
radius account    required pam_radius_auth.so
radius session    required pam_radius_auth.so

s_radius auth     requisite pam_securetty.so
s_radius auth     required pam_radius_auth.so use_first_pass
s_radius account  required pam_radius_auth.so
s_radius session  required pam_radius_auth.so

#
# The PAM configuration file for the `local' service
#
local auth        requisite pam_securetty.so
local auth        required pam_unix2.so
local account     required pam_unix2.so
local password    required pam_unix2.so md5 use_authtok
local session     required pam_unix2.so

s_local auth      requisite pam_securetty.so
s_local auth      required pam_unix2.so use_first_pass
s_local account   required pam_unix2.so
s_local password  required pam_unix2.so md5 use_authtok
s_local session   required pam_unix2.so

#
# The PAM configuration file for the `remote' service
#
remoteauth        required pam_permit.so
remoteaccount     required pam_permit.so
remotepassword    required pam_permit.so
remotesession     required pam_permit.so
```

# Appendix D - Linux-PAM

---

---

```
#
# The PAM configuration file for the `login' service
#
loginauth      requisite pam_securetty.so
loginauth      required  pam_unix2.so
loginauth      optional  pam_group.so
loginaccount   requisite pam_time.so
loginaccount   required  pam_unix2.so
loginpassword  required  pam_unix2.so md5 use_authtok
loginsession   required  pam_unix2.so
login  session required  pam_limits.so

#
# The PAM configuration file for the `xsh' service
#
sshdauth      required  pam_unix2.so
sshdauth      optional  pam_group.so
sshdaccount   requisite pam_time.so
sshdaccount   required  pam_unix2.so
sshdpassword  required  pam_unix2.so md5 use_authtok
sshdsession   required  pam_unix2.so
sshd  session required  pam_limits.so

#
# The PAM configuration file for the `passwd' service
#
passwdpassword required  pam_unix2.so md5
#
# The PAM configuration file for the `samba' service
```

# Appendix D - Linux-PAM

---

```
#
smbauth      required  pam_unix2.so
smbaccount   required  pam_unix2.so
#
# The PAM configuration file for the `su' service
#
suauth       required  pam_wheel.so
suauth       sufficient pam_rootok.so
suauth       required  pam_unix2.so
suaccount    required  pam_unix2.so
susession    required  pam_unix2.so

#
# Information for the PPPD process with the 'login' option.
#
ppp          auth      required  pam_nologin.so
ppp          auth      required  pam_unix2.so
ppp          account   required  pam_unix2.so
ppp          session   required  pam_unix2.so

#
# Information for the ippd process with the 'login' option: local authent.
#
ippd         auth      required  pam_nologin.so
ippd         auth      required  pam_unix2.so
ippd         account   required  pam_unix2.so
ippd         session   required  pam_unix2.so

# Information for the ippd process with the 'login' option: radius authent.
#ippd auth required  pam_radius_auth.so conf=/etc/raddb/server
```

# Appendix D - Linux-PAM

---

---

```
#ippd auth optional    pam_auth_srv.so
#ippd account required pam_radius_auth.so conf=/etc/raddb/server
#ippd session required pam_radius_auth.so conf=/etc/raddb/server

#
# The PAM configuration file for the `other' service
#
otherauth      required pam_warn.so
otherauth      required pam_deny.so
otheraccount   required pam_deny.so
otherpassword  required pam_warn.so
otherpassword  required pam_deny.so
othersession  required pam_deny.so
```

## Reference

**The Linux-PAM System Administrators' Guide**  
Copyright (c) Andrew G. Morgan 1996-9. All rights reserved.  
Email: [morgan@linux.kernel.org](mailto:morgan@linux.kernel.org)

# Appendix E - Upgrades and Troubleshooting

---

## Upgrades

Users should upgrade the BLACK BOX ® Advanced Console Server whenever there is a bug fix or new features that they would like to have. Below are the six files added by Black Box to the standard Linux files in the /proc/flash directory when an upgrade is needed. They are:

- boot\_ori - original boot code
- boot\_alt - alternate boot code
- syslog - event logs (not used by Linux)
- config - configuration parameters, only the boot parameters are used by the boot code
- zImage - Linux kernel image
- script - file where all BLACK BOX ® Advanced Console Server configuration information is stored

### The Upgrade Process

To upgrade the BLACK BOX ® Advanced Console Server, follow these steps:


**Step 1:** Log in to the BLACK BOX ® Advanced Console Server as root.  
Provide the root password if requested.

**Step 2:** Go to the /proc/flash directory using the following command:

```
cd /proc/flash
```

**Step 3:** FTP to the host where the new firmware is located.

Log in using your username and password. Go to the directory where the firmware is located. Select binary transfer and “get” the firmware file.



**Note:** The destination file name in the /proc/flash directory must be zImage.  
Example (hostname = server; directory = /tftpboot; username= admin;  
password = adminpw; firmware filename on that server = zImage.134).

# Appendix E - Upgrades and Troubleshooting

---

```
ftp
> open server
> user admin
> Password: adminpw
> cd /tftpboot
> bin
> get zImage.134 zImage
> quit
```



**Note:** Due to space limitations, the new zImage file may not be downloaded with a different name, then renamed. The BLACK BOX® Advanced Console Server searches for a file named zImage when booting and there is no room in flash for two zImage files.

## Step 4: Run zImage.

To make sure the downloaded file is not corrupted or that the zImage saved in flash is OK the user should run:

```
md5sum -b /proc/flash/zImage
```

## Step 5: Check text file information.

Now the user should check with the information present in the text file saved in the Black Box site (e.g. zImage.134.md5sum). If the numbers match, the downloaded file is not corrupted.

## Step 6: Issue the command reboot.

```
reboot
```

## Step 7: Confirm that the new Linux kernel has taken over.

After rebooting, the new Linux kernel will take over. This can be confirmed by typing

```
cat /proc/version
```

to see the Linux kernel version.

# Appendix E - Upgrades and Troubleshooting

---

## Troubleshooting

### Flash Memory Loss

If the contents of flash memory are lost after an upgrade, please follow the instructions below to restore your system:

**Step 1:** Turn the BLACK BOX ® Advanced Console Server OFF, then back ON.

**Step 2:** Using the console, wait for the self test messages.

If you haven't got any, make sure you have the right settings. If you really get no boot message, press <s> right after powering ON and skip ALTERNATE boot code. That will make the boot run its ORIGINAL boot code.

**Step 3:** During the self test, press <Esc> after the Ethernet test.

**Step 4:** When the Watch Dog Timer prompt appears, press <Enter>.

**Step 5:** Choose the option Network Boot when asked.

**Step 6:** Enter the IP address of the Ethernet interface.

**Step 7:** Enter the IP address of the host where the new zImage file is located.

**Step 8:** Enter the file name of the zImage file on the host.

**Step 9:** Select the TFTP option instead of BOOTP.

The host must be running TFTP and the new zImage file must be located in the proper directory. e.g. /tftpboot for Linux.

**Step 10:** Accept the default MAC address by pressing <Enter>.

The BLACK BOX ® Advanced Console Server should begin to boot off the network and the new image will be downloaded and begin running in RAM. At this point, follow the upgrade steps above (login, cd /proc/flash, ftp, and so forth) to save the new zImage file into flash again.

# Appendix E - Upgrades and Troubleshooting

---

---



Note: Possible causes for the loss of flash memory may include: downloaded wrong zImage file, downloaded as ASCII instead of binary; problems with flash memory.

If the BLACK BOX ® Advanced Console Server booted properly, the interfaces can be verified using *ifconfig* and *ping*. If ping does not work, check the routing table using the command *route*. Of course, all this should be tried after checking that the cables are connected correctly.

The file */etc/config\_files* contains a list of files acted upon by *saveconf* and *restoreconf*. If a file is missing, it will not be loaded onto the ramdisk on boot. The following table lists files that should be included in the */etc/config\_files* file and which programs use each.

Table 30: Files to be included in */etc/config\_file* and the program to use

File	Program
<i>/etc/securetty</i>	telnet, login, su
<i>/etc/issue</i>	getty
<i>/etc/getty_ttyS0</i>	login (via console)
<i>/etc/hostname</i>	tcp
<i>/etc/hosts</i>	tcp
<i>/etc/host.conf</i>	tcp
<i>/etc/nsswitch.conf</i>	dns
<i>/etc/resolv.conf</i>	dns
<i>/etc/config_files</i>	saveconf
<i>/etc/passwd</i>	login, passwd, adduser...
<i>/etc/group</i>	login, passwd, adduser...



# Appendix E - Upgrades and Troubleshooting

Table 30: Files to be included in /etc/config\_file and the program to use

File	Program
<i>/etc/ssh/ssh_host_key.pub</i>	sshd
<i>/etc/ssh/sshd_config</i>	sshd
<i>/etc/ssh/ssh_config</i>	ssh client
<i>/etc/ssh/ssh_host_key</i>	sshd (ssh1)
<i>/etc/ssh/ssh_host_key.pub</i>	sshd (ssh1)
<i>/etc/ssh/ssh_host_dsa_key</i>	sshd (ssh2)
<i>/etc/ssh/ssh_host_dsa_key.pub</i>	sshd (ssh2)
<i>/etc/snmp/snmpd.conf</i>	snmpd
<i>/etc/portslave/pslave.conf</i>	cy_ras, portslave, BLACK BOX ® Advanced Console Server configuration information
<i>/etc/network/ifcfg_eth0</i>	ifconfig eth0, cy_ras, rc.sysinit
<i>/etc/network/ifcfg*</i>	ifconfig, cy_ras, rc.sysinit
<i>/etc/network/ifcfg_lo ifconfig</i>	lo, cy_ras, rc.sysinit
<i>/var/run/radsession.id</i>	radinit, radius authentication process
<i>/home</i>	adduser, passwd
<i>/etc/network/st_routes</i>	ifconfig, cy_ras, rc.sysinit
<i>/etc/syslog-ng/syslog-ng.conf</i>	syslog-ng



**Important!** If any of the files listed in /etc/config\_files is modified, the BLACK BOX ® Advanced Console Server administrator must execute the command *saveconf* before rebooting the BLACK BOX ® Advanced Console Server or the changes will be lost. If a file is created (or a filename altered), its name must be added to this file before executing *saveconf* and rebooting.

# Appendix E - Upgrades and Troubleshooting

---

---



**Important!** Black Box Technical Support is always ready to help with any configuration problems. Before calling, execute the command

```
cat /proc/version
```

and note the Linux version and BLACK BOX® Advanced Console Server version written to the screen. This will speed the resolution of most problems.

## Hardware Test

A hardware test called *tstest* is included with the BLACK BOX® Advanced Console Server firmware. It is a menu-driven program, run by typing *tstest* at the command prompt. The various options are described below. Note that the BLACK BOX® Advanced Console Server should not be tested while in use as the test will inactivate all ports. You should inactivate all processes that may use the serial ports: *inetd*, *sshd*, *cy\_ras*, and *cy\_buffering*. Following are the hardware test steps:

Step 1: *signal\_ras* stop.

Step 2: Perform all hardware tests needed.

Step 3: *signal\_ras* start.

## Port Test

Either a cross cable or a loop-back connector is necessary for this test. Their pinout diagrams are supplied in [Appendix B - Cabling, Hardware, and Electrical Specifications](#). Connect the loop-back connector to the modem cable and then connect the modem cable to the port to be tested (or connect a cross cable between two ports to be tested). When *tstest* senses the presence of the cable or connector, the test will be run automatically and the result shown on the screen.

line of data corresponds to a port in test. The last four columns (DATA, CTS, DCD, and DSR) indicate errors. The values in these columns should be zero. Below is an example of the output screen.

# Appendix E - Upgrades and Troubleshooting

---

---

<- Packets ->			<- Errors ->					
From	To	Sent	Received	Passes	Data	CTS	DCD	DSR
2	<-> 2	35	35	35	0	0	0	0
4	<-> 5	35	35	35	0	0	0	0
5	<-> 4	35	35	35	0	0	0	0

When this test is run with a cable or connector without the DSR signal (see the pinout diagram for the cable or connector being used), errors will appear in the DSR column. This does not indicate a problem with the port. In the example above, tctest perceived that a loop-back connector was attached to port 2 and that a cross cable was used to connect ports 4 and 5.

## Port Conversation

This test sends and receives data on the selected port. One way to run this test is to place a loop-back connector on the port to be tested and begin. Enter the number of the port and a baud rate (9600 is a typical value). Type some letters, and if the letters appear on the screen, the port is working. If the letters do not appear on the screen (which also occurs if the loop-back connector is removed), the port is not functioning correctly.

A second method that can be used to test the port is to connect it to a modem with a straight cable. Begin the test and type "at". The modem should respond with "OK", which will appear on the screen. Other commands can be sent to the modem or to any other serial device. Press Ctrl-Q to exit the terminal emulation test.

## Test Signals Manually

This test confirms that signals are being sent and received on the selected port. Neither the loop-back connector nor the cross cable are necessary. Enter the number of the port to be tested and begin the test.

State	DTR	DCD	DSR	RTS	CTS
ON	X			X	
	↓			↓	
OFF		X	X		X

*Figure 39: Initial test*

# Appendix E - Upgrades and Troubleshooting

---

---

First, type Ctrl-D to see the X in the DTR column move position, then type Ctrl-R to see the X in the RTS column change position. If each of the Xs moves in response to its command, the signals are being sent. Another method to test the signals is to use a loop-back connector. Enter the number of the port with the loopback connector and start the test. In this case, when Ctrl-D is typed, the Xs in the first three columns will move as shown below.

State	DTR	DCD	DSR	RTS	CTS
ON	X	X	X	X	
	↓	↓	↓		
OFF					X

*Figure 40: Second screen, showing changed positions*

This is because the test is receiving the DTR signal sent through the DCD and DSR pins. When Ctrl-R is typed, the Xs in the RTS and CTS columns should move together. If the Xs change position as described, the signals are being sent and received correctly.

## Single User Mode

The BLACK BOX ® Advanced Console Server has a single user mode used when:

- The name or password of the user with root privileges is lost or forgotten,
- After an upgrade or downgrade which leaves the BLACK BOX ® Advanced Console Server unstable,
- After a configuration change which leaves the BLACK BOX ® Advanced Console Server inoperative or unstable.

Type the word “single” (with a blank space before the word) during boot using a console connection. This cannot be done using a telnet or other remote connection. The initial output of the boot process is shown below.

```
Entry Point = 0x00002120
loaded at: 00002120 0000D370
relocated to: 00300020 0030B270
board data at: 003052C8 0030537C
relocated to: 002FF120 002FF1D4
```

# Appendix E - Upgrades and Troubleshooting

---

```
zimage at: 00008100 0006827E
relocated to: 00DB7000 00E1717E
initrd at: 0006827E 0024F814
relocated to: 00E18000 00FFF596
avail ram: 0030B270 00E18000
Linux/PPC load: root=/dev/ram
```

After printing “Linux/PPC load: root=/dev/ram,” the BLACK BOX® Advanced Console Server waits approximately 10 seconds for user input. This is where the user should type “<sp>single” (spacebar, then the word “single”). When the boot process is complete, the Linux prompt will appear on the console:

```
[root@(none) /]#
```

If the password or username was forgotten, execute the following commands:

```
passwd
saveconf
reboot
```

For configuration problems, you have two options:

**Step 1: Edit the file(s) causing the problem with vi, then execute the commands:**

```
saveconf
reboot
```

**Step 2: Reset the configuration by executing the commands:**

```
echo 0 > /proc/flash/script
reboot
```

If the problem is due to an upgrade/downgrade, a second downgrade/upgrade will be necessary to reverse the process. First, the network must be initialized in order to reach a ftp server. Execute the following script, replacing the parameters with values appropriate for

# Appendix E - Upgrades and Troubleshooting

---

---

your system. If your ftp server is on the same network as the BLACK BOX ® Advanced Console Server, the gw and mask parameters are optional.

```
config_eth0 ip 200.200.200.1 mask 255.255.255.0 gw 200.200.200.5
```

At this point, the DNS configuration (in the file /etc/resolv.conf) should be checked. Then, download the kernel image using the ftp command.

## Troubleshooting the Web Configuration Manager

### What to do when the initial Web page does not appear

Try pinging, telnetting, or tracerouting to the BLACK BOX ® Advanced Console Server to make sure it is reachable. If not, the problem is probably in the network or network configuration. Are the interfaces up? Are the IP addresses correct? Are filters configured which block the packets? If the BLACK BOX ® Advanced Console Server is reachable, see if the /bin/webs process is running by executing the command ps. If it is not, type /bin/webs & to start it. If the /bin/webs process is not being initialized during boot, change the file /etc/inittab.

### How to restore the Default Configuration of the Web Configuration Manager

This would be required only when the root password was lost or the configuration file /etc/websum.conf was damaged. From a console or telnet session, edit the file /etc/config\_files. Find the reference to /etc/websum.conf and delete it. Save the modified /etc/config\_files file. Execute the command saveconf. Reboot the system. Enter into the Web Configuration Manager with the default username and password (root/tslinux). Edit the file /etc/config\_files and insert the reference to /etc/websum.conf.

## Using a different speed for the Serial Console

The serial console is originally configured to work at 9600 bps. If you want to change that, it is necessary to change the configuration following the steps:

**Step 1: Run bootconf. The user will be presented with the screen:**

```
Current configuration
MAC address assigned to Ethernet [00:60:2e:00:16:b9]
IP address assigned to Ethernet interface [192.168.160.10]
Watchdog timer ((A)ctive or (I)nactive) [A]
```

# Appendix E - Upgrades and Troubleshooting

---

```
Firmware boot from ((F)lash or (N)etwork) [F]
Boot type ((B)ootp,(T)ftp or Bot(H)) [T]
Boot File Name [zvmppctsbin]
Server's IP address [192.168.160.1]
Console speed [9600]
(P)erform or (S)kip Flash test [P]
(S)kip, (Q)uick or (F)ull RAM test [F]
Fast Ethernet ((A)uto Neg, (1)00 BtH, 100 Bt(F), 10 B(t)F, 10
Bt(H)) [A]
Fast Ethernet Maximum Interrupt Events [0]
```

**Type <Enter> for all fields but the Console Speed. When presented the following line:**

```
Do you confirm these changes in flash ( (Y)es, (N)o (Q)uit )
[N] :
```

**Step 2: Enter Y and the changes will be saved in flash.**

**Step 3: Logout and login again to use the console at the new speed.**

# Appendix E - Upgrades and Troubleshooting

---


---

## CPU LED

Normally the CPU status LED should blink consistently one second on, one second off. If this is not the case, an error has been detected during the boot. The blink pattern can be interpreted via the following table:

Table 31: CPU LED Code Interpretation

Event	CPU LED Morse code
Normal Operation	S (short, short, short . . . )
Flash Memory Error - Code	L (long, long, long . . . )
Flash Memory Error - Configuration	S, L
Ethernet Error	S, S, L
No Interface Card Detected	S, S, S, L
Network Boot Error	S, S, S, S, L
Real-Time Clock Error	S, S, S, S, S, L



Note: The Ethernet error mentioned in the above table will occur automatically if the Fast Ethernet link is not connected to an external hub during the boot. If the Fast Ethernet is not being used or is connected later, this error can be ignored.



# Appendix F - Certificate for HTTP Security

## Introduction

The following configuration will enable you to obtaining a Signed Digital Certificate. A certificate for the HTTP security is created by a CA (Certificate Authority). Certificates are most commonly obtained through *generating public and private keys*, using a public key algorithm like RSA or X509. The keys can be generated by using a key generator software.

## Procedure

Step 1: Enter OpenSSL command.

On a Linux computer, key generation can be done using the OpenSSL package, through the following command:

```
# openssl req -new -nodes -keyout private.key -out public.csr
```

If this command is used, the following information is required:

Table 32: Required information for the OpenSSL package

Parameter	Description
Country Name (2 letter code) [AU]:	The country code consisting of two letters.
State or Province Name (full name) [Some-State]:	Provide the full name (not the code) of the state.
Locality Name (e.g., city) []:	Enter the name of your city.
Organization Name (e.g., company) [Internet Widgits Ltd]:	Organization that you work for or want to obtain the certificate for.
Organizational Unit Name (e.g., section) []:	Department or section where you work.
Common Name (e.g., your name or your server's hostname) []:	Name of the machine where the certificate must be installed.

# Appendix F - Certificate for HTTP Security

---

---

Table 32: Required information for the OpenSSL package

Parameter	Description
Email Address []:	Your email address or the administrator's email address.

The other requested information can be skipped.

The certificate signing request (CSR) generated by the command above contains some personal (or corporate) information and its public key.

## Step 2: Submit CSR to the CA.

The next step is to submit the CSR and some personal data to the CA. This service can be requested by accessing the CA Web site and is not free. There is a list of CAs at the following URL

`pki-page.org`

The request will be analyzed by the CA, for policy approval and to be signed.

## Step 3: Upon receipt, install certificate.

After the approval, the CA will send a certificate file to the origin, which we will call `Cert.cer`, for example purposes. The certificate is also stored on a directory server. The certificate must be installed in the GoAhead Web server, by following these instructions:

**Step A:** Open a Black Box Terminal Server session and do the login.

**Step B:** Join the certificate with the private key into the file `/web/server.pem`.

```
#cat Cert.cer private.key > /web/server.pem
```

**Step C:** Copy the certificate to the file `/web/cert.pem`.

```
#cp Cert.cer /web/cert.pem
```

**Step D:** Include the files `/web/server.pem` and `/web/cert.pem` in `/etc/config_files`.

# Appendix F - Certificate for HTTP Security

---

**Step E:** Save the configuration in flash.

```
#saveconf
```

**Step F:** The certification will be effective in the next reboot.

# Appendix F - Certificate for HTTP Security

---

---

This page has been left intentionally blank.

# Appendix G - IPSEC

---

---

## Introduction

This document contains some information that Technical Support may need to help customers with IPsec problems. It covers some basic aspects of tunneling, the kinds of tunnels supported by the BLACK BOX® Advanced Console Server IPsec implementation, how to configure the BLACK BOX® Advanced Console Server and how to manage the IPsec and the IPsec connections.

## Basic IPsec Knowledge

IPsec provides encryption and authentication services at the IP level of the network protocol stack. Working at this level, IPsec can protect any traffic carried over IP, unlike other encryption which generally protects only a particular higher-level protocol (PGP for mail, SSH for login, SSL for Web work and so on).

IPsec can be used on any machine which does IP networking. Dedicated IPsec gateway machines can be installed wherever required to protect traffic. IPsec can also run on routers, on firewall machines, on various application servers, and on end-user desktop or laptop machines.

IPsec is used mainly to construct a secure connection (*tunnel*) between two networks (ends) over a not-necessarily-secure third network. In our case, the IPsec will be used to connect the BLACK BOX® Advanced Console Server securely to a host or to a whole network—configurations frequently called host-to-network and host-to-host tunnel. Considering practical aspects, this is the same thing as a VPN, but here one or both sides have a degenerated subnet (only one machine).

# Appendix G - IPSEC

---

---

## Using IPsec to create a VPN

A VPN, or Virtual Private Network lets two networks communicate securely when the only connection between them is over a third network which they do not trust.

The method is to put a security gateway machine between each of the communicating networks and the untrusted network. The gateway machines encrypt packets entering the untrusted net and decrypt packets leaving it, creating a secure tunnel through it.

## The Authentication

A complication, which applies to any type of connection, is that a secure connection cannot be created magically. There must be some mechanism which enables the gateways to reliably identify each other. Without this, they cannot sensibly trust each other and cannot create a genuinely secure link.

In the BLACK BOX ® Advanced Console Server IPsec implementation there are two methods of authentication:

1. A shared secret provides authentication. If Alice and Bob are the only ones who know a secret and Alice receives a message which could not have been created without that secret, then Alice can safely believe the message came from Bob.
2. A public key or RSA authentication can also provide authentication. If Alice receives a message signed with Bob's private key (which of course only he should know) and she has a trustworthy copy of his public key (so that she can verify the signature), then she can safely believe the message came from Bob.

## The Encryption

In a tunnel, the two system must have a common key that they will use to encrypt and decrypt the packages. The key for the encryption can be provided in two ways:

### *Maual keying*

The two ends share a secret key to encrypt their message. Of course, if an enemy gets the key, all is lost. The BLACK BOX ® Advanced Console Server IPsec implementation does not support manual keying.

### *Automatic keying*

The two systems authenticate each other and negotiate their own secret key. The key are automatically changed periodically.

# Appendix G - IPSEC

---

## The software parts

The IPsec software has three main parts:

<i>KLIPS (kernel IPsec)</i>	Implements the IPsec code in the Linux kernel.
<i>PLUTO</i>	The user space IPsec. It negotiate connections with other systems.
<i>scripts</i>	Various scripts provide and administrator interface to the machinery.

## IPSec Configuration

### The configuration file

IPsec uses a configuration file, `ipsec.conf`. This section describes setting up the parts of that file that apply to all connections:

<i>Config setup section</i>	This describes machine configuration.
<i>Conn default section</i>	Default parameters which apply to all connections.

This section also gives an introduction to the parts of the file that specify the actual connections. The following section covers setting up a conventional VPN connection using automatic keying with RSA authentication of the gateways.

### General comments on `ipsec.conf`

The `ipsec.conf` file is divided into sections, and the following rules apply:

1. The '#' character marks a comment.
2. The first uncommented line of a section must be at the margin, and must not be indented.

# Appendix G - IPSEC

---

---

3. All other non-comment lines of a section must be indented.
4. Blank lines separate sections.
5. You cannot put a blank line within a section; use a lone '#' instead.

The configuration file uses left and right to refer to the two gateways involved in a connection, and has other parameters which come in left/right pairs. For example, leftsubnet is the subnet behind left. Which gateway is left and which is right is entirely up to you.

## The setup section of ipsec.conf

The first section of ipsec.conf contains overall setup parameters for IPsec, which apply to all connections. In our example file, this would be:

```
# basic configuration
config setup
# THIS SETTING MUST BE CORRECT or almost nothing will work;
# %defaultroute is okay for most simple cases.
interfaces=%defaultroute
# Debug-logging controls: "none" for (almost) none, "all" for
lots.
klipsdebug=none
plutodebug=none
# Use auto= parameters in conn descriptions to control startup
actions.
plutoload=%search
plutostart=%search
# Close down old connection when new one using same ID shows up.
uniqueids=yes
```



# Appendix G - IPSEC

---

The variables set here are:

<i>interfaces</i>	Tells the IPsec code in the Linux kernel which network interface to use. The interfaces specified here are the only ones this gateway machine will use to communicate with other IPsec gateways. If this is not correct, nothing works. In many cases, the appropriate interface is just your default connection to the world (the Internet, or your corporate network). In these cases, you can use the default setting: <code>interfaces=%defaultroute</code> . To check what IPsec sees as the default route, you can use the command <i>ipsec showdefaults</i> . You may need to compare this with the output from <i>netstat -rn</i> to get a more complete picture. In other cases, you can name one or more specific interfaces to be used by IPsec. For example: <code>interfaces="ipsec0=eth0"</code> or <code>interfaces="ipsec0=eth0 ipsec1=ppp0"</code> . Both tell IPsec to use eth0 as ipsec0. The second one also supports IPsec over PPP. Note that multiple tunnels do not require multiple interfaces. It is possible, and even common, to have one IPsec interface carrying traffic for many tunnels. If you need to discover interface names, use the command: <code>ifconfig</code> .
<i>klipsdebug</i>	Debugging setting for the IPsec kernel code
<i>plutodebug</i>	Debugging setting for the IPsec key and connection negotiation daemon. <code>klipsdebug</code> and <code>plutodebug</code> can each be set to "none" or to "all" in most circumstances.
<i>plutoload</i>	List of connections to be automatically loaded into memory when Pluto starts.

# Appendix G - IPSEC

---

---

## *plutostart*

List of connections to be automatically negotiated when Pluto starts. `plutoload` and `plutostart` can be quoted lists of connection names, but are often set to `%search` as in our example. Any connection with `auto=add` in its connection definition is then loaded, and any connection with `auto=start` is started. In most cases, you want `plutostart=%search` here and `auto=start` in your connection descriptions. That way when a connection is broken, for example if one machine crashes or is taken down for some reason, it will be reliably rebuilt. If only one end is told to start the connection, and then the other end crashes, you may lose the connection for a long time. The end that could rebuild does not know what it needs to.

## *uniqueids*

Controls whether two connections with the same subnet on the remote end are allowed. Normally this is set to *yes* so that when a remote system disconnects and reconnects, Pluto will automatically take the old connection down.

## Connection defaults

There is a special name `%default` that lets you define things that apply to all connections. You can also set general defaults here and override them later for specific connections. If both the `%default` section and the actual connection description set the same variable, then the connection description takes precedence.

Our example file has:

```
# defaults for subsequent connection descriptions
conn %default
# How persistent to be in (re)keying negotiations (0 means very).
keyingtries=0
# How to authenticate gateways
authby=rsasig
# Load all connection descriptions by default
```

# Appendix G - IPSEC

---

```
# Some will override this with auto=start
```

```
auto=add
```

Variables set here are:

## *keyingtries*

How persistent to be in (re)keying negotiations (0 means very). For testing, you might wish to set this to some small number, perhaps even to 1, to avoid wasting resources on incorrectly set up connections. In production, it is often set to zero (retry forever). Keeping the connection up is what machine resources are for, so if a connection is down you might as well waste resources retrying rather than waste them by sitting idle. Of course some caution should be exercised with this, since it can waste network resources as well.

## *authby=rsasig*

Authenticate gateways using RSA signatures. This is the preferred method and is what we will use in this section's examples. An alternate method is to use shared secrets.

## *auto=add*

Automatically add connections descriptions to Pluto's in-memory database at startup. This is required before Pluto can recognize incoming requests for that connection, so we suggest making it the default here. To actually start negotiations for a given connection, you need `auto=start`. You could make that the default here or leave `auto=add` as the default and override it where needed with `auto=start` in individual connection descriptions.

## Editing a connection description

A sample connection description is:

```
# sample tunnel
```

```
# The network here looks like:
```

```
# leftsubnet===left---leftnexthop.....rightnexthop---  
right===rightsubnet
```

```
# If left and right are on the same Ethernet, omit leftnexthop and  
rightnexthop.
```

```
conn sample
```

# Appendix G - IPSEC

---

---

```
# left security gateway (public-network address)
left=10.0.0.1
# next hop to reach right
leftnexthop=10.44.55.66
# subnet behind left (omit if there is no subnet)
leftsubnet=172.16.0.0/24
# right s.g., subnet behind it, and next hop to reach left
right=10.12.12.1
rightnexthop=10.88.77.66
rightsubnet=192.168.0.0/24
auto=start
```

We are omitting the variables we have shown as set in the default connection above. All of them could also be set here. If they are set in both places, settings here take precedence. Defaults are used only if the specific connection description has no value set.

Many of the variables in this file come in pairs such as *leftsubnet* and *rightsubnet*, one for each end of the connection. The variables on the left side are:

*left*                      The gateway's external interface. The one it uses to talk to the other gateway. This can be `left=%defaultroute`.

# Appendix G - IPSEC

---

## *Leftnexthop*

Where left should send packets whose destination is right, typically the first router in the appropriate direction. This need not always be so. If the two gateways are directly linked (packets can go from one to the other without IP routing by any intermediate device) then you need not set either *leftnexthop* or *rightnexthop*. A connection with *left=%defaultroute* or *right=%defaultroute* must not have the corresponding *nexthop* parameter set. However, in all other cases, you must provide *nexthop* information. KLIPS bypasses the normal routing machinery, so you must give KLIPS the information even though routing already knows it.

## *leftsubnet*

Addresses for the machines that left is protecting. Often something like 101.202.203.0/24 to indicate that a subnet resides behind left. Often this subnet will be directly connected to left, but this not necessary. The only requirement is that left must be able to route to it. If you omit the *leftsubnet* line, then left is both the security gateway and the only client on that end.

## *auto*

If the *conn setup* section has *plutoload=%search*, then all connections marked *auto=add* are loaded when Pluto starts. If the *conn setup* section has *plutostart=%search*, then all connections marked *auto=start* are started when Pluto starts. Initially, we suggest using *auto=add* on all connections. This lets you start them manually during testing. Once they are tested, you can change many of them to *auto=start*.

For each *left\** parameter, there is a corresponding *right\** parameter.

Note that a connection to a subnet behind left does not include left itself. The tunnel described above protects packets going from one subnet to the other. It does not apply to packets which either begin or end their journey on one of the gateways. If you need to protect those packets, you must build separate tunnel descriptions for them.

It is a common error to attempt testing a subnet-to-subnet connection by pinging from one of the gateways to the far end or vice versa. This does not work, even if the connection is functioning perfectly, because traffic to or from the gateway itself is not sent on that connection. If you want to protect traffic originating or terminating on the gateway, then you need a separate tunnel for that in addition to the subnet's tunnel.

# Appendix G - IPSEC

---

---

## Example file for BLACK BOX ® Advanced Console Server-to-network connection

For an BLACK BOX ® Advanced Console Server -to-network connection, a simple network diagram looks like this:

```
BLACK BOX ® Advanced Console Server
interface e.f.g.h =left
|
interface e.f.g.i =leftnexthop
router
interface we don't know
|
INTERNET
|
interface we don't know
router
interface j.k.l.m =rightnexthop
|
interface j.k.l.n =right
right gateway machine
interface 192.168.0.something
| (branch office uses private IP addresses)
subnet 192.168.0.0/24 =rightsubnet
```

The ipsec.conf file for the above network would look like this (with RSA keys shortened for easy display):

```
# basic configuration
config setup
```

# Appendix G - IPSEC

---

```
interfaces="%defaultroute"
klipsdebug=none
plutodebug=none
plutoload=%search
plutostart=%search
# defaults that apply to all connection descriptions
conn %default
keyingtries=0
# How to authenticate gateways
authby=rsasign
# VPN connection for head office and branch office
conn head-branch
# identity we use in authentication exchanges
leftid=@head.example.com
leftrsasigkey=0x175cffc641f...
# left security gateway (public-network address)
left=e.f.g.h
# next hop to reach right
leftnexthop=e.f.g.i
# right s.g., subnet behind it, and next hop to reach left
rightid=@branch.example.com
rightrsasigkey=0xfc641fd6d9a24...
right=j.k.l.n
rightnexthop=j.k.l.m
```

# Appendix G - IPSEC

---

---

```
rightsubnet=192.168.0.0/24
```

## IPsec Usage

### The IPsec Daemon

The IPsec daemon (PLUTO) is the program that loads and negotiates the connections. To start the IPsec daemon use the following command:

```
/usr/local/sbin/ipsec setup --start
```

Similarly, this command accepts the usual daemon commands as stop and restart.

The ipsec daemon is not automatically initialized when you boot your Console Server equipment for the first time. If you want the IPsec to auto run on boot you must uncomment the lines regarding the IPsec on the `/etc/rc.sysinit` script.

### Adding and Removing a Connection

All the connections can be loaded to the IPsec database at boot time if these connections have the auto parameter set to add. However if a certain connection doesn't have this option set and you wish to add this connection manually you can use the following command:

```
/usr/local/sbin/ipsec auto --add <connection name>
```

Similarly, to take a connection out of the IPsec database you can use the command:

```
/usr/local/sbin/ipsec auto --delete <connection name>
```

Once a connection descriptor is in the IPsec internal database, IPsec will accept the other end to start the security connection negotiation. You can also start its negotiation as explained in the next section.



# Appendix G - IPSEC

---

## Starting and Stopping a Connection

All the connections can be negotiated at boot time if these connections have the auto parameter set to start. However if a certain connection doesn't have this option set you can set it. Once a connection descriptor is in the IPsec internal database, you can start its negotiation using the command:

```
/usr/local/sbin/ipsec auto --up <connection name>
```

Similarly to close a tunnel you use the command:

```
/usr/local/sbin/ipsec auto --down <connection name>
```

Below you can see the output of a successful up operation:

```
[root@henrique root]# ipsec auto --up teste
104 "teste" #5: STATE_MAIN_I1: initiate
106 "teste" #5: STATE_MAIN_I2: sent MI2, expecting MR2
108 "teste" #5: STATE_MAIN_I3: sent MI3, expecting MR3
004 "teste" #5: STATE_MAIN_I4: ISAKMP SA established
112 "teste" #6: STATE_QUICK_I1: initiate
004 "teste" #6: STATE_QUICK_I2: sent QI2, IPsec SA established
```

## Generating the RSA key pair

To build a connection, the Console Server and the other end must be able to authenticate each other. For IPsec, the default is public key authentication based on the RSA algorithm.

# Appendix G - IPSEC

---

---

## Generating an RSA key pair

The Console Server doesn't have an RSA key pair by default. If you would like to create one, you can simply uncomment the lines regarding IPsec in the file `/etc/rc.sysinit`. Your key pair will then be generated in the next boot. You also can generate your key pair by issuing the following commands as root:

```
. ipsec newhostkey --bits <key length> --output /etc/ipsec.secrets
. chmod 600 /etc/ipsec.secrets
```

Key generation may take some time. In addition,, the Console Server needs a lot of random numbers, and therefore needs and uses traffic on the Ethernet port to generate them.

## Extracting authentication keys

Once your gateway's key is in `ipsec.secrets`, the next step is to send your public key to everyone you need to set up connections with and collect their public keys. You need to extract the public part in a suitable format. This is done with the `ipsec_showhostkey` command:

```
ipsec showhostkey --left
ipsec showhostkey --right
```

These two produce the key formatted for insertion in an `ipsec.conf` file. Public keys need not be protected as fanatically as private keys. They are intended to be made public; the system is designed to work even if an enemy knows all the public keys used. You can safely make them publicly accessible. For example, put a gateway key on a Web page or make it available in DNS, or transmit it via an insecure method such as email.

## Debugging Commands

### IPsec look

The output of `ipsec` appears as shown below:

```
[root@henrique root]# ipsec look
henrique Mon Oct 28 16:40:24 PST 2002

64.186.161.96/32 -> 64.186.161.128/32 => tun0x1006@64.186.161.128
esp0x4e1a10ce@64.186.161.128 (0)
```

# Appendix G - IPSEC

---

```
ipsec0->eth0 mtu=16260(1443)->1500

esp0x4e1a10ce@64.186.161.128 ESP_3DES_HMAC_MD5: dir=out
src=64.186.161.96 iv_bits=64bits iv=0xd491678073a22185 ooowin=64
alen=128 aklen=128 eklen=192 life(c,s,h)=addtime(4,0,0)

esp0xa99f2a63@64.186.161.96 ESP_3DES_HMAC_MD5: dir=in
src=64.186.161.128 iv_bits=64bits iv=0x46209cee5f952117 ooowin=64
alen=128 aklen=128 eklen=192 life(c,s,h)=addtime(4,0,0)

tun0x1005@64.186.161.96 IPIP: dir=in src=64.186.161.128 pol-
icy=64.186.161.128/32->64.186.161.96/32 flags=0x8<>
life(c,s,h)=addtime(4,0,0)

tun0x1006@64.186.161.128 IPIP: dir=out src=64.186.161.96
life(c,s,h)=addtime(4,0,0)

Destination Gateway Genmask Flags MSS Window irtt Iface
0.0.0.0 64.186.161.1 0.0.0.0 UG 40 0 0 eth0
64.186.161.0 0.0.0.0 255.255.255.0 U 40 0 0 eth0
64.186.161.0 0.0.0.0 255.255.255.0 U 40 0 0 ipsec0
64.186.161.128 64.186.161.128 255.255.255.255 UGH 40 0 0 ipsec0
```

**In this output you can see that there is an activated tunnel between the networks 64.186.161.96/32 and 64.186.161.128/32. You can also see the routing table for this host after the encryption information .**

## IPsec whack

**The output of ipsec whack -status looks like this:**

```
[root@henrique root]# ipsec whack --status
000 interface ipsec0/eth0 64.186.161.96
000
000 "teste": 64.186.161.96[@micro]...64.186.161.128[@BLACK BOX ®
Advanced Console Server ]
```

# Appendix G - IPSEC

---

---

```
000 "teste": ike_life: 3600s; ipsec_life: 28800s; rekey_margin:
540s; rekey_fuzz: 100%; keyingtries: 0

000 "teste": policy: RSASIG+ENCRYPT+TUNNEL+PFS; interface: eth0;
erouted

000 "teste": newest ISAKMP SA: #5; newest IPsec SA: #6; eroute
owner: #6

000

000 #6: "teste" STATE_QUICK_I2 (sent QI2, IPsec SA established);
EVENT_SA_REPLACE in 28245s; newest IPSEC; eroute owner

000 #6: "teste" esp.4e1a10ce@64.186.161.128
esp.a99f2a63@64.186.161.96 tun.1006@64.186.161.128
tun.1005@64.186.161.96

000 #5: "teste" STATE_MAIN_I4 (ISAKMP SA established);
EVENT_SA_REPLACE in 3019s; newest ISAKMP
```

As you can see, it shows almost the same information shown by the `ipsec auto -up` command. You can use this command if the `up` command doesn't show anything on the screen (it can happen depending on the BLACK BOX® Advanced Console Server `syslog` configuration).

## IPsec and Road Warriors

### IPsec, Security for the Internet Protocol

FreeS/WAN is a Linux implementation of the IPsec (IP security) protocols. IPsec provides encryption and authentication services at the IP (Internet Protocol) level of the network protocol stack.

Working at this level, IPsec can protect any traffic carried over IP, unlike other encryption which generally protects only a particular higher-level protocol—PGP for mail, SSH for remote login, SSL for Web work, and so on.

# Appendix G - IPSEC

---

## Applications of IPsec

Because IPsec operates at the network layer, it is remarkably flexible and can be used to secure nearly any type of Internet traffic. Two applications, however, are extremely widespread:

- A Virtual Private Network, or VPN, allows multiple sites to communicate with the Console Server securely over an insecure Internet by encrypting all communication between the sites and the Console Server.
- “Road Warriors” connect to the Console Server from home, or perhaps from a hotel somewhere.

A somewhat more detailed description of each of these applications is below. Our Quick Start section will show you how to build each of them.

### Using secure tunnels to create a VPN

A VPN, or Virtual Private Network lets the Console Server and a whole network communicate securely when the only connection between them is over a third network which is not trustworthy. The method is to put a security gateway machine in the network and create a security tunnel between the Console Server and this gateway. The gateway machine and the Console Server encrypt packets entering the untrusted net and decrypt packets leaving it, creating a secure tunnel through it.

### Road Warriors

The prototypical “Road Warrior” is a traveler connecting to the Console Server from a laptop machine. For purposes of this document:

- Anyone with a dynamic IP address is a “Road Warrior.”
- Any machine doing IPsec processing is a “gateway.” Think of the single-user Road Warrior machine as a gateway with a degenerate subnet (one machine: itself) behind it.

These require a somewhat different setup than VPN gateways with static addresses and with client systems behind them, but are basically not problematic. There are some difficulties which appear for some Road Warrior connections:

- Road Warriors who get their addresses via DHCP may have a problem. FreeS/WAN can quite happily build and use a tunnel to such an address, but when the DHCP lease expires, FreeS/WAN does not know that. The tunnel fails, and the only recovery method is to tear it down and rebuild it.

# Appendix G - IPSEC

---

---

- If Network Address Translation (NAT) is applied between the two IPsec Gateways, this breaks IPsec. IPsec authenticates packets on an end-to-end basis, to ensure they are not altered en route. NAT rewrites packets as they go by.

In most situations, however, FreeS/WAN supports Road Warrior connections just fine.

## Configuration

### Before you Start

#### Set up and test networking

Before trying to get FreeS/WAN working, you should configure and test IP networking on the Console Server and on the other end. IPsec cannot work without a working IP network beneath it.

Many reported "FreeS/WAN problems" turn out to actually be problems with routing or fire-walling. If any actual IPsec problems turn up, you often cannot even recognize them (much less debug them) unless the underlying network is right.

#### Enabling IPsec

The IPsec is disabled by default in the Console Server family. To enable it you must edit the file `/etc/inittab` and `/etc/config_files` and uncomment the lines regarding the IPsec. After performing these changes you must save the configuration using the `saveconf` tool and reboot the equipment.

### Quick Start

This is a quick guide to set up two common configurations: VPN and Road Warrior. There are three examples: a Road Warrior using RSA signature, a VPN using RSA signature and a VPN using shared secret(s). It will assume the other end is also running the FreeS/Wan. If it is not your case make the appropriate conversions for your IPsec software.

#### "Road Warrior" remote access

A common requirement is for connections between a Console Server and some set of remote machines. For example, one administrator may want to access the Console Server from wher-

# Appendix G - IPSEC

---

ever he might be. We refer to the remote machines as “Road Warriors.” For purposes of IPsec, anyone with a dynamic IP address is a Road Warrior.

## Information exchange

To set up a Road Warrior connection, you need some information about the system on the other end. Connection descriptions use *left* and *right* to designate the two ends. We adopt the convention that, from the Console Server's point of view, *left*=local and *right*=remote. The Console Server administrator needs to know some things about each Road Warrior:

- The system's public key (for RSA only).
- The ID that system uses in IPsec negotiation.

To get system's public key in a format suitable for insertion directly into the Console Server's `ipsec.conf` file, issue this command on the warrior machine:

```
/usr/local/sbin/ipsec showhostkey --right
```

The output should look like this (with the key shortened for easy reading):

```
rightrsasigkey=0s1LgR7/oUM...
```

The Road Warrior needs to know:

- The Console Server's public key or the secret, and
- The ID the Console Server uses in IPsec negotiation.

which can be generated by running `/usr/local/sbin/ipsec showhostkey -left` on the Console Server. Each warrior must also know *the IP address of the Console Server*:

This information should be provided in a convenient format, ready for insertion in the warrior's `ipsec.conf` file. For example:

```
left=1.2.3.4
leftid=@acs.example.com
leftrsasigkey=0s1LgR7/oUM...
```

The Console Server administrator typically needs to generate this only once. The same file can be given to all warriors.

# Appendix G - IPSEC

---

---

Setup on the Road Warrior machine

Simply add a connection description *us-to-Console Server*, with the *left* and *right* information you gathered above to the `ipsec.conf` file. This might look like:

```
# pre-configured link to Console Server
conn us-to-acs
    # information obtained from Console Server admin
    left=1.2.3.4                # Console Server IP address
    leftid=@acs.example.com
    # real keys are much longer than shown here
    lefttrsasigkey=0s1LgR7/oUM...
    # warrior stuff
    right=%defaultroute
    rightid=@xy.example.com
    rightrsasigkey=0s1LgR7/oUM
```

Road warrior support on the Console Server

**Adding Road Warrior support so people can connect remotely to your Console Server is straightforward.**

```
conn gate-xy
    left=1.2.3.4
    leftid=@acs.example.com
    lefttrsasigkey=0s1LgR7/oUM...
    # allow connection attempt from any address
    # attempt fails if caller cannot authenticate
    right=%any
    # authentication information
```



# Appendix G - IPSEC

---

```
rightid=@xy.example.com
rightrsasigkey=0s1LgR7/oUM...
```

## BLACK BOX ® Advanced Console Server-to-network VPN

Often it may be useful to have explicitly configured IPsec tunnels between the Console Server and a gateway of an office with a fixed IP address (in this case every machine on the office network would have a secure connection with the Console Server), or between the Console Server and the Console Server administrator machine, which must, in this case, have a fixed IP address.

To do it just insert this connection description in your ipsec.conf file with the variables that fit your environment:

```
# sample tunnel

# The network here looks like:

BLACK BOX ® Advanced Console Server ----acsnexthop.....right-
nexthop----right===rightsubnet

# If BLACK BOX ® Advanced Console Server and right are on the same
Ethernet, omit leftnexthop and rightnexthop.

conn sample

    # BLACK BOX ® Advanced Console Server

    left=10.0.0.1

    leftid=@acs.example.com

    # next hop to reach right

    leftnexthop=10.44.55.66

    # This line is only for RSA signature

    lefttrsasigkey=0s1LgR7/oUM...

    # right s.g., subnet behind it, and next hop to reach left

    right=10.12.12.1

    rightid=@xy.example.com
```

# Appendix G - IPSEC

---

---

```
rightnexthop=10.88.77.66
rightsubnet=192.168.0.0/24
auto=start
# This line is only for RSA signature
rightrsasigkey=0s1LgR7/oUM...
# This line is only for shared secret
authby=secret
```

If you want to use shared secrets you must insert the following line to the `ipsec.secrets` file:

```
10.0.0.1 10.12.12.1 : PSK "secret"
```

The good part is that this connection descriptor and the secret line can be added to both the Console Server and the other end. This is the advantage of using `left` and `right` instead of using local remote parameters.

If you give an explicit IP address for *left* (and *left* and *right* are not directly connected), then you must specify *leftnexthop* (the router which *Console Server* sends packets to in order to get them delivered to *right*). Similarly, you may need to specify *rightnexthop* (vice versa). The *nexthop* parameters are needed because of an unfortunate interaction between FreeS/WAN and the Linuxkernel routing code. They will be eliminated in a future release.

## Setting up RSA authentication keys

To build a connection, the Console Server and the other end must be able to authenticate each other. For FreeS/WAN, the default is public key authentication based on the RSA algorithm. IPsec does allow several other authentication methods.

# Appendix G - IPSEC

---

## Generating an RSA key pair

The Console Server doesn't have an RSA key pair by default. It will be generated on the first reboot after you have uncommented the IPsec lines in the file */etc/inittab*. You also can generate your key pair by issuing the following commands as root:

```
/usr/local/sbin/ipsec newhostkey --bits <key length> --output /etc/ipsec.secrets
chmod 600 /etc/ipsec.secrets
```

Key generation may take some time. In addition, the Console Server needs a lot of random numbers and therefore needs and uses traffic on the Ethernet to generate them. It is also possible to use keys in other formats, not generated by FreeS/WAN. This may be necessary for interoperation with other IPsec implementations.

## Exchanging authentication keys

Once your BLACK BOX® Advanced Console Server's key is in *ipsec.secrets*, the next step is to send your public key to everyone you need to set up connections with and collect their public keys. The other players will be:

- For a VPN: each BLACK BOX® Advanced Console Server administrator needs public keys for all gateways his or her BLACK BOX® Advanced Console Server talks to.
- For a Road Warrior: the BLACK BOX® Advanced Console Server needs public keys for all Warriors that connect to it, and each Warrior needs the BLACK BOX® Advanced Console Server public key.

You need to extract the public part in a suitable format. This is done with the *ipsec\_showhostkey* command. For VPN or Road Warrior applications, use one of the following:

```
/usr/local/sbin/ipsec showhostkey --left
/usr/local/sbin/ipsec showhostkey --right
```

These two produce the key formatted for insertion in an *ipsec.conf* file. Public keys need not be protected as fanatically as private keys. They are intended to be made public; the system is designed to work even if an enemy knows all the public keys used. You can safely make them publicly accessible. For example, put a gateway key on a Web page or make it available in DNS, or transmit it via an insecure method such as email.

# Appendix G - IPSEC

---

---

## The Configuration File

### Description

The *ipsec.conf* file specifies most configuration and control information for the FreeS/WAN IPsec subsystem. (The major exception is secrets for authentication; *ipsec.secrets*) Its contents are not security-sensitive *unless* manual keying is being done for more than just testing, in which case the encryption/authentication keys in the descriptions for the manually-keyed connections are very sensitive (and those connection descriptions are probably best kept in a separate file, via the include facility described below).

The file is a text file, consisting of one or more *sections*. White space followed by # followed by anything to the end of the line is a comment and is ignored, as are empty lines which are not within a section.

A line which contains *include* and a file name, separated by white space, is replaced by the contents of that file, preceded and followed by empty lines. If the file name is not a full pathname, it is considered to be relative to the directory containing the including file. Such inclusions can be nested. Only a single filename may be supplied, and it may not contain white space, but it may include shell wildcards for example:

```
include ipsec.*.conf
```

The intention of the include facility is mostly to permit keeping information on connections, or sets of connections, separate from the main configuration file. This permits such connection descriptions to be changed, copied to the other security gateways involved, etc., without having to constantly extract them from the configuration file and then insert them back into it. Note the *also* parameter (described below) which permits splitting a single logical section (e.g., a connection description) into several actual sections.

A section begins with a line of the form:

```
type name
```

where *type* indicates what type of section follows, and *name* is an arbitrary name which distinguishes the section from others of the same type. (Names must start with a letter and may contain only letters, digits, periods, underscores, and hyphens.) All subsequent non-empty lines which begin with white space are part of the section; comments within a section must

# Appendix G - IPSEC

---

begin with white space too. There may be only one section of a given type with a given name.

Lines within the section are generally of the following form:

*parameter=value*

(Note the mandatory preceding white space.) There can be white space on either side of the =. Parameter names follow the same syntax as section names, and are specific to a section type. Unless otherwise explicitly specified, no parameter name may appear more than once in a section.

An empty *value* stands for the system default value (if any) of the parameter, i.e., it is roughly equivalent to omitting the parameter line entirely. A *value* may contain white space only if the entire *value* is enclosed in double quotes (""); a *value* cannot itself contain a double quote, nor may it be continued across more than one line.

Numeric values are specified to be either an integer (a sequence of digits) or a decimal number (sequence of digits optionally followed by "." and another sequence of digits).

There is currently one parameter which is available in any type of section:

*also* The value is a section name; the parameters of that section are appended to this section, as if they had been written as part of it. The specified section must exist, must follow the current one, and must have the same section type. (Nesting is permitted, and there may be more than one *also* in a single section, although it is forbidden to append the same section more than once.) This allows, for example, keeping the encryption keys for a connection in a separate file from the rest of the description, by using both an *also* parameter and an *include* line.

A section with name *%default* specifies defaults for sections of the same type. For each parameter in it, any section of that type which does not have a parameter of the same name gets a copy of the one from the *%default* section. There may be multiple *%default* sections of a given type, but only one default may be supplied for any specific parameter name, and all *%default* sections of a given type must precede all non-*%default* sections of that type. *%default* sections may not contain *also* parameters.

Currently there are two types of sections: a *config* section specifies general configuration information for IPsec, while a *conn* section specifies an IPsec connection.

# Appendix G - IPSEC

---

---

## Conn Sections

A *conn* section contains a *connection specification*, defining a network connection to be made using IPsec. The name given is arbitrary, and is used to identify the connection to `ipsec_auto` and `ipsec_manual`. Here's a simple example:

```
conn snt
    left=10.11.11.1
    leftsubnet=10.0.1.0/24
    leftnexthop=172.16.55.66
    right=192.168.22.1
    rightsubnet=10.0.2.0/24
    rightnexthop=172.16.88.99
    keyingtries=0                # be very persistent
```

To avoid trivial editing of the configuration file to suit it to each system involved in a connection, connection specifications are written in terms of *left* and *right* participants, rather than in terms of local and remote. Which participant is considered *left* or *right* is arbitrary; IPsec figures out which one it is being run on based on internal information. This permits using identical connection specifications on both ends.

Many of the parameters relate to one participant or the other; only the ones for *left* are listed here, but every parameter whose name begins with `left` has a `right` counterpart, whose description is the same but with `left` and `right` reversed.

Parameters are optional unless marked *required*; a parameter required for manual keying need not be included for a connection which will use only automatic keying, and vice versa.

### Conn Parameters: General

The following parameters are relevant to both automatic and manual keying. Unless otherwise noted, for a connection to work, in general it is necessary for the two ends to agree exactly on the values of these parameters.

# Appendix G - IPSEC

---

<i>type</i>	The type of the connection. Currently the accepted values are: <i>tunnel</i> (the default) signifying a host-to-host, host-to-subnet, or subnet-to-subnet tunnel; <i>transport</i> , signifying host-to-host transport mode; and <i>passthrough</i> (supported only for manual keying), signifying that no IPsec processing should be done at all.
<i>left</i>	Required. The IP address of the left participant's public-network interface. If it is the magic value <i>%defaultroute</i> , and <i>interfaces=%defaultroute</i> is used in the <i>config setup</i> section, <i>left</i> will be filled in automatically with the local address of the default-route interface (as determined at IPsec startup time). This also overrides any value supplied for <i>leftnexthop</i> . (Either <i>left</i> or <i>right</i> may be <i>%defaultroute</i> , but not both.) The magic value <i>%any</i> signifies an address to be filled in (by automatic keying) during negotiation; the magic value <i>%opportunistic</i> signifies that both left and leftnexthop are to be filled in (by automatic keying) from DNS data for left's client.
<i>leftsubnet</i>	Private subnet behind the left participant, expressed as <i>network/netmask</i> . If omitted, essentially assumed to be <i>left/32</i> , signifying that the left end of the connection goes to the left participant only.
<i>leftnexthop</i>	Next-hop gateway IP address for the left participant's connection to the public network. Defaults to <i>%direct</i> (meaning <i>right</i> ).
<i>leftupdown</i>	What <i>updown</i> script to run to adjust routing and/or firewalling when the status of the connection changes.

## Conn Parameters: Automatic Keying

The following parameters are relevant only to automatic keying, and are ignored in manual keying. Unless otherwise noted, for a connection to work, in general it is necessary for the two ends to agree exactly on the values of these parameters.

# Appendix G - IPSEC

---

---

- auto* What operation, if any, should be done automatically at IPsec startup; currently-accepted values are *add* (signifying an *ipsec auto --add*), *route* (signifying that plus an *ipsec auto --route*), *start* (signifying that plus an *ipsec auto --up*), and *ignore* (also the default) (signifying no automatic startup operation). This parameter is ignored unless the *plutoload* or *plutostart* configuration parameter is set suitably; see the *config setup* discussion below.
- auth* Whether authentication should be done as part of ESP encryption, or separately using the AH protocol, acceptable values are *esp* (the default) and *ah*.
- authby* How the two security gateways should authenticate each other. Acceptable values are *secret* for shared secrets (the default) and *rsasig* for RSA digital signatures.
- leftid* How the left participant should be identified for authentication. Defaults to left. Can be an IP address or a fully-qualified domain name preceded by @ (which is used as a literal string and not resolved).
- leftrsasigkey* The left participant's public key for RSA signature authentication, in RFC 2537 format. The magic value *%none* means the same as not specifying a value (useful to override a default). The value *%dnsondemand* means the key is to be fetched from DNS at the time it is needed. The value *%dnsonload* means the key is to be fetched from DNS at the time the connection description is read from *ipsec.conf*. Currently this is treated as *%none* if *right=%any* or *right=%opportunistic*. The value *%dns* is currently treated as *%dnsonload* but will change to *%dnsondemand* in the future. The identity used for the left participant must be a specific host, not *%any* or another magic value. *Caution:* if two connection descriptions specify different public keys for the same *leftid*, confusion and madness will ensue.
- pfs* Whether Perfect Forward Secrecy of keys is desired on the connection's keying channel. (With PFS, penetration of the key-exchange protocol does not compromise keys negotiated earlier.) Acceptable values are *yes* (the default) and *no*.



# Appendix G - IPSEC

---

<i>keylife</i>	How long a particular instance of a connection (a set of encryption/authentication keys for user packets) should last, from successful negotiation to expiry. Acceptable values are an integer optionally followed by <i>s</i> (a time in seconds) or a decimal number followed by <i>m</i> , <i>h</i> , or <i>d</i> (a time in minutes, hours, or days respectively) (default <i>8.0h</i> , maximum <i>24h</i> ).
<i>rekey</i>	Whether a connection should be renegotiated when it is about to expire. Acceptable values are <i>yes</i> (the default) and <i>no</i> .
<i>rekeymargin</i>	How long before connection expiry or keying-channel expiry should attempts to negotiate a replacement begin. Acceptable values as for <i>keylife</i> (default <i>9m</i> ).
<i>rekeyfuzz</i>	Maximum percentage by which <i>rekeymargin</i> should be randomly increased to randomize rekeying intervals (important for hosts with many connections). Acceptable values are an integer, which may exceed 100, followed by a “%.”
<i>keyingtries</i>	How many attempts (an integer) should be made to negotiate a connection, or a replacement for one, before giving up (default <i>3</i> ). The value <i>0</i> means “never give up.”
<i>ikelifetime</i>	How long the keying channel of a connection (buzzphrase: ISAKMP SA) should last before being renegotiated. Acceptable values as for <i>keylife</i> .
<i>compress</i>	Whether IPComp compression of content is desired on the connection. Acceptable values are <i>yes</i> and <i>no</i> (the default).

## Conn Parameters: Manual Keying

The following parameters are relevant only to manual keying, and are ignored in automatic keying. Unless otherwise noted, for a connection to work, in general it is necessary for the two ends to agree exactly on the values of these parameters. A manually-keyed connection must specify at least one of AH or ESP.

<i>spi</i> or <i>spibase</i>	<i>Spi</i> or <i>spibase</i> is required for manual keying. the SPI number to be used for the connection. Must be of the form <i>0xhex</i> , where <i>hex</i> is one or more hexadecimal digits. (Note: it will generally be necessary to make <i>spi</i> at least <i>0x100</i> to be acceptable to KLIPS, and use of SPIs in the range <i>0x100-0xfff</i> is recommended.)
------------------------------	---

# Appendix G - IPSEC

---

---

<i>esp</i>	ESP encryption/authentication algorithm to be used for the connection, e.g. <i>3des-md5-96</i> .
<i>espenckey</i>	ESP encryption key.
<i>espauthkey</i>	ESP authentication key.
<i>espreplay_window</i>	ESP replay-window setting. An integer from 0 to 64. Relevant only if ESP authentication is being used.
<i>leftespi</i>	SPI to be used for the leftward ESP SA, overriding automatic assignment using <i>spi</i> or <i>spibase</i> . Typically a hexadecimal number beginning with 0x.
<i>ah</i>	AH authentication algorithm to be used for the connection, e.g. <i>hmac-md5-96</i> . Default is not to use AH.
<i>ahkey</i>	Required if <i>ah</i> is present. AH authentication key
<i>ahreplay_window</i>	AH replay-window setting. An integer from 0 to 64.
<i>leftahspi</i>	SPI to be used for the leftward AH SA, overriding automatic assignment using <i>spi</i> or <i>spibase</i> . Typically a hexadecimal number beginning with 0x.

## Config Sections

At present, the only config section known to the IPsec software is the one named `setup`, which contains information used when the software is being started. Here's an example:

```
config setup
interfaces="ipsec0=eth1 ipsec1=ppp0"
klipsdebug=none
plutodebug=all
manualstart=
plutoload="snta sntb sntc sntd"
plutostart=
```

# Appendix G - IPSEC

---

Parameters are optional unless marked “required.” The currently-accepted *parameter* names in a *config setup* section are:

## Recommended Configuration

Certain parameters are now strongly-recommended defaults, but cannot (yet) be made system defaults due to backward compatibility. Recommended config setup parameters are:

- `plutoload=%search`
- `plutostart=%search`

In practice, it is preferable to use the `auto` parameter to control whether a particular connection is added or started automatically.

Recommended *conn* parameters (mostly for automatic keying, as manual keying seldom sees much use) are:

<i>keyingtries=0</i>	Unlimited retries are normally appropriate for VPN connections. Finite values may be needed for Road Warrior and other more ephemeral applications, but the fixed small default is pretty much useless.
<i>disablearrivalcheck=no</i>	Tunnel-exit checks improve security and do not break any normal configuration.
<i>authby=rsasig</i>	Digital signatures are superior in every way to shared secrets.

## IPsec Usage

This section will teach you:

- How to start and stop the IPsec daemon.
- How to add and remove an IPsec connection from the IPsec database.
- How to start and stop a connection.

# Appendix G - IPSEC

---

---

## The IPsec Daemon

The ipsec daemon is automatically initialized when you first boot your Console Server equipment after you have uncommented the IPsec lines in the `/etc/inittab` and `/etc/config_files`. Rebooting your BLACK BOX® Advanced Console Server is not mandatory. However, you can start the IPsec daemon by using the command:

```
/usr/local/sbin/ipsec setup
```

This program accepts the options: `--start`, `--stop`, and `--restart`.

## Adding and Removing a Connection

All the connections can be loaded to the IPsec database at boot time if these connections have the `auto` parameter set to *add*. However if a certain connection doesn't have this option set and you wish to add this connection manually you can use the following command:

```
/usr/local/sbin/ipsec (auto/manual) --add <connection name>
```

You must use `auto` or `manual` depending on your connection keying type (`manual/auto`). Similarly to take a connection out of the IPsec database you can use the command:

```
/usr/local/sbin/ipsec (auto/manual) --delete <connection name>
```

Once a connection descriptor is in the IPsec internal database, IPsec will accept the other end to start the security connection negotiation. You can also start its negotiation as explained in the next section.

## Starting and Stopping a Connection

All the connections can be negotiated at boot time if these connections have the `auto` parameter set to `start`. However if a certain connection doesn't have this option set you can set it. Once a connection descriptor is in the IPsec internal database, you can start its negotiation using the command:

```
/usr/local/sbin/ipsec (auto/manual) --up <connection name>
```

Similarly to close a tunnel you use the command:

```
/usr/local/sbin/ipsec (auto/manual) --down <connection name>
```


# Appendix H - Web User Management

## Introduction

In the BLACK BOX ® Advanced Console Server Web server, the user database is completely separated from the system's (as defined in the `/etc/passwd` file), and the logic used for managing permissions is also different. The Web's user database is stored in the `/etc/websum.conf` file, and it has basically three lists: *users*, *user groups* and *access limits*.


## Default Configuration for Web User Management

The following three screen shots show the default configuration for User List, User Group List, and Access Limit List pages, respectively.



User List			
Entry	Username	Group	Status
<input type="radio"/>	root	root	Enabled

*Figure 41: User List default page*



User Group List			
Entry	Group ID	Privilege Level	Status
<input type="radio"/>	root	FULL	Enabled
<input type="radio"/>	admin	ADMINISTRATOR	Enabled
<input type="radio"/>	monitor	MONITOR	Enabled
<input type="radio"/>	user	USER	Enabled

*Figure 42: User Group List default page*

# Appendix H - Web User Management

---

---

Access Limit List				
Entry	URL	Privilege Level	Access Method	Secure
<input type="radio"/>	/	USER	FULL	No
<input type="radio"/>	/appl/	USER	COOKIE	No
<input type="radio"/>	/read/	MONITOR	COOKIE	No
<input type="radio"/>	/adm/	ADMINISTRATOR	COOKIE	No
<input type="radio"/>	/cfg/	FULL	COOKIE	No
<input type="radio"/>	/um/	FULL	COOKIE	No
<input type="radio"/>	/goform/	MONITOR	COOKIE	No
<input type="radio"/>	/goform/Login	USER	FULL	No
<input type="radio"/>	/goform/CheckLogin	USER	FULL	No
<input type="radio"/>	/goform/MainPageTable	USER	COOKIE	No
<input type="radio"/>	/goform/Logout	USER	COOKIE	No
<input type="radio"/>	/goform/appl/	USER	COOKIE	No
<input type="radio"/>	/goform/adm/	ADMINISTRATOR	COOKIE	No
<input type="radio"/>	/goform/cfg/	FULL	COOKIE	No
<input type="radio"/>	/goform/um/	FULL	COOKIE	No

*Figure 43: Access Limit List default page*

# Appendix H - Web User Management

---

## How Web User Management works

When a user logs in, the username and the password are encrypted and stored in the browser. Whenever a URL is requested, the User Manager will perform the following tasks:

### Task 1: Check the URL in the Access Limit List

The Web server first scans for the full URL, and then it looks for the subdirectories, until reaching the root directory “/.” (In the URL `http://CAS/goform/cfg/IPTablesRulesHandle`, the access limits will be scanned in the following order: `/goform/cfg/IPTablesRulesHandle`, `/goform/cfg`, `/goform` and `/`.) When the URL matches an Access Limit, the following information will be available:

- Accessibility* When configured as FULL ACCESS, the URL can be accessed without any authentication; otherwise, the user can authenticate with BASIC, DIGEST or COOKIE authentication. The last type is recommended, because it allows the user to log out in the end of the session. The page will not be accessible when the accessibility is configured as NO ACCESS.
- Security* When set to be secure, the page will be accessed only through HTTPS, which will encrypt the pages through OpenSSL. If the browser is in unsecure mode, the protocol and the port will change to HTTPS.
- Privilege* This is the level of accessibility of the page. If the privilege is USER, any user will be able to access the page. If the privilege is FULL, only users with full access will be able to access the page. There are two levels between them: MONITOR and ADMINISTRATOR.

# Appendix H - Web User Management

---

---

## Task 2: Read the Username and the Password

This is done when the page must be accessed through authentication. If the username matches an entry in the users list, the following information will be available:

<i>Enabled</i>	The username must be enabled to be authenticated.
<i>Encrypted password</i>	The password passed by the browser must match the one registered in the entry.
<i>Group</i>	Each username is linked to a user group.

## Task 3: Look for the group retrieved in the user groups list

The user group entry will have the following information:

<i>Enabled</i>	The group must be enabled to grant access to the URL.
<i>Privilege</i>	The group can have four privileges: in increasing order, they are USER, MONITOR, ADMINISTRATOR and FULL. The group privilege will be compared with the URL privilege. If it is greater or equal, the URL can be accessed by the user; otherwise, access is denied.

## Web User Management Configuration - Getting Started

The users, groups and access limits for Web User Management are configurable with your browser, though it is not recommended to change the groups and the access limits. In the default configuration:

- The access limits have privileges based on the functionality of the Web page.
- There are four different groups (root, monitor, admin and user), each one with a specific privilege.
- There is one root user (username is root and password is linux).



# Appendix H - Web User Management

---

## Changing the Root Password

The first thing to do after logging into a Web session the first time must be to change the root password. See Security Issue under .

Step 1: Click on the link **Web User Management > Users**.

Step 2: Select the root user and click the **Change Password** button.

Step 3: Type the password twice and click the **Submit** button.

Step 4: Click on the link **Web User Management > Load/Save Web Configuration**.  
The Login page will appear.

Step 5: Type the username *root* and the password that was configured, then click on the **Login** button.

Step 6: After the authentication, click on the **Save Configuration** button.

Step 7: Click on the link **Administration > Load/Save Configuration**.

Step 8: Click on the **Save to Flash** button.

## Adding and Deleting Users

### Adding a User

Step 1: Click on the link **Web User Management > Users**.

Step 2: Click on the **Add User** button.

Step 3: Configure the new user.

Type the username, the password (twice) and select a user group, depending on the access privilege desired. Leave the item **Enabled** checked.

# Appendix H - Web User Management

---

---

Step 4: Click on the Submit button.

A confirmation message will appear.

Step 5: If there are more users to be added, repeat the steps 1 to 4.

Step 6: Click on the link Web User Management > Load/Save Web Configuration.

Step 7: Click on the Save Configuration button.

This will save the users added in the file `/etc/websum.conf`.

Step 8: Click on the link Administration > Load/Save Configuration.

Step 9: Click on the Save to Flash button.

Step 10: Test the user(s) added.

Log out the current user (Go to the link Application > Logout) and log in again, with the new user.

## Deleting a User

The root user is delete-protected, and, because of that, it cannot be removed from the user list. The other users can be deleted.

Step 1: Click on the link Web User Management > Users.

Step 2: Select the user to be deleted and click on the Delete User button.

A confirmation message will appear.

Step 3: If there are more users to be deleted, repeat the steps 1 and 2.

Step 4: Click on the link Web User Management > Load/Save Web Configuration.

Step 5: Click on the Save Configuration button.

This will save the users added in the file `/etc/websum.conf`

Step 6: Click on the link Administration > Load/Save Configuration.

Step 7: Click on the Save to Flash button.

# Appendix H - Web User Management

---

## Adding and Deleting User Groups

The default configuration already comes with four user groups, and, for most of the cases, they will be enough. However, you have the option of editing the user groups.

### Adding a group

**Step 1:** Click on the link **Web User Management > Groups**.

**Step 2:** Click on the **Add Group** button

**Step 3:** Configure the new group.

Type the group name and select the access privilege this group will have. Leave the **Enabled** item checked.

**Step 4:** Click on the **Submit** button.

A confirmation message will appear.

**Step 5:** If there are more groups to be added, repeat the steps 1 to 4.

**Step 6:** Click on the link **Web User Management > Load/Save Web Configuration**.

**Step 7:** Click on the **Save Configuration** button.

This will save the users added in the file `/etc/websum.conf`

**Step 8:** Click on the link **Administration > Load/Save Configuration**.

**Step 9:** Click on the **Save to Flash** button.

### Deleting a group

Before deleting a group, make sure that there are no users using that group.

**Step 1:** Click on the link **Web User Management > Groups**.

**Step 2:** Select the group to be deleted and click on the **Delete Group** button.

A confirmation message will appear.

# Appendix H - Web User Management

---

---

Step 3: If there are more groups to be deleted, repeat the steps 1 and 2.

Step 4: Click on the link Web User Management > Load/Save Web Configuration.

Step 5: Click on the Save Configuration button.

This will save the users added in the file `/etc/websum.conf`

Step 6: Click on the link Administration > Load/Save Configuration.

Step 7: Click on the Save to Flash button.

## Adding and Deleting Access Limits

The default configuration has the access limits set according to the functionality of the Web page.

- Pages or forms which causes the configuration to change will have FULL privilege (only high-privileged users will have access to it).
- Pages which change the status of the board without changing the configuration will have ADMINISTRATOR privilege;
- Pages with the system information will have MONITOR privilege.
- Only application pages will have USER privilege.

Changing access limits is not recommended, unless you need to create or change the web server pages; even so, the user should place the web pages in the subdirectories with the privilege desired. For example, a page with ADMINISTRATOR privilege should be placed in `/adm`.

### Adding an Access Limit

Step 1: Click on the link Web User Management > Access Limits.

Step 2: Click on the Add Access Limit button.

# Appendix H - Web User Management

---

**Step 3: Configure the new access limit.**

Type the URL (or the subdirectory), and select the access privilege. If authentication is required to access the page, select **COOKIE ACCESS**; otherwise, select **FULL ACCESS**. If this page is confidential, check the **Secure** box.

**Step 4: Click on the Submit button.**

A confirmation message will appear.

**Step 5: If there are more access limits to be added, repeat the steps 1 to 4.**

**Step 6: Click on the link Web User Management > Load/Save Web Configuration.**

**Step 7: Click on the Save Configuration button.**

This will save the users added in the file `/etc/websum.conf`.

**Step 8: Click on the link Administration > Load/Save Configuration.**

**Step 9: Click on the Save to Flash button.**

## Deleting an access limit

**Step 1: Click on the link Web User Management > Access Limits.**

**Step 2: Select the access limit to be deleted and click on the Delete Access Limit button.**

A confirmation message will appear.

**Step 3: If there are more access limits to be deleted, repeat the steps 1 and 2.**

**Step 4: Click on the link Web User Management > Load/Save Web Configuration.**

**Step 5: Click on the Save Configuration button.**

This will save the users added in the file `/etc/websum.conf`

**Step 6: Click on the link Administration > Load/Save Configuration.**

**Step 7: Click on the Save to Flash button.**

# Appendix H - Web User Management

---

---

This page has been left intentionally blank.

# Appendix I - Connect to Serial Ports from Web

---

---

## Introduction

Depending on how the serial port is configured, connecting to a serial port will either open up a telnet or ssh connection. A serial port configured as `socket_server` or `raw_data` will open up a telnet connection while `socket_ssh` will open up a ssh connection. Any Web user configured in the Web User Management section of the WMI will be able to use this application.

## Tested Environment

Table 33: Windows XP + JREv1.4.0\_01 or 02

Internet Explorer 6.0	Success
Netscape 6/6.2.3	Success
Netscape 7.0	Success
Mozilla 1.1	Success

Requirements: Java 2 Runtime Environment (JRE) SE v1.4.0\_01 or v1.4.0\_02 (which can be found at <http://java.sun.com/>) installed on your PC with your browser acknowledged to use it. You can first check if the browser you are using acknowledges the Java version by following the procedures given in the next sections.

# Appendix I - Connect to Serial Ports from Web

---

---

## On Windows

### From Internet Explorer

Go to Tools → Internet Options → Advanced. Scroll down and look for a section on Java. There should be a checkbox that says "Use Java 2 v1.4.0 ...." If there isn't, this could either mean your browser is not activated to use the Java plug-in that came with the JRE you have installed or it just means that you don't have any JRE installed, in which case please install and repeat the check.

If you have already installed JRE and you just want to activate your browser to use it, go to your system's Control Panel → Java Plug-in icon → Browser → check on the browser(s) you want to activate to use the Java Plug-in. Now repeat the check to see if your browser will now use the correct Java Plug-in.

### From Netscape or Mozilla

Check to see if Java is enabled. Go to Edit → Preferences → Advanced → Check on Enable Java. To see what version of JRE Plug-in is used, go to Help → About Plug-ins. Scroll down to Java Plug-in section. Check if the Java Plug-in is the version you have installed.



**Tip.** When installing Netscape 7.0, it will ask if you want to install Sun Java. If you click on the box to install it, a version of JRE will be installed into your system; however, this does not mean that other browsers such as IE will recognize it. If you choose not to install Sun Java through Netscape but do it separately, Netscape 7.0 should automatically detect the JRE, and this can be checked by the instructions mentioned above.



# Appendix I - Connect to Serial Ports from Web

---

---

## Step-by-Step Process

**Step 1: Point your browser to the Console Server.**

In the address field of your browser type the Console Access Server's IP address. For example:

```
http://10.0.0.0
```

**Step 2: Log in.**

Log in with a user configured in the Web User Management section, and its password. This will take you to the Configuration and Administration page.

**Step 3: Select the Connect to Serial Ports link.**

Click on the Connect to Serial Ports link on the Link Panel to the left of the page in the Configuration section. This will take you to the Port Selection page. The ports will be listed by their server farm name if it were configured.



*Figure 44: Serial Port Connection page*

**Step 4: Select port.**

On the Port Selection page, choose a port to connect to from the dropdown menu and click the Connect button. This will open a new browser window that contains the applet connecting to the server chosen.

**Step 5: Log in.**

If the port selected was configured as `socket_server` or `raw_data`, and depending on how it is configured to be authenticated, log in by typing into the terminal.

# Appendix I - Connect to Serial Ports from Web

---

---



*Figure 45: SSH User Authentication Popup Window*

**Step 6:** Enter command.

Click in the terminal window and start entering commands.

**Step 7:** To send a break to the terminal.

Click on the SendBreak button.

**Step 8:** Disconnect connection.

Click on the Disconnect button. Make sure the Status bar shows an Offline status. Closing the popup window will also disconnect you from the server.

**Step 9:** Reconnect to port.

Refresh the current page by clicking on the refresh icon at the upper right hand corner of the window.

# Appendix J - Examples for Config Testing

---

---

## Introduction

The following three examples are just given to *test* a configuration. The steps should be followed *after* configuring the BLACK BOX® Advanced Console Server.

## Console Access Server


With the BLACK BOX® Advanced Console Server set up as a CAS you can access a server connected to the BLACK BOX® Advanced Console Server through the server's serial console port from a workstation on the LAN or WAN. There is no authentication by default, but the system can be configured for authentication to be performed by a Radius server, a TacacsPlus server, or even by a local database. Either telnet or ssh can be used.

See [Appendix A - New User Background Information](#) for more information about ssh. The instructions in [Chapter 2 - Installation, Configuration, and Usage](#) will set up a fully-functional, default CAS environment. More options can be added after the initial setup, as illustrated in [Chapter 3 - Additional Features](#).

An example of a CAS environment is shown in This configuration example has local authentication, an Ethernet interface provided by a router, and serially-connected workstations.

# Appendix J - Examples for Config Testing

The following diagram, shows additional scenarios for the BLACK BOX® Advanced Console Server: both remote and local authentication, data buffering, and remote access.



*Figure 46: CAS diagram with various authentication methods*

As shown in the above figure, our “CAS with local authentication” scenario has either telnet or ssh (a secure shell session) being used. After configuring the serial ports as described in [Chapter 3 - Additional Features](#) or in [Appendix C - The pslave Configuration File](#), the following step-by-step check list can be used to test the configuration.

# Appendix J - Examples for Config Testing

---

## Step 1: Create a new user.

Run the `adduser <username>` to create a new user in the local database. Create a password for this user by running `passwd <username>`.

## Step 2: Confirm physical connection.

Make sure that the physical connection between the BLACK BOX ® Advanced Console Server and the servers is correct. A cross cable (not the modem cable provided with the product) should be used. Please see [Appendix B - Cabling, Hardware, and Electrical Specifications](#) for pin-out diagrams.

## Step 3: Confirm that server is set to same parameters as the BLACK BOX ® Advanced Console Server.

The BLACK BOX ® Advanced Console Server has been set for communication at 9600 bps, 8N1. The server must also be configured to communicate on the serial console port with the same parameters.

## Step 4: Confirm routing.

Also make sure that the computer is configured to route console data to its serial console port (Console Redirection).

## Step 5: Telnet to the server connected to port 1.

From a server on the LAN (not from the console), try to telnet to the server connected to the first port of the BLACK BOX ® Advanced Console Server using the following command:

```
telnet 200.200.200.1 7001
```

For both telnet and ssh sessions, the servers can be reached by either:

1. Ethernet IP of the BLACK BOX ® Advanced Console Server and assigned socket port.

or

2. Individual IP assigned to each port.

If everything is configured correctly, a telnet session should open on the server connected to port 1. If not, check the configuration, follow the steps above again, and check the troubleshooting appendix.

# Appendix J - Examples for Config Testing

Step 6: Activate the changes.

Now continue on to [Task 5: Activate the changes](#) through [Task 8: Reboot the BLACK BOX® Advanced Console Server](#) listed in [Chapter 2 - Installation, Configuration, and Usage](#).



Note: It is possible to access the serial ports from Microsoft stations using some off-the-shelf packages. Although Black Box is not liable for those packages, successful tests were done using at least one of them. From the application's viewpoint running on a Microsoft station, the remote serial port works like a regular COM port. All the I/O with the serial device attached to the Advanced Secure Console Port Server is done through socket connections opened by these packages and a COM port is emulated to the application.

## Terminal Server

The BLACK BOX® Advanced Console Server provides features for out-of-band management via the configuration of terminal ports. All ports can be configured as terminal ports. This allows a terminal user to access a server on the LAN.




Figure 47: Terminal Server diagram

The terminal can be either a dumb terminal or a terminal emulation program on a PC.

# Appendix J - Examples for Config Testing

---

No authentication is used in the example shown above and rlogin is chosen as the protocol. After configuring the serial ports as described in [Chapter 3 - Additional Features](#) or in [Appendix C - The pslave Configuration File](#), the following step-by-step check list can be used to test the configuration.

**Step 1: Create a new user.**

Since authentication was set to none, the BLACK BOX ® Advanced Console Server will not authenticate the user. However, the Linux Server receiving the connection will. Create a new user on the server called *test* and provide him with the password *test*.

**Step 2: Confirm that the server is reachable.**

From the console, ping 200.200.200.3 to make sure the server is reachable.

**Step 3: Check physical connections.**

Make sure that the physical connection between the BLACK BOX ® Advanced Console Server and the terminals is correct. A cross cable (not the modem cable provided with the product) should be used. Please see the [Appendix B - Cabling, Hardware, and Electrical Specifications](#) for pin-out diagrams.

**Step 4: Confirm that terminals are set to same parameters as the BLACK BOX ® Advanced Console Server.**

The BLACK BOX ® Advanced Console Server has been set for communication at 9600 bps, 8N1. The terminals must also be configured with the same parameters.

**Step 5: Log onto server with new username and password.**

From a terminal connected to the BLACK BOX ® Advanced Console Server, try to log in to the server using the username and password configured in step one.


**Step 6: Activate changes.**

Now continue on to [Task 5: Activate the changes](#) through listed in [Chapter 2 - Installation, Configuration, and Usage](#).

# Appendix J - Examples for Config Testing

## Dial-in Access

The BLACK BOX® Advanced Console Server can be configured to accommodate out-of-band management. Ports can be configured on the BLACK BOX® Advanced Console Server to allow a modem user to access the LAN. Radius authentication is used in this example and ppp is chosen as the protocol on the serial (dial-up) lines. Black Box recommends that a maximum of two ports be configured for this option.



*Figure 48: Ports configured for Dial-in Access*

After configuring the serial ports as described in [Chapter 3 - Additional Features](#) or in [Appendix C - The pslave Configuration File](#), the following step-by-step check list can be used to test the configuration.

**Step 1: Create a new user.**

Since Radius authentication was chosen, create a new user on the Radius authentication server called *test* and provide them with the password *test*.



# Appendix J - Examples for Config Testing

---

**Step 2: Confirm that the Radius server is reachable.**

From the console, ping 200.200.200.2 to make sure the Radius authentication server is reachable.

**Step 3: Confirm physical connections.**

Make sure that the physical connection between the BLACK BOX ® Advanced Console Server and the modems is correct. The modem cable provided with the product should be used. Please see [Appendix B - Cabling, Hardware, and Electrical Specifications](#) for pinout diagrams.

**Step 4: Confirm modem settings.**

The BLACK BOX ® Advanced Console Server has been set for communication at 57600 bps, 8N1. The modems should be programmed to operate at the same speed on the DTE interface.

**Step 5: Confirm routing.**

Also make sure that the computer is configured to route console data to the serial console port.

**Step 6: Perform a test dial-in.**

Try to dial in to the BLACK BOX ® Advanced Console Server from a remote computer using the username and password configured in step one. The computer dialing in must be configured to receive its IP address from the remote access server (the BLACK BOX ® Advanced Console Server in this case) and to use PAP authentication.

**Step 7: Activate changes.**

Now continue on to [Task 5: Activate the changes](#) through [Task 8: Reboot the BLACK BOX ® Advanced Console Server](#) listed in [Chapter 2 - Installation, Configuration, and Usage](#).

# Appendix J - Examples for Config Testing

---

---

This page has been left intentionally blank.

# Appendix K - Wiz Application Parameters

---

---

## Basic Parameters (wiz)

- Hostname
- System IP
- Domain Name
- DNS Server
- Gateway IP
- Network Mask

## Access Method Parameters (wiz --ac <type>)

(CAS profile)

- Ipno
- Socket\_port
- Protocol
- Users
- Poll\_interval
- Tx\_interval
- Idletimeout
- Conf.group
- <sN>.serverfarm
- pool\_ipno
- pool\_socket\_port
- pool\_serverfarm

# Appendix K - Wiz Application Parameters

---

---

- web\_WinEMS
- translation

(TS profile)

- Protocol
- Socket\_port
- Userauto
- Telnet\_client\_mode

## Alarm Parameter (wiz --al)

- Alarm
- xml\_monitor

## Authentication Parameters (wiz --auth)

- Authtype
- Authhost1
- Accthost1
- Authhost2
- Accthost2
- Radtimeout
- Radretries

# Appendix K - Wiz Application Parameters

---

- Secret

## Data Buffering Parameters (wiz --db)

- Data\_buffering
- Conf.nfs\_data\_buffering
- Syslog\_buffering
- Dont\_show\_DBmenu
- DB\_timestamp
- DB\_mode
- Syslog\_sess

## Power Management Parameters (wiz --pm)

- pmkey
- pmNumOfOutlets
- pmoutlet
- pmtype
- pmusers

# Appendix K - Wiz Application Parameters

---

---

## Serial Settings Parameters (`wiz --sset <type>`)

### (CAS profile)

- Speed
- Datasize
- Stopbits
- Parity
- Flow
- Dcd
- SttyCmd
- DTR\_reset

### (TS profile)

- Speed
- Datasize
- Stopbits
- Parity
- Flow
- Dcd

# Appendix K - Wiz Application Parameters

---

---

## Sniffing Parameters (wiz --snf)

- Admin\_users
- Sniff\_mode
- Escape\_char
- Multiple\_sessions

## Syslog Parameters (wiz --sl)

- Conf.facility
- Conf.DB\_facility

## Terminal Appearance Parameters (wiz --tl)

- Issue
- Prompt
- Lf\_suppress
- Auto\_answer\_input
- Auto\_answer\_output

# Appendix K - Wiz Application Parameters

---

---

## Terminal Server Profile Other Parameters (`wiz --tso`)

- Host
- Term
- Conf.locallogins



# Appendix L - Copyrights

---

## References

The Advanced Secure Console Port Server is based in the HardHat Linux distribution, developed by Montavista Software for embedded systems. Additionally, several other applications were incorporated into the product, in accordance with the free software philosophy.

The list below contains the packets and applications used in the Advanced Secure Console Port Server and a reference to their maintainers. The copyrights notices required in some packets are placed in the /COPYRIGHTS directory of the Advanced Secure Console Port Server image.

### Bash

Bourne Again Shell version 2.0.5a. Extracted from the HardHat Linux distribution.  
<http://www.gnu.org/software/bash>

### Bootparamd

NetKit Bootparamd version 0.17  
<ftp://ftp.uk.linux.org/pub/linux/Networking/netkit>

### Busybox

BusyBox version 0.60.2  
<ftp://ftp.lineo.com/pub/busybox/>

### Cron

Paul Vixie's cron version 3.0.1.  
[paul@vix.com](mailto:paul@vix.com)

### DHCPD

PhysTech DHCP Client Daemon version 1.3.20.p10.  
<http://www.phystech.com/download/dhcpd.html>

# Appendix L - Copyrights

---

---

## Flex

Flex version 2.5.4

vern@ee.lbl.gov

COPYRIGHT: This product includes software developed by the University of California, Berkeley and its contributors

## GNU

The GNU project

<http://www.gnu.org>

## HardHat Linux

MontaVista Software - HardHat version 2.1

<http://www.montavista.com>

## IPSec

The Linux FreeS/WAN IPsec version 1.9.8

<http://www.freeswan.org>

COPYRIGHT: This product includes software developed by Eric Young (eay@cryptsoft.com)

## IPtables

Netfilter IPtables version 1.2.2. Extracted from the HardHat Linux distribution.

<http://www.netfilter.org>

## Linux Kernel

Linux Kernel version 2.4.18. Extracted from the HardHat Linux distribution

<http://www.kernel.org>

## Net-SNMP

SourceForge Net-SNMP project version 5.0.3

<http://sourceforge.net/projects/net-snmp/>

# Appendix L - Copyrights

---

## NTP

NTP client

<http://doolittle.faludi.com/ntpclient/>

## OpenSSH

OpenSSH version 3.5p1

<http://www.openssh.org>

COPYRIGHT: This product includes software developed by the University of California, Berkeley and its contributors.

## OpenSSL

OpenSSL Project version 0.9.6g

<http://www.openssl.org>

COPYRIGHT: This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)

COPYRIGHT: This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)

## PAM

Linux PAM version 0.75

<http://www.kernel.org/pub/linux/libs/pam/>

## Portslave

SourceForge Portslave project version 2000.12.25. (modified). Includes pppd version 2.4.1 and rlogin version 8.10

<http://sourceforge.net/projects/portslave/>

## RSYNC

rsync version 2.5.5

<http://rsync.samba.org/rsync/>

## Syslog-ng

Syslog new generation version 1.5.17

<http://www.balabit.hu/products/syslog-ng/>

# Appendix L - Copyrights

---

---

## Tinylogin

TinyLogin version 0.80

<ftp://ftp.lineo.com/pub/tinylogin/>

## WEBS

GoAhead WEBS version 2.1 (modified)

<http://goahead.com/webserver/webserver.htm>

Copyright (c) 20xx GoAhead Software, Inc. All Rights Reserved

## ZLIB

zlib version 1.1.4

<http://www.gzip.org/zlib/>

# List of Figures

---

---

1. Cable Package #1 .....	20
2. Cable Package #2 .....	20
3. The BLACK BOX ® Advanced Console Server 32-Port, its cables, connectors and other box contents .....	21
4. The BLACK BOX ® Advanced Console Server 16-port, its cables, connectors and other box contents .....	22
5. Login page of the Web Configuration Manager .....	40
6. Configuration & Administration Menu page .....	40
7. General page .....	41
8. Choose a free COM port .....	52
9. Port Settings .....	53
10. The /etc/hostname file with hostname typed in .....	55
11. Contents of the /etc/hosts file .....	55
12. Configuration and Administration page .....	76
13. Port Selection page .....	76
14. Profile Section of Serial Port Configuration page .....	77
15. Serial Ports - Users Group Table Entry page .....	78
16. An example of the clustering feature .....	118
17. Example of Centralized Management .....	123
18. Edit Text File page .....	136
19. Data Buffering section of the Serial Port Configuration page .....	141
20. Data Buffering section of the General page .....	142
21. DHCP client section .....	153
22. First IP Tables page .....	167

# List of Figures

---

---

23. IP Tables Chains Table (table filter) . . . . .	167
24. IP Tables Rules Table (table: filter, chain: INPUT) . . . . .	168
25. IP Tables Append Rule (table: filter, chain: INPUT) . . . . .	169
26. Sniff Session section of the Serial Port Configuration page . . . . .	239
27. Syslog page 1 . . . . .	251
28. Cable 1 - Black Box RJ-45 to DB-25 Male, straight-through. . . . .	305
29. Cable 2 - Black Box RJ-45 to DB-25 Female/Male, crossover . . . . .	305
30. Cable 3 - Black Box RJ-45 to DB-9 Female, crossover . . . . .	306
31. Cable 4 - Black Box RJ-45 to Black Box RJ-45, straight-through . . . . .	306
32. Cable 5 - Black Box/Sun Netra Cable . . . . .	307
33. Loop-Back Connector . . . . .	307
34. Black Box\Sun Netra Adapter . . . . .	308
35. RJ-45 Female to DB-25 Male Adapter . . . . .	308
36. RJ-45 Female to DB-25 Female Adapter . . . . .	309
37. RJ-45 Female to DB-9 Female Adapter . . . . .	309
38. Data flow diagram of Linux-PAM . . . . .	338
39. Initial test . . . . .	363
40. Second screen, showing changed positions . . . . .	364
41. User List default page . . . . .	405
42. User Group List default page . . . . .	405
43. Access Limit List default page . . . . .	406
44. Serial Port Connection page . . . . .	417
45. SSH User Authentication Popup Window . . . . .	418
46. CAS diagram with various authentication methods . . . . .	420

# List of Figures

---

47. Terminal Server diagram .....	422
48. Ports configured for Dial-in Access .....	424

# List of Figures

---

---

This page has been left intentionally blank.



# List of Tables

---

1. Hardware vs. Configuration Methods	32
2. Applications Section	42
3. Configuration Section	43
4. Administration Section	44
5. Web User Management Section	44
6. Information Section	45
7. Master Black Box Configuration (where it differs from the CAS standard)	119
8. BLACK BOX® Advanced Console Server configuration for Slave 1 (where it differs from the CAS standard)	121
9. BLACK BOX® Advanced Console Server configuration for Slave 2 (where it differs from the CAS standard)	121
10. General Options for the Help Wizard	188
11. Help CLI Options - Synopsis 1	190
12. Help CLI Options - Synopsis 2	192
13. Help CLI Options - Synopsis 3	193
14. vi modes	286
15. vi navigation commands	287
16. vi file modification commands	287
17. vi line mode commands	287
18. Process table	293
19. BLACK BOX® Advanced Console Server power requirements	297
20. BLACK BOX® Advanced Console Server environmental conditions	297
21. BLACK BOX® Advanced Console Server physical conditions	298
22. BLACK BOX® Advanced Console Server safety specifications	298
23. Cables and their pin specifications	302

# List of Tables

---

---

24. Which cable to use .....	303
25. Parameters Common to CAS, TS, & Dial-in Access .....	311
26. Mostly CAS-specific Parameters .....	321
27. TS Parameters .....	331
28. Dial-in configuration Parameters .....	333
29. Files to be included in /etc/config_file and the program to use .....	360
30. CPU LED Code Interpretation .....	368
31. Required information for the OpenSSL package .....	369
32. Windows XP + JREv1.4.0_01 or 02 .....	415

# Glossary

---

## Authentication

Authentication is the process of identifying an individual, usually based on a username and password. In security systems, authentication is distinct from authorization, which is the process of giving individuals access to system objects based on their identity. Authentication merely ensures that the individual is who he or she claims to be, but says nothing about the access rights of the individual. (Source: [www.webopedia.com](http://www.webopedia.com))

## Break Signal

A break signal is generated in an RS-232 serial line by keeping the line in zero for longer than a character time. Breaks at a serial console port are interpreted by Sun servers as a signal to suspend operation and switch to monitor mode.

## Console Access Server (CAS)

A CAS has an Ethernet LAN connection and many RS-232 serial ports. It connects to the console ports of servers and networking equipment and allows convenient and secure access from a single location.

## Console Port

Most of the equipment in a data center (servers, routers, switches, UPS, PBX, etc.) has a serial console port for out-of-band management purposes.

## Cluster

A cluster is a group of one or more computers working as a group to execute a certain task. From the user standpoint, a cluster acts as a large computer system.

## Flash

Flash refers to a type of memory that can be erased and reprogrammed in units of memory known as blocks rather than one byte at a time; thus, making updating to memory easier.

## In-band network management

In a computer network, when the management data is accessed using the same network that carries the data, this is called “in-band management.”

# Glossary

---

---

## IP packet filtering

This is a set of facilities in network equipment that allows the filtering of data packets based on source/destination addresses, protocol, TCP port number and other parameters. Packet filtering is one of the main functions of a firewall.

## KVM Switch (KVM)

Keyboard-Video-Mouse Switches connect to the KVM ports of many computers and allow the network manager to access them from a single KVM station.

## Mainframe

Large, monolithic computer system.

## MIBs

Management Information Bases. SNMP-compliant devices, called agents, store data about themselves in MIBs and return this data to the SNMP requesters.

## Out-of-band network management

In a computer network, when the management data is accessed through a network that is independent of the network used to carry data, this is called “out-of-band network management.”

## Off-line data buffering

This is a CAS feature that allows capture of console data even when there is no one connected to the port.

## Profile

Usage setup of the Advanced Secure Console Port Server: either as a Console Access Server (CAS), a Terminal Server, or a Remote Access Server.

## RADIUS

Protocol between an authentication server and an access server to authenticate users trying to connect to the network.

# Glossary

---

## RISC

Reduced Instruction Set Computer. This describes a computer processor architecture that uses a reduced set of instructions (and achieves performance by executing those instructions very fast.) Most UNIX servers (Sun Sparc, HP, IBM RS6000, Compaq Alpha) were designed with a processor using a RISC architecture. The Intel<sup>®</sup> x86 architecture.

## RS-232

A set of standards for serial communication between electronic equipment defined by the Electronic Industries Association in 1969. Today, RS-232 is still widely used for low-speed data communication.

## Secure Shell (SSH)

SSH has the same functionality as Telnet (see definition below), but adds security by encrypting data before sending it through the network.

## Server Farm

A collection of servers running in the same location (see Cluster).

## SNMP

Short for Simple Network Management Protocol, a set of protocols for managing complex networks. The first versions of SNMP were developed in the early 80s. SNMP works by sending messages, called protocol data units (PDUs), to different parts of a network. SNMP-compliant devices, called agents, store data about themselves in Management Information Bases (MIBs) and return this data to the SNMP requesters. (Source: Webopedia)

## Telnet

Telnet is the standard set of protocols for terminal emulation between computers over a TCP/IP connection. It is a terminal emulation program for TCP/IP networks such as the Internet. The Telnet program runs on your computer and connects your PC to a server on the network. You can then enter commands through the Telnet program and they will be executed as if you were entering them directly on the server console. This enables you to control the server and communicate with other servers on the network. To start a Telnet session, you must log in to a server by entering a valid username and password. Telnet is a common way to remotely control Web servers. (from webopedia.com)

# Glossary

---

---

## Terminal Server

A terminal server has one Ethernet LAN port and many RS-232 serial ports. It is used to connect many terminals to the network. Because they have the same physical interfaces, terminal servers are sometimes used as console access servers.

## TTY

The UNIX name for the COM (Microsoft) port.

## U Rack height unit

A standard computer rack has an internal width of 17 inches. Rack space on a standard rack is measured in units of height (U). One U is 1.75 inches. A device that has a height of 3.5 inches takes 2U of rack space.

# Index

---

## A

Access Method 73  
Alarm 181  
Authentication 100

## B

Basic Wizard 66

## C

Cable Length 301  
CLI 32  
Clustering 118  
Command Line Interface 32, 65  
Configuration using a Web browser 39  
Connectors 302  
CronD 134  
Custom Wizard 35

## D

Data Buffers 137  
Default Configuration Parameters 32  
DHCP 150  
DNS Server 34  
Domain 35

## E

Ethernet 33

## F

Filters 156  
Flash Memory Loss 359

## G

Gateway 33  
    default 34  
Generating Alarms 172

## H

Hardware Specifications 297  
Hardware Test 362  
HyperTerminal 33

## I

IP Address 34  
IPsec 373

## K

Kerberos 101, 106, 318  
Kermit 33

## L

Linux File Structure 284  
Linux-PAM 337

## M

Minicom 33

# Index

---

---

## **N**

Netmask 34  
NTP 195

## **P**

Passwords 283  
Port Test 362

## **R**

Radius authentication 424  
Routing Table 288  
RS-232 Standard 300

## **S**

Secure Shell Session 289  
Sendmail 181

Sendsms 181  
Snmpttrap 181  
Syslog-n 256  
System Requirements 31

## **T**

Terminal Appearance 271  
Time Zone 280

## **U**

Upgrades 357  
Using 72  
Using the Wizard through your Browser 72

## **W**

Wizard 34



This page has been left intentionally blank.



© Copyright 2002, Black Box Corporation. All rights reserved.

---

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax: 724-746-0746