

**DTX5002-T
Firmware Revision 3.0.0.11
Release Notes
April 28th 2008**

This document outlines:

1. DTX5002-T Firmware Version and Compatibility
2. Important Installation Notes
3. How to Update Firmware
4. Enhancements
5. Fixes
6. Notes

**DTX5002-T System Firmware Version and Compatibility
Version 3.0.0.11**

Version 3.0.0.11 of DTX System firmware is intended to be used in a system with the following DTX system-component revisions:

- DTX5002-T Revision 3.0.0.11
- DTX5002-R Revision 3.0.0.11
- DTX5000-CTL Revision 2.0.0 Build# 5396

Important Installation Notes

When upgrading directly it is important to upgrade Transmitters before upgrading Receivers.

How to Update Firmware

It is recommended to use DTX5000-CTL to upgrade Transmitters.

The Transmitter can also be upgraded using a serial or http upgrade procedure, as described below.

Prior to upgrading/downgrading:

1. Remove any attached vMedia devices (memory key or CD\DVD ROM)
2. When reverting to a previous version of firmware always set:
 - a. The Network Speed on both Transmitter and Receiver to Auto-Negotiate.
 - b. The Target Video to DVI-Normal or VGA-Normal.

Procedure 1 – Upgrade using DTX5000-CTL

This procedure assumes that the receiver is already being managed by DTX5000-CTL.

1. Upload the unit firmware file using the System > Unit Files > Add button in DTX5000-CTL.
2. In DTX5000-CTL, click on the Units tab. A list is displayed of all the units that are managed by DTX5000-CTL.

3. Click the appropriate unit name. The Unit Overview window will open.
4. In the Tools section, click the Upgrade Firmware icon. The Upgrade Unit Firmware wizard will launch.
5. Click Next. The Select Firmware Files window will open.
6. Select the appropriate firmware file and click Next. The unit will upgrade and reboot.
7. The upgrade should take approximately 2 minutes.

Multiple units can also be upgraded in parallel by using the Upgrade Firmware button on the **Units – All** screen in DTX5000-CTL.

Procedure 2 - Serial port upgrade of the Transmitters

1. Power up the Receiver and Transmitter and make sure there is a connection between them.
2. Connect the Receiver via a null modem cable to a PC running HyperTerminal or equivalent. Configure the HyperTerminal session for 57600 bits per second, 8 data bits, no parity, 1 stop bit and no flow control.
3. From the first screen on the console, select option 2 to access the Transmitter menu. If the password option is enabled, you will be prompted for a password ("password" is the default).
4. From the Transmitter menu select option 3; "*Firmware Management*".
5. Confirm that Transmitter has upgraded correctly by checking the "appliance information" on the console menu.
6. Choose *Transmitter Flash Upgrade Via XMODEM*.
7. Specify the location of the upgrade file *TX1000_XXXX.dld* and initiate the file transfer. The upgrade should be completed in approximately 35 minutes.
8. After 15 minutes the message "connection to Transmitter lost" will appear on the serial session. It is important NOT to unplug the Transmitter power as the upgrade is still running. Leave unit power for at 5 more minutes.
9. Connect again via the serial menu to the TX and confirm the new revision.

Procedure 3 - Upgrade using HTTP.

1. Power up the Receiver and Transmitter and make sure there is a connection between them.
2. Connect the Receiver via a null modem cable to a PC running HyperTerminal or equivalent. Configure the HyperTerminal session for 57600 bits per second, 8 data bits, no parity, 1 stop bit and no flow control.
3. Choose option 2 on the *Main Menu* to access the *Transmitter menu*. If the password option is enabled, you will be prompted for a password
4. From the *Transmitter menu* select option 3 "*Firmware Management*".
5. Choose *Transmitter Flash Upgrade Via HTTP*. You will be prompted to enter the URL for the upgrade file.
6. Enter the URL for the upgrade file using the following syntax:

http://<server IP address>[:server port]/<upgrade file path>

For example:

http://192.168.0.1:8080/TX1000_XXXX.dld

Note: If the server is set up on standard port 80, the port information can be omitted

7. The upgrade should take approximately 5 minutes.
8. Wait 5 minutes after you receive the message "connection to Transmitter Lost.
9. Confirm the new revision is displayed on the serial console of the Transmitter.

Enhancements

1. Matrix mode is now available on DTX5002-T
2. USB Keyboard and Mouse:
 - Improvements in reliability of USB connection and disconnection when switching. A generic keyboard and mouse is now permanently connected to the computer from the transmitter
 - Keyboard and mouse are available at the same time as video when switching. Previously, keyboard and mouse became available several seconds after the video
3. vMedia:
 - Improvements in the reliability of connection and disconnection when switching. The vMedia device is not automatically connected to the computer after switching (see notes below).
4. Video Support:
 - Improvements in the compatibility between the user monitor and the computer graphics card. This ensures that the computer will not be requested to output a video resolution that is incompatible with the Black Box DTX5002-R/DTX5002-T, and the user will be prompted if the video resolution is incompatible with their monitor.

Fixes

1. USB Keyboard and Mouse:
 - Previously, keyboard and mouse was occasionally not available after making a switch to a computer and this required a power cycle of the Receiver to recover.
 - The receiver now supports more than one USB keyboard or Mouse.
2. vMedia:
 - Improvements in the reliability of connection and disconnection when switching. The vMedia device is not automatically connected to the computer after switching (see notes below).
 - vMedia previously not being detected on a Linux computer
 - Previously, USB memory keys were not reliably detected on MAC Targets.
 - Previously copying very large files from the USB memory stick could cause USB to hang.
3. Video Support:
 - During BIOS, video could be disconnected if the keyboard was pressed. This is now resolved.
 - EDID issues resolved where in previous revisions the maximum resolution available was 800 X 600 despite the monitor being capable of far higher resolutions.

Notes

1. Multimedia keyboard keys are not supported.
2. Hot-plug of the network connection is not supported.
3. After switching to a computer the vMedia is only connected to the computer after a hot-plug of the vMedia device.
4. vMedia devices are only appear on the target computer when they are connected to a receiver, this was not the case in previous revisions where the Transmitter appeared as a vMedia device.
5. In the event that a monitor does not support the resolution output by the computer the Receiver and Transmitter automatically set the resolution to the default resolution advertised by the monitor thereby providing a clipped view of the computers desktop. The resolution can then be adjusted as necessary. This may cause scrolling vide in the case where the resolution output by the computer is less that the default resolution of the monitor.