


## Desktop Speakerphone

Your Desktop Speakerphone converts your wireless handset into a speakerphone for use in your home or office.



### Features

- Rapidly charges the phone's battery.
- Positive lock for reliable connection to the wireless phone.
- Housing made of durable, high-impact plastic.
- Wall-mounted power source included for maximum portability.

## Controls and Connectors

- **Volume control** increases or decreases speaker volume.
- **Mute button** will alternately mute or activate the microphone. When in mute mode, the Mute LED will flash.
- **Headset jack**, when used with the optional headset, offers hands-free operation. Use the phone volume control in headset mode.

## Instructions for Use

### *Initial setup:*

Plug the wall-mounted power supply into a wall outlet or power strip. Then plug the barrel plug in the Desktop Speakerphone's power jack.

Set the volume control by adjusting the phone volume to mid-range; then adjust the volume control on the Desktop Speakerphone to the desired sound level.

### *To make or receive a call:*

- Extend the phone's antenna for the best possible reception.
- Slide the phone in the cradle at an angle until the connector fully engages.
- Make or receive a call on the phone (see the phone owner's manual for instructions).
- Adjust the speaker volume as necessary using the Desktop Speakerphone's volume control.

## Frequently Asked Questions

- Q. How do I know if my phone is seated properly in the cradle?
- A. The Power LED will light once the phone is seated in the cradle. It will continue to stay lit as long as the phone remains seated.
- Q. What position should the Desktop Speakerphone be in to give the best performance?
- A. The enhanced microphone and high-mass speaker provide excellent sound performance in most home and office desktop environments. For best performance, the unit should sit on a flat surface with the front facing you.