


To install the DSL Surge Protector, connect the DSL Surge Protector's *equipment side* to your external DSL modem (see the above illustration). Connect the *line side*, using the RJ-11 cable provided, to the RJ-11 or RJ-45 DSL jack from the wall plate. Ground the surge protector by connecting the ground wire to a ground screw on the wall plate of an AC grounded outlet.

© Copyright 2000. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746



DSL Surge Protector



Use the DSL Surge Protector to provide absolute protection for your DSL modems. This surge protector has a convenient plug-and-play-design, a self-resetting circuit, a bi-polar diode design, and a high MTBF rating.

Turn over this page for installation instructions.

CUSTOMER SUPPORT INFORMATION

Order **toll-free** in the U.S.: Call **877-877-BBOX** (outside U.S. call **724-746-5500**)

FREE technical support 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**

Mailing address: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018

Web site: www.blackbox.com • E-mail: info@blackbox.com